Red - physical
Dashed blue - information

Ground Segment
- Monitor and command transport ACT-13
- Plan end-of-life disposal ACT-14

Telecommands FE-03
Telemetry FE-04
Disposal command FE-09

Cislunar Cargo Tug
- Execute telecommands SF-03.7
- Manage modes and failures SF-03.9
- Provide telemetry SF-03.8
- Perform disposal manoeuvre SF-07.1

Operational commands FE-18
Housekeeping and mode status FE-19

Sun
- Provide sunlight

Sunlight FE-10

Navigation state FE-15
Disposal trajectory FE-23
Passivation order FE-24
Relative navigation state FE-16

- Generate electrical power SF-03.5
- Determine orbit and attitude SF-03.3
- Control trajectory and attitude SF-03.4
- Passivate the system SF-07.2

Raw power FE-11
Thrust command FE-17
Thruster power FE-12

- Store and distribute electrical power SF-03.6
- Generate thrust SF-03.1
- Perform rendezvous and proximity navigation SF-03.10

Lunar Orbit Destination
- Clear approach and docking ACT-15

Approach clearance FE-05

Xenon feed FE-14

Propellant Module
- Supply propellant in orbit ACT-18

Propellant FE-02

- Receive propellant in orbit SF-02
- Store and feed propellant SF-03.2

Xenon to storage FE-13

Docked state FE-21

Launch Vehicle
- Launch cargo and propellant to staging orbit ACT-04

Cargo in staging orbit FE-01

- Capture cargo in Earth staging orbit SF-01
- Hand over cargo at lunar destination SF-04
- Receive delivered cargo ACT-16

Secured cargo FE-20
Delivered cargo FE-06

- Hand over return cargo in Earth orbit SF-06
- Collect return cargo SF-05
- Provide return cargo ACT-17

Secured return cargo FE-22
Return cargo FE-07

Returned cargo FE-08

Cargo Customer
- Receive returned cargo ACT-03