Remote Controller Overview

Power: Press and hold both power buttons simultaneously to turn the remote controller on or off.
Unlocking: After switching on the power, move all four switches SWA/B/C/D to their uppermost positions to unlock the remote controller.
Safe remote control: After unlocking the remote controller, move all four switches SWA/B/C/D to their lowermost positions to enter safe remote control mode.
Safe remote control mode: SWA (down): half-speed mode; SWB (down): remote control mode; SWC (down): no function; SWD (down): emergency stop released.
Clearing an accidental bumper trigger: If a bumper collision is triggered and the chassis cannot move, toggle SWD up and down to restore normal operation. This can also be done using the red emergency stop button on the vehicle: press the emergency stop button, then release it.



Refer to the table below for the remote control functions.

Stick / Switch	Function	Description
Left stick	Forward	Move the left stick up (up arrow).
Left stick	Reverse	Move the left stick down (down arrow).
Left stick	Lateral movement	Move the left stick left or right (left/right arrows).
Left stick	Diagonal movement	Move the left stick diagonally: upper left, upper right, lower left, or lower right.
Right stick	Turn left	Move the right stick left (left arrow).
Right stick	Turn right	Move the right stick right (right arrow).
SWA (up / down)	Half speed	SWA (up): full speed SWA (down): half speed
SWB (up / center / down)	Control mode selection	SWB (up): charging mode SWB (center): host computer control mode SWB (down): remote controller control mode
SWC (up / center / down)	None	SWC (up): double Ackermann steering mode SWC (center): Ackermann steering mode SWC (down): omnidirectional wheel mode
SWD (up / down)	Emergency stop	SWD (up): enable emergency stop SWD (down): release emergency stop
VRA (up / center return / down)	None	None
VRB (up / center return / down)	None	None

Notes on automatic charging

1. Place the back of the charging dock firmly against a fixed wall or another immovable object.
2. Remote-controlled charging: Drive the vehicle to a position 1 m directly in front of the charging dock, then enable remote-controlled charging mode (SWB up).
3. When docking for the first time, check that the copper contacts on the charging dock and the vehicle charging module make full contact. If contact is poor, manually adjust the charging dock height by rotating its base.
4. Charging dock LED strip colors:
    1) Green: not charging;
    2) Blue: identifying the automatic charging program;
    3) Red: charging.

- Note: Use the red indicator light on the charger to confirm whether charging is taking place normally.