- User Manual -

How To Use The Device : -

1. Switch ON the Device.
2. Then wait 10 seconds.
3. Then Open Your WiFi and refresh it again and again … while a signal shows " AutoConnectAP " network .. immediately connect to that network and wait for 10-15 seconds.
4. Then open browser (Chrome , Opera, etc..) , search the local IP 192.168.4.1 then it will show 3 option … You just click on CONFIGURE then set the WiFi name and Password which is currently on (** not your phone that you are using now to set up**) , save it.
5. After saving WiFi name and Password successfully then the NodeMCU's blue led light will glows up which shows that WiFi is connected successfully. If NodeMCU's blue led light does not glows up then probably wifi id & pass is wrong . If all is ok but blue led light does not glows up then open the box and press the RST and FLASH button of NodeMCU, 95% chance is that the blue led light will glows up. ** Once the WiFi network is connect then the same network will automatically when you switch on the Device if the Hotspot or Fiber in ON . No need to connect every time with same network**
6. Once a WiFI is connected your Device is ready to use.
7. Swipe or Hold the RF id card for 2 second to scan and a beep sound will produce that means it is a successful scan.
8. Wait for minimum 8 second after a successful scan.
9. Scan the QR Code pasted on the device to access the Attendance Sheet.

Point that should be follow :-

1. Use a Best and Fast Internet Connection.
2. If any malfunctioning happens the press the RST and FLASH button of NodeMCU.
3. Charging : Use a normal USB-C charger ,not a Superfast High watt charger .. it may be damaged . << CAUTION…   (** 5V charger is best for that)
4. While charging, Open the box and see … if red light is ON it means Charging if it shows blue light Battery is full .. plug out the charger.

While charging Keep the Device Switch OFF … It will be Damaged

BY : Rohan Sen
B.Tech ECE 2nd Year (28-10-2025)
24IUT0010217