

Website: <https://www.printess.org>

Follow-Along Instructional Video: <https://www.youtube.com/watch?v=ZmEkr5MQ0lw>

Component	Quantity	Cost per unit	Total cost	Source of materials	Product/Model number
RUMBA+ board	1	\$27.17	\$27.17	Aliexpress	
TMC2208 Stepper Motor Drivers	6	\$4.4	\$26.38	Amazon	ASIN: B07RK28VWC
100mm Linear Stepper Motors	4	\$23.41	\$93.64	Aliexpress	Select T6*1 (1 mm pitch) and Stroke 100 mm
50mm Linear Stepper Motors	2	\$21.75	\$43.50	Aliexpress	Select T6*1 (1 mm pitch) and Stroke 50mm
Power Supply	1	\$9.99	\$9.99	Amazon	ASIN: B0D2CBVVLN Includes power jack adapter
Wires	2	\$0.06	\$0.12	Amazon	
12mm M3 Screws	70	\$0.11	\$7.70	McMaster	91290A117
55mm M3 Screws	8	\$0.41	\$3.32	McMaster	91290A181
M3 Nuts	50	\$0.07	\$3.75	Amazon McMaster	ASIN: B06XPFLNBS
M3 Heat-Set Inserts	26	\$0.20	\$5.31	McMaster	3D-printed parts are designed for a heat set insert outer diameter of 5.5mm. Most on Amazon are 5mm. Parts can be redesigned with smaller heat-set through-holes to accommodate 5mm inserts.
¼" 12 x 12 or 8 x 12 Acrylic	2	\$7.5	\$14.99	Amazon McMaster	ASIN: B07X8F9X4K
PLA Filament	<0.4kg	\$14/kg	\$6	Amazon	ASIN: B07PGY2JP1
Syringes	as needed			Syringe adapters were designed for BD syringes	
Syringe dispensing tips	as needed			McMaster	

Bill of Materials. Total printer cost is approximately \$250, not including shipping and tax. Please note, costs may change and cheaper alternatives may be available.

Supporting Methods: Printess Manual

Assembly Instructions.....	3
Install VSCode and Upload Firmware.....	11
Install Pronterface.....	13
Pronterface Guidelines.....	13
Install Python.....	15
Crucial GCode Commands and Examples.....	16
Optional Commands.....	19
GCode Visualizer.....	19
Useful Terminal Commands for Unix Shell (Mac).....	20
Using Python Script to Calculate Extruder Distances.....	20
Using CURA to Slice 3D Models to GCode.....	22
Troubleshooting.....	25
Alternative Components Assembly.....	27
Alternative Base Upgrades.....	27
Mixing Nozzle.....	28
Syringe Cooler Assembly.....	30
Tissue Culture Cooling Plate Assembly.....	31
Tip-Tilt Bed Leveling Platform Assembly.....	34
Ball-Screw Carriage for Reduced Backlash.....	36

Safety: We remind readers that (1) the Printess is not a toy and contains moving mechanical parts and electronic components, (2) its operation should be closely supervised by someone familiar with standard machine shop precautions, including removing loose jewelry and clothing, and tying hair back, and (3) the motors should be current limited using the driver trim-pots at a level that is just sufficient for printer operation.

To build the Printess, you will first need to 3D print and laser cut all the components and assemble the printer, including wiring the RUMBA control board (See “Assembly Instructions”). You will then need to upload the Marlin firmware to the RUMBA board (See “Install Arduino and Upload Firmware”). Subsequently, you can install the Pronterface GUI (See “Install Pronterface”) and set up the Python algorithm to calculate extrusion distances for your G-code scripts (See “Install Python” and “Using Python Script to Calculate Extruder Distances”). If you are unfamiliar with G-code, the “Crucial G-code Commands and Examples” section may be helpful. We have additionally provided a troubleshooting section. If you wish to build any of the additional components, such as the syringe cooler, tissue culture cooling plate, or tip-tilt platform, you will find sections with those instructions following the troubleshooting section.

Assembly Instructions

All CAD files, firmware, and scripts are available open-source on Zenodo at <https://doi.org/10.5281/zenodo.13173619>. The latest versions of these files and the construction and operation manual can be found on Github at:

<https://github.com/weiss-jonathan/Printess-Low-Cost-3D-Printer>. If you run into path length issues when unzipping the repository folder using your native OS unzipper, you can use a 3rd party unzipper, such as 7-Zip, which should bypass the issue.





Required hardware and tools:









- 1) FDM 3D printer
- 2) Laser Cutter
- 3) Soldering iron with heat-set insert tip
- 4) Screwdriver set

Tools for optional components:

- 5) Mixing nozzle: rotary tool or saw
- 6) Multinozzle printhead: SLA printer
- 7) Syringe cooler: vacuum chamber

Begin by 3D printing the following CAD files and laser cutting the SVG files for the back and base. The required and optional files are provided in both .stl and .step format within their respective folders. We have had success printing the CAD files on the Mark 2 3D printer (MarkForged, Watertown, MA) using black onyx and carbon fiber materials. Subsequent printer iterations have been successfully printed on a Prusa printer in PLA. For the base and back, $\frac{1}{4}$ " thick 12" by 12" black acrylic sheets were laser cut on a Glowforge machine, but can be cut on any laser cutter accommodating acrylic material.

Part name	Suggested Printing Orientation	File type	Quantity	Filename (.stl, .step, and .pdf, .eps, or .dxf files provided)
<u>Required components</u>				
Right Brace 		CAD	1	Right Brace Thick.stl Right Brace Thick.step
Left Brace 		CAD	1	Left Brace Thick.stl Left Brace Thick.step
Triangle Brace 		CAD	2	Right Triangle Brace.stl Right Triangle Brace.step Left Triangle Brace.stl Left Triangle Brace.step


Base Feet			CAD	2	Base Feet.stl Base Feet.step
X and Y axis connector			CAD	1	XY Axes Connector.stl XY Axes Connector.step
Z axis-to-extruder connector			CAD	2	Z-Axes Holder.stl Z-Axes Holder.step
Syringe Plunger Holder: 1mL			CAD	2	1mL Plunger Holder.stl 1mL Plunger Holder.step
Syringe Barrel Holder: 1mL			CAD	2	1mL Barrel Holder.stl 1mL Barrel Holder.step
Platform attachment: flat			CAD	1	Stage.stl Stage.step
Base			PDF	1	Acrylic Bottom.pdf Acrylic Bottom.eps Acrylic Bottom.dxf
Back			PDF	1	Acrylic Back.pdf Acrylic Back.eps Acrylic Back.dxf
<u>Optional components</u>					
Syringe plunger holder: 3mL			CAD	optional	3mL plunger holder.stl 3mL plunger holder.step
Syringe barrel holder: 3mL			CAD	optional	3mL Barrel Holder.stl 3mL Barrel Holder.step
Syringe plunger holder: 5mL			CAD	optional	5mL plunger holder.stl 5mL plunger holder.step
Syringe barrel holder: 5mL			CAD	optional	5mL Barrel HolderL.stl 5mL Barrel Holder.step
Syringe plunger holder: 10mL			CAD	optional	10mL Plunger Holder.stl 10mL Plunger Holder.step


Syringe barrel holder: 10mL		CAD	optional	10mL Syringe Barrel Holder.stl 10mL Syringe Barrel.step
Platform attachment: 90mm petri dish		CAD	optional	90mm Petri Dish Holder.stl 90mm Petri Dish Holder.step
Platform attachment: 35mm petri dish		CAD	optional	35mm Petri Dish Holder.stl 35mm Petri Dish Holder.step
Platform attachment: cube holder		CAD	optional	Cubic container holder.stl Cubic container holder.step
Platform attachment: 6 well-plate		CAD	optional	6 well plate holder.stl 6 well plate holder.step
Mixing Nozzle		CAD	optional	Mixing Nozzle Body.step Mixing Nozzle Body.stl Impeller.step Impeller.stl Motor Spacer.step Motor Spacer.stl 3mL Connected Barrel Holder for Mixing Nozzle.step 3mL Connected Barrel Holder for Mixing Nozzle.stl
8-Multinozzle		CAD	optional	8x1 Bimaterial Multinozzle Printhead.stl 8x1 Bimaterial Multinozzle Printhead.step 1mL Multinozzle Barrel Holder.stl 1mL Multinozzle Barrel Holder.step 3mL Multinozzle Barrel Holder.stl 3mL Multinozzle Barrel Holder.step
32-Multinozzle		CAD	optional	8x4 Bimaterial Multinozzle Printhead.stl 8x4 Bimaterial Multinozzle Printhead.step
Tip tilt platform		CAD	optional	Tip-Tilt Platform.stl Tip-Tilt Platform.step
Syringe cooling sleeve		CAD	optional	Cooling Sleeve for 1mL BD syringe.stl Cooling Sleeve - Cooling Sleeve Disc For Vacuum.stl Cooling Plate Vertical - 3D Printed.stl Cooling Sleeve for 1mL BD syringe.step Cooling Sleeve - Cooling Sleeve Disc For Vacuum.step Cooling Plate Vertical - 3D Printed.step
Cooling bed		CAD	optional	Laser Cut from 3mm Acrylic - Cooling Plate Padding.PDF Laser Cut from 6mm Acrylic - Cooling Plate Main Body and Crossbeam.PDF
Motor safety stopper		CAD	optional	Motor Safety Stopper.stl Motor Safety Stopper.step

Description of 3D printed components:

- Supports: The right, left, and triangle supports offer stability to the printer and help minimize vibrations during printing.
- Axes connectors: These parts allow for the connection between linear stepper motors.
- Platform attachments: A variety of compatible build platforms are available including petri dish, cube holder, and 6 well-plate.
- Syringe plunger and barrel holders: A variety of syringe mounting designs are available that can accommodate 1 mL, 3 mL, 5 mL, and 10 mL Nordson plastic syringes. You can use different sizes on each of the two Z axes, and the plunger and barrel holder on one side must match in size.

After printing the components and removing supports, first insert the 4 mm M3 heat-set inserts into the cavities of the designated components as pictured below. Heat-setting requires a soldering iron with a heat-set insert tip (it is possible without one so long as you can make good contact with the insert) set at a working temperature of ~600°F. An additional tutorial on heat setting can be found [here](#).






Step 8) Attach one 100mm travel length stepper motor to the left side of the back plate. Repeat for the right side.

Use (M3 x 12mm screws and hex nuts with washers) for the attachments


Note: The left stepper motor is the Z-Axis and right motor is the A-axis



SCALE 1:2

Step 9) Attach the Z and A axis holder to the stages of their respective stepper motors.

Use (M3 x 60mm screws) for the attachments. The screw goes through these holes as shown




Step 10) Attach one 50mm travel stepper motor to the axis holder. Repeat for the other axis holder.

Use (M3 x 12mm screws)

Note: There should be square nuts in the back of the axis holder.

Of these smaller stepper motors, the left is the B-axis and the right is the C-axis.




Step 11) Attach one of the plunger holders to the stage of the B-axis. Repeat for the C-axis.

Use (M3 x 12mm screws) for the attachments.



Step 12) Attach one barrel holder to the Z-axis connector. Repeat for the A-axis holder.


Use (M3 x 12mm screws) for the attachments.



Step 13) Attach the print platform to the stage of the X-axis step motor.

Use (M3 x 12mm screws) for the attachments.

Note: The print platform can vary in shape and size.



Step 14) Attach the Rumba board to the back of the printessa.

Use (M3 x 12 mm screws and hex nuts with washers) for the attachment.



Note: You'll only be able to attach the board to the back using 3 of the available holes provided due to misaligned predrilled holes on the back plate

Step 15) Attach the wires leading from each of the stepper motors to the Rumba board.

Note: The order of the wire connections should be as follows:

(Black, Green, Red, Blue)

Update: Stepper motor wires are now connected using Dupont pin connections and would be plugged in to the 4 pin connection under each Rumba board stepper motor connector.



Note: Make sure these jumper pins are in the standalone position


Step 16) If the DC female power jack hasn't been connected. Attach two 24 - 20 AWG wires to the Rumba board. Black to negative terminal and a red wire to positive. Follow by connecting the loose ends to the jack. Black to negative, Red to Positive.

Dupont pin connectors as mentioned above are optional and can make the stepper motor connection more secure and easy to disassemble if necessary. [Video](#) on how to use Dupont pin connectors.

Component	Cost	Source of materials	Product/Model number	Notes
4-Pin Dupont Connector Kit	\$8.99	Amazon	ASIN: B07BDJ63CP	If you don't have a crimping tool, there are other kits available that include one.

Step 17) Make sure the Power Select Pin is set to Standalone power.

Step 18) Insert the stepper motor drivers into the board and ensure they are in the correct orientation by aligning the pins on your driver to the control board diagram below (i.e. "EN" in the top left corner). Inserting upside down will cause a short-circuit and irreversibly damage your board.



Step 19) Plug in the power adapter and attach the power jack to the RUMBA board and use the multimeter to confirm if the voltage is acceptable by putting the negative common probe to the negative terminal and red probe to the positive terminal of the female jack.

Step 20) Check if the stepper motor driver is correctly tuned. Using the multimeter, have the negative probe touching the negative terminal of the RUMBA board and positive probe touching the potentiometer of each of the stepper motors. The acceptable range is 0.36V to 0.5V. After this, assembly is complete.


After completing building the printer, you will need to connect a computer to the RUMBA board mounted on the back of the printer via the included mini USB cord. You can then proceed to 1) uploading the Marlin firmware to the RUMBA 2) installing the Pronterface GUI and 3) setting up the python script if needed to calculate extrusion distances for your G-code.

Over time, if you notice your stepper motors becoming squeaky or need to clean them of debris, you can lubricate the lead screw. We suggest WD-40 Specialist Dry Lube:


Component	Cost	Source of materials	Product/Model number	Notes
WD-40 Specialist Dry Lube	\$8.49	Amazon	300059	Apply directly to the lead screw with the 'smart straw' in a well-ventilated area. Press canister very lightly to avoid over-spraying. Move carriages around after application to distribute lubrication.

Install [VSCode](#) and Upload Firmware


Install plugin:



Select Marlin Folder:



Show ABM Panel:




Do not have the printer connected via Pronterface while uploading firmware.


[Arduino](#) IDE can also be used to upload the firmware to the RUMBA Board but may be very slow:

1. Download the Marlin Firmware file provided in Github. From within that folder, you can use the version for RUMBA or RUMBA32 depending on which board you have.
2. In the Marlin subfolder, open Marlin.ino in Arduino
3. Ensure that the RUMBA is plugged in and that the lights are on. Connect the board to the computer using a mini USB cable.

4. In Arduino, go to Tools -> Port and select the port that your board is connected to (mine is "usbmodem..."). If you aren't sure which port it is connected to, disconnect and reconnect, and look at which option disappears and reappears.
5. Tools -> Board and select "Arduino Mega or Mega 2560"
6. Ensure Tools -> Processor is "ATmega2560"



7. Click upload above the Marlin tab (Right arrow). There should be a message saying "Compiling Sketch" below. This will take 10-15 minutes. Ensure your laptop is plugged in as this is an energy intensive process.



Install Pronterface

Precompiled version to download the app:
<https://github.com/klement/Printron/releases>

Download the appropriate file for your operating system as shown below:



▼Assets 5

		38.6 MB	May 24, 2023
📦	printrun-2.0.1_macos-11_x64_py3.10.zip		
📦	printrun-2.0.1_macos-12_x64_py3.10.zip		
📦	printrun-2.0.1_windows_x64_py3.10.zip	34.9 MB	May 24, 2023
📄	Source code (zip)		May 24, 2023
📄	Source code (tar.gz)		May 24, 2023

22 people reacted

X64 is 64 bit (try this one first)

X86 is 32 bit

Pronterface Guidelines


- Connect your printer to your computer, click “Port” to refresh the available inputs, then click the drop down next to it and select the port your printer is connected to.
 - Ensure VSCode is closed if you just used it to upload the firmware.
- Ensure the baudrate is “@115200”
 - If you see errors that include “line number” or “checksum,” reduce the baudrate
- Change XY motor rate to 300. It is default to 3000. This is too fast for the motors and they will stall:



- In general, use the console in the bottom right to send lines of GCode to the printer:



- You may use the GUI controller to manually move the X, Y, and Z axes for quick adjustments, but **BEWARE** using these buttons will automatically reset your positioning system to G90 (see [GCode](#) below) even if you set it to G91 in the console. During experiments, we strongly suggest not using the GUI controller at all. You can move axes by sending commands such as “G1 X10” to the console. If you use the GUI, get into the habit of calling G91 before any motion commands in the console.



- To upload .txt GCode programs to run, click “Load file” at the top center. “SD, Print, Pause, Off” don’t do anything, so do not click those.
 - When uploading GCode text files to Pronterface, use .txt plain text, NOT rich text format (RTF). If usingTextEdit on mac, go to preferences and select “Plain Text,” then make a new document.
- If you need to emergency stop the printer in the middle of a program, you have to either click “Disconnect” FOLLOWED BY “Connect” or unplug the printer from the outlet. Note that every time you reconnect the printer, you need to reset calibrations (See G92 in GCode section below). This is not very convenient, sorry!

Optional:

Making Macros in Pronterface:

<https://github.com/kliment/Printrun/blob/master/README.md#using-macros-and-custom-buttons>

Install Python

To check current python version in terminal (mac) or command prompt (windows), type the below command:

```
python --version
```

A screenshot of a Mac OS X terminal window titled "jonathanweiss — bash — 80x24". The window shows the command "python --version" being run, followed by the output "Python 3.7.4". The window has its characteristic red, yellow, and green window control buttons at the top left.

If you do not have Python 3 and need to download python, do so here:

<https://www.python.org/downloads/>

If you use Windows, make sure python is added to your environmental variables. The complete path of python.exe can be added by:

1. Right-clicking This PC and going to Properties.
2. Clicking on the Advanced system settings in the menu on the left.
3. Clicking on the Environment Variables button on the bottom right.
4. In the System variables section, selecting the Path variable and clicking on Edit. The next screen will show all the directories that are currently a part of the PATH variable.
5. Clicking on New and entering Python's install directory.
 - a. C:\Users\...\Python

After downloading python 3, if your python --version still says you have Python 2, you can force python 3 to run by calling "python3" instead of "python". For more permanent solution, check out the forums below:

Windows:

<https://medium.com/@ryanmillerc/install-python-3-in-locally-in-appdata-alongside-python-2-in-windows-10-fe4287708429>

Mac:


<https://stackoverflow.com/questions/43354382/how-to-switch-python-versions-in-terminal>

It is easy to run python scripts using your terminal. We will need to run a python script to calculate extrusion distances. More on this [later](#).

Crucial GCode Commands and Examples

Familiarize yourself with all of the axes first. Stage Axes: X, Y; Vertical Axes: Z, A; Extrusion Axes: B, C. Practice moving each axis to learn which axes correspond to which motors and their polarity: for the vertical axes, positive motion is upwards, while for the extrusion axes, positive motion is downward.

Refer to <https://reprap.org/wiki/G-code> and <https://marlinfw.org/meta/gcode/> for more information, commands, examples, etc. Below is a summary of key commands.

Command	Description
G90	<p>Set system to <i>Absolute Positioning</i>. When using absolute positioning, all coordinates you provide will be read in the coordinate system you define. Thus, you need to first define your coordinate system, usually by designating an origin (0, 0, 0). See G92 below. Run on its own line.</p>
G91	<p>Set system to <i>Incremental Positioning</i>. All distances will be relative to the current location. Run on its own line.</p>
G92	<p>Recalibrate current position. Use mainly to set current position to origin.</p> <p>G90, G91, G92 Example (refer to diagram below). Our goal is to move our location from the origin in the bottom left to points 1, 2, and then 3:</p>  <p>G90; Set system to absolute positioning G92 X0 Y0; Set current positions in (X, Y) to (0, 0)</p> <p>G1 X10 Y10 F200; Move to the coordinates (10, 10) in (X, Y). This is point 1. G1 X30 Y20 F200; Move to the coordinates (30, 20) in (X, Y). This is point 2.</p>

	<p>G91; Set system to incremental positioning G1 X20 Y10 F200; Move 20 in X and 10 in Y</p> <p>With respect to our defined coordinate system above, we are now at (50,30) in (X, Y). This is point 3. Switching to relative to arrive at point 3 was for the sake of example and unnecessary. It is up to you which coordinate system you want to use. You may find one more logical than the other depending on your application.</p> <p>Note: You need to recalibrate your position (G92) after reconnecting to the printer every time. In between running scripts, the printer will remember its absolute location so long as you do not disconnect.</p> <p>Another Example GCode to make a 5x5mm square:</p> <pre>G91; Relative G1 X5 Y0 F300 G1 X0 Y5 F300 G1 X-5 Y0 F300 G1 X0 Y-5 F300</pre> <p>G90; Absolute G92 X0 Y0; Define current location as (0,0) G1 X5 Y0 F300 G1 X5 Y5 F300 G1 X0 Y5 F300 G1 X0 Y0 F300</p>
G1	<p>Move in a straight line.</p> <p>Example (refer to diagram below):</p> <pre>G90; Absolute Positioning G92 X0 Y0 G1 X3 Y1 F300 Note: G1 and G01 are the same. Use G1.</pre>

G2, G3	<p>Clockwise (G2) and counterclockwise (G3) arcs / circles.</p> <p>Example (refer to diagram below):</p> <p>J = Y-offset. -2 from Start I = X-offset. 0 from Start</p>
	<p>G91; Incremental Positioning G2 X2 Y-2 I0 J-2</p> <p>X and Y indicate the point where circle should end (omitting will default to full circle) I and J indicate the midpoint <i>relative</i> to the starting point. (I and J are always read in relative even when you are in absolute positioning).</p> <p>Note: If you specify a point (X, Y) that is not on the circle, then the nearest point on the circle will be selected. Please use ncviewer for practicing these commands to understand how they work.</p>
F	<p>Define speed of motor for X, Y, Z, and A movements (units in mm/min).</p> <p>Use F300 as starting speed. Higher speeds may stall the motors.</p> <p>Include an F command on the first motion line you give to the printer after connecting to Pronterface. The printer will remember this speed until you explicitly change it or disconnect, but it does not hurt to include it on every relevant line as we have done in the examples thus far.</p> <p>Note: This does NOT influence the speed of the extruders. Pronterface will automatically adjust the speed of the B and C axes to move the distance you specify by the time the X, Y, Z, A translations finish.</p>
;	Anything that comes inline after ";" is a comment and ignored by the computer.

Optional Commands

Command	Description
G0	Jog (movement with no extrusion). You do not need this command for our printer as extrusion is controlled explicitly by the extrusion axes. Just omit B or C if you want to move with no extrusion.
G4	Dwell. Wait a certain amount of time before running the next line. Example: G1 X5 G4 P2000 G1 X5 Moves 5mm in X, waits 2 seconds (units after "P" are in milliseconds; Can also use "S" for seconds), then moves 5mm again in X.
G60	Save current Position
G61	Return to saved position Example: G60 G61 XY F300 G60 will save all coordinates of the current position, and this code just moves us to the saved X and Y coordinates: https://marlinfw.org/docs/gcode/G061.html
M114	Get current position in absolute coordinates.
M2	End code. In general, include this at the end of every Gcode script, but it happens to be unnecessary for Pronterface.

We have provided an example G-code file in the repository in the "Python Extrusion Distance Script" folder under the filename "Demo_G-code.txt" that you may use to gain familiarity with the printer.

GCode Visualizer

- <https://ncviewer.com/>
- Copy your Gcode into this program to visualize the paths it will make.
- May not recognize axes names beyond X, Y, and Z, so you might have to edit your code if using other axes that your printer has.

Useful Terminal Commands for Unix Shell (Mac)

- `pwd`: print working directory
 - This lets you see what folder you are in.
- `ls`: list all the contents in your current directory
 - On windows, use `dir` instead of `ls`
- `cd`: change directory (to select a file or enter a new folder within your current folder)
 - i.e. “`cd Desktop`” to go to Desktop if you are currently in your user folder.
- Type “`python pythonScript.py`” without quotations to run a python script. Replace `pythonScript.py` with the name of your python file.
 - Make sure your python script is in the same directory as any files that it needs.
- **Tip:** If you hit tab after typing a few characters, the full item name will automatically populate.

Using Python Script to Calculate Extruder Distances

Extrusion Distance Calculations

We developed a python script (most up-to-date version [here](#)) to calculate the necessary extrusion distance for each line of Gcode. This program is available for use and modification on Github (https://github.com/weiss-jonathan/Printess-Low-Cost-3D-Printer/blob/main/Python%20Extrusion%20Distance%20Script/gcode_translator_08_10_23.py). The program inputs a .txt file of G-code and outputs the file with calculated extrusion distances. It can be run using the terminal or an IDE such as Pycharm. It may be necessary to include a small initial extrusion move to pressurize and syringe prior to printing and a final small reverse extrusion to depressurize after printing. The extrusion calculations rely on the fact that the cylindrical geometric volume that is pushed down in the syringe barrel is equal to that extruded from the nozzle, allowing us to calculate the height, which is the extrusion distance. Extrusion distance can be defined as the distance in millimeters that the stepper motor connected to the syringe plunger moves. Extrusion distance is calculated as follows:

<p>E = extrusion distance</p> <p>k = extrusion coefficient, a user determined scaling factor</p> <p>b_d = syringe barrel diameter</p> <p>n_d = nozzle diameter</p> <p>l = length of path (i.e., G1 X5, l=5)</p>	<p><i>Volume pushed</i> = <i>volume extruded</i></p> $E * \pi * \left(\frac{b_d}{2}\right)^2 = k * l * \pi * \left(\frac{n_d}{2}\right)^2$ $E = \frac{k * l * \left(\frac{n_d}{2}\right)^2}{\left(\frac{b_d}{2}\right)^2}$ $E = \frac{k * l * n_d^2}{b_d^2}$
--	--

The extrusion coefficient value, “k,” may be changed throughout the code by writing an overriding line (K = new coefficient #, k = #, KK = # or kk = #).

In a simpler explanation, the purpose of this program is that we need to calculate the distance that the extruder axis has to push the plunger in order to extrude a filament of desired volume and diameter. Imagine moving the plunger a certain distance downward while X moves by 5mm, and imagine moving the plunger the same distance while X moves by 10mm. In the latter case, the same amount of material is extruded across a farther distance, so by conservation of mass, the filament will be thinner. We have provided a Python script that will calculate what the extruder coordinate (B and C axes) has to be given the X, Y, Z, and/or A coordinates to extrude a filament of desired thickness.

1. Begin by creating a .txt file and name it “gcode.txt”. This name needs to be exact. On a Mac, you can use the applicationTextEdit. Paste this code at the top and alter the positioning system and syringe parameters based on your subsequent GCode:

```
G91  
Z_syringe_diameter = 4.6  
A_syringe_diameter = 4.6  
Z_nozzle_diameter = 0.2  
A_nozzle_diameter = 0.2  
extrusion_coefficient = 1  
[Add your GCode here]
```

Example:

```
G90  
Z_syringe_diameter = 4.6  
A_syringe_diameter = 4.6  
Z_nozzle_diameter = 0.2  
A_nozzle_diameter = 0.2  
extrusion_coefficient = 3  
  
G1 X24.0 Y0.0 F300.0  
G1 Z2 ; NO E  
G1 X0 Y-4 F300 ; NO E  
G1 Z0
```

Important Notes:

- Make sure there is no empty line at the top of the .txt file. The first line must be G90 or G91, depending on whether you are using an absolute or relative coordinate system.
- If you have inline comments, make sure there is a space between before the “;”.
 - ie G1 X5 Y5 ;comment
- If you are troubleshooting and running this script several times, make sure you close the gcode_modified.txt file in between runs to avoid confusion between versions.
- When the **extrusion coefficient** is set to 1, the extruded filament will have the same diameter as your nozzle. Setting it 2 will double the volume. 3 will triple, etc. It is a simple scaling factor for the extrusion axes.

BD Syringe Size	Inner Diameter (mm)
1 mL	4.9
3 mL	8.6
5 mL	12.0
10 mL	14.4

2. Run gcode_translator using your [terminal](#) (see above section for useful commands) or an IDE such as Pycharm

- a. If your .txt file is named something other than “gcode.txt” (it is easier to just rename your .txt file), you can go into the python script and alter line 5 with the file name:

```
file = open("gcode.txt", "r")
```

- b. Run the code, ensuring that your .txt file and the python script are in the same directory.
- c. The translator will output the file with the extrusion distances calculated as a new file called “gcode_modified.txt”
- d. Double check that your code looks good, and now upload this modified file to Pronterface
 - i. We recommend an initial extrusion to pressurize the syringe prior to printing and a final “unextrusion” to depressurize after printing.

For example, right before the coded path in your gcode, include the line:

G1 B0.2 F400

and right after finishing, include the line:

G1 B-0.2 F400

Alter the distance as needed.

Using CURA to Slice 3D Models to GCode

Go to the [Ultimaker Cura Slicer](#) download page.

Download and install the software version corresponding to the user’s operating system. Note: For Mac users, there are two versions available: x64 and ARM64. “x64” is meant for Intel based chips and “ARM64” is for newer macs using the apple silicon chips. The .dmg file is a disk image and the .pkg is an installation package. Choose either one.

Setting Up Printer Configuration Manually:

1. If the program is a new installation, the application may prompt the user to set up a new printer. But if it does not or gets closed by accident, the user can go to Preferences → Printers (left hand menu) → Add New (button top right).
2. Next select “Non Ultimaker printer.”
3. After that, open the drop-down menu “Add a non-networked printer,” scroll down to the “Custom” category, and select the “Custom FFF printer”. The user can change the name of the machine here or do it later.
4. The next screen should be the machine setting page. On this page, the user can enter the size of the build platform as a rectangular 100 mm x 100 mm x 100 mm.
 - a. The origin at center checkbox should be checked and all heated options unchecked since the Printess does not have any heating accessories.
 - b. Under G-code flavor select “Marlin”
 - c. The current setting of the print head is min X: -100, max X: 100, min Y: -100, max Y: 100, and the number of extruders is 1 or 2.
 - d. For now, the “Apply Extruder offsets...” should be unchecked.
5. Delete everything in the Start G-code and End G-Code section. These sections are where the users would write their own start and end g-code to be applied to Cura’s g-code output.
6. Under each extruder tab
 - a. Enter the desired nozzle diameter into the “Nozzle size” field.
 - b. Enter the inner diameter of the syringe into the “Compatible material diameter”
 - c. Apply any offset in the “Nozzle offset (X/Y)” fields. Extruder 1 has a 0 offset. If using a separate syringe for secondary material, Extruder 2’s offset from Extruder 1 needs to be manually measured and entered.
 - d. Enter 0 for the remaining settings

Exporting Printer Configurations:

1. Go to Help → Show Configuration Folder
2. Save the entire folder or folder contents into a separate folder

Importing Printer Configurations:

1. Go to Help → Show Configuration Folder
2. Copy the entire folder into the existing Cura configuration folder.

Adjusting the Print Settings:

1. There are three tabs in the middle: PREPARE, PREVIEW, MONITOR. The user should only be concerned with the PREPARE and PREVIEW.
2. Under PREPARE, there is a button that prompts the user to open a file and 3 drop down menus. The leftmost drop down menu selects the desired Printer configuration. The middle menu is for activating the desired extruder and material. The last menu is the Print Settings.
3. Under Print Settings, select the “show custom” setting button. This gives the user a plethora of customizations for changing the behavior of the g-code output.

4. When hovering over any of the categories, a slider icon  appears on the right, which opens the “setting visibility” menu. Here, the user can access options like line width, extruder retraction distance, and speed. Go through all the options and select the ones you would like to change. It is good to play around with these settings to see what they do to optimize your print. Some useful ones include Wall, Top/Bottom, Infill, and every Print Speed option.
5. In the Print Settings drop down menu, go to the speed category and change all the speeds to 5 mm/sec. Under the Travel category, change the retraction speed to 2 mm/sec. This limits the g-code output to a feed rate of F300. Under Cooling, uncheck the Enable Print Cooling box.
6. When finished, click the blue floppy disk save icon on top. This prompts the user of the changes made and that the settings to be saved under a new name or to overwrite an existing customized setting.
7. To export and import custom Printer Setting profiles, go to Preferences → Configure Cura and in the left-hand side menu select Profiles. Here the user can click the Import button on the top right to import a profile. To export a profile, select the custom profile and under the hamburger button , and select export.

Troubleshooting

I get errors when trying to run the python script

- Try to get rid of all the inline comments from your file before running it (lines that start with a ; should be ok).
- Make sure you have properly named your .txt file.
- If you have G2 or G3 motion, make sure this is in terms of I and J and not R.
- If you suspect there is a Python version issue, try reinstalling python 3. You can also run python scripts by calling “python3” instead of “python”.

- Example: `% python3 gcode_translator_1_27_21.py`

I get errors when uploading .txt files to Pronterface, or the program is not running once uploaded.

- Disconnect and reconnect
- Make sure your file is either a .txt or .gcode. (.rtf files DO NOT work.)

The material coming out of my syringe does not stick to the substrate (glass slide, petri dish, etc.)

- Most likely your syringe is too high off the substrate. Before starting your program, make sure the syringe is ~0.2mm above the surface. You can manually move the syringe down so that it just barely touches the surface, and then move up by ~0.2mm. You may need to adjust this value depending on how much material you are extruding (i.e. higher height for higher extrusion coefficients).

When printing materials on agar gel, the material seems to melt.

- Pluronic will quickly absorb water from the gel and pool, so it will be difficult to make solid structures. Pluronic can be more useful as a medium through which to deliver other molecules of interest to your bacteria. Avoid embedding bacteria in pluronic as it is a detergent and will harm bacteria with prolonged exposure (edge contact is OK). If you must use pluronic and need it to maintain its structure, try using a very high percentage (45%+). This may slow the water absorption process.
- Alginate exhibits a similar behavior but can be avoided by crosslinking with higher concentrations of calcium (try this first) and/or alginate. It is better to embed bacteria in alginate as it doesn't actively harm bacteria.

My extrusion doesn't start at the very beginning of the print, and it leaks after the print is finished or during segments where I don't want extrusion.

- You need to include a pressurization command (i.e. G1 B0.2) whenever starting an extrusion to start the flow of the material out the syringe. You also need to include a depressurization command (i.e. G1 B-0.2) after you are done extruding to stop leaking from happening. You will need to adjust how much to pressurize or depressurize via trial-and-error. B+/-0.2 is a good place to begin.

My syringe runs into the ground or my axes are generally not moving how I want them to when I start a program.

- Double check that your GCode is correct.

- 99% of the time this happens, you are either in absolute positioning (G90) and forgot to zero using G92 before starting or **you used the GUI to manually position the axes, which resets the positioning system to G90**, and forgot to switch it back. 1% of the time this happens, it is because your motor wiring came loose.

When I try to move a motor, it makes a sound but doesn't actually move.

- You are probably trying to run the motor too quickly. Make sure you include an F command at the end of your motion line. We recommend not moving faster than F300.
 - i.e. G1 X10 Y10 F300
- If the bearing is not lubricated well, the table can get stuck. Try running the motor while pushing with your hand to get the table unstuck. If this works, go back to the original spot to see whether the motor gets stuck again. If it appears that that one spot needs lubrication, then add a little of lubricant (SHC-100) to the spot on the bearing where the table was stuck. Use gloves and rub the lubricant around the affected spot with your hand, then discard glove in trash. Run motor back and forth over the spot to further distribute the lubricant.
- If the issue persists, the driver board may not be supplying the motor with enough current to drive the stepper motor and you may need to adjust the potentiometer on the Marlin board connected to that axes.

My board keeps crashing with the rapid yellow flashing light.

- Unplug and replug in the printer. If this keeps happening, check the power supply. If it is rated 36V, that's probably the issue since the RUMBA board is technically only rated up to 35V. Swap with a 12 or 24V 4A power supply.

Alternative Components Assembly

Alternative Base Upgrades

In the table below we provide some suggestions of optional upgrades for the base Printess. Please note that other printer components may require alterations to accommodate these upgrades.


Component	Replaced Original Component	Source of materials	Suggested product model number	Cost	Notes
Anti-backlash lead nut	Attachment for existing stepper motors	Thomson Linear	XCF6X1	\$45.2	Increased precision. Requires adapter to current motors.
NEMA 11 external ball screw linear stepper motor	Nema 11 stepper motor	StepperOnline	11E18S1004BA M5-150RS	\$106.49	Increased precision. We have included assembly instructions below and a 3D-printable file named "ball-nut-adapter" compatible with this motor in "Optional Files" of the repository.
2mm Pitch Motor	Nema 11 stepper motors	Amazon	ASIN: B0D2KXYNRY	\$64	Increased speed
Longer motors for X and Y axes	Nema 11 stepper motors	Amazon	ASIN: B08D3S5T1Z	\$65	Increased print area
Larger Acrylic Sheets	Acrylic Sheets	McMaster	Variable	Variable	Increased print area
Higher torque motors	Nema 11 stepper motors	Amazon	ASIN: B08DKB5G6F	\$73 for 100mm	Improved extrusion of viscous inks
8 axis control board	RUMBA+ board	Amazon	B094Y77FQN BIGTREETECH Octopus	\$54	Increased number of axes
10 axis control board	RUMBA+ board	Amazon	BIGTREETECH BTT Octopus Max EZ	\$90	Increased number of axes
End-stops	Attachment for existing stepper motors	Amazon	ASIN: B07PCN6T6F	\$10.69	Enable homing. Requires additional adapters and modification of Marlin firmware.

Mixing Nozzle


Additional required components for Mixing Nozzle

Component	Quantity	Cost per unit	Total cost	Source of materials	Product/Model number	Notes
127 RPM Mini Econ Gear Motor	1	\$12.99	\$12.99	ServoCity	638394	Can substitute for other motors if desired.
Push-to-connect tube fitting	1	\$3.32	\$3.32	McMaster	51115K546	
20 mm long M3x0.5 mm screw	2	\$0.0818	\$0.1636	McMaster	91292A123	Longer screws are also okay.
8 mm long M3x0.5 mm screw	2	\$0.0545	\$0.109	McMaster	91292A112	
M3x0.5 square nuts	2	\$0.1428	\$0.2856	McMaster	97258A101	
Epoxy	1	\$32.04	\$32.04	McMaster	7370A38	Can use alternative adhesive if desired.


Mixing Nozzle Assembly



Step 1) 3D print the main printhead (a), impeller (b), and motor spacer (c) on a Formlabs 3B+ printer using the BioMed Black resin




Step 2) Cut the push-to-connect tube fitting (McMaster part # 51115K546) at the middle (see cutting plane) and sand the connector until flat




Step 3) Adhere the cut push-to-connect fitting into the center slot of the 3D printed main printhead using epoxy. Allow it to cure following the epoxy manual



Step 4) Press fit the printed impeller onto the D bore shaft of the motor (ServoCity SKU # 638394)




Step 5) Screw motor/impeller assembly onto the 3D printed motor spacer using two M3x0.5mm 8mm long screws




Step 7) Screw the assembled motor holder onto the 3D printed extruder using two M3x0.5 mm 20 mm long screws

Step 6) On both sides, slide square nuts into the 3D printed extruder



Step 8) Attach desired syringes



Step 9) Attach desired nozzle tip


Step 10) Connect the DC motor to the fan 0 pin on the Rumba board. Speed can be modulated using the Marlin fan command M106 P0 S[speed], where speed is the duty cycle, which is out of 256 (i.e. S256 would be 100%), and M107 [off].

Syringe Cooler Assembly

Additional required components for the syringe cooler:

Component	Quantity	Cost per unit	Total cost	Source of materials	Product/Model number
Peristaltic Pump	1	\$28.88	\$28.88	Amazon	B098RWZ4SV


Note: This cooling sleeve and disks are printed using a stereolithography printer.



Tissue Culture Cooling Plate Assembly

Additional required components for cooling plate:


Component	Quantity	Cost per unit	Total cost	Source of materials	Product/Model number
Aluminum Water Cooling Block	1	\$9.50	\$9.50	Amazon	757233296242
Peristaltic Pump (comes with 3 mm tubing)	1	\$28.88	\$28.88	Amazon	B098RWZ4SV
7 mm ID Tubing	1	\$9.99	\$9.99	Amazon	B08Z38ST3V
Barbed Reducer	2	\$1.40	\$2.80	McMaster	5463K628



This cooling apparatus pumps chilled DI water from a plastic or glass jar that has two 1/8" inch trough bulkhead barbs attached and the pump is any peristaltic pump that can handle 4mm tubing with 3mm ID. The chilled water first goes through the syringe cooler, then to the aluminum blocks of the plate cooler and returns the DI water to the reservoir.

Step 1) Attach the print platform to the carriage of the x-axis of the printessa using the M3 x 12mm screw

Step 2) Place cooling blocks on the print platform and secure using the 4 set screws on the side. The screws are metallic silver.



Cooling Setup


Step 3) Slip the BD 1mL syringe into cooling sleeve and place an 8mm O-ring or 8mm hose clamp on the luer lock side of syringe to hold up the cooling sleeve.

Optional: Add a "tiny" bit of thermal grease on the syringe to improve contact to the cooling sleeve

Step 4) Insert the syringe into the barrel holder and plunger the plunger holder.

Step 5) Connect the outer barb of one cooling block to the outer barb of the second block using one of the 7mm ID x 145mm tubes.

Step 6) Attach one 7mm ID x 145mm tube to one of the inner barbs. Attach the last 7mm ID x 145mm tube to the last remaining barb. Attach 8mm to 4mm reducer to the open ends of both tubes. One tube is going to be the inlet and the other is outlet for this set of cooling blocks.




Step 8) Connect the outlet of the cooling sleeve to the inlet of the cooling block using 3mm ID x 500mm tube.

Step 7) Connect the outlet tube/barb of the peristaltic pump to the bottom inlet barb of the cooling sleeve using the 3mm ID x 250mm tube.

Step 9) Connect the outlet of the cooling block set to the inlet of the jar using 3mm ID x 500mm tube.



Step 10) Finally finish the loop by connecting the outlet of the jar to inlet barb of the peristaltic pump using the 3mm ID x 1000mm tube




Tip-Tilt Bed Leveling Platform Assembly

Additional required components for tip-tilt platform:


Component	Quantity	Cost per unit	Total cost	Source of materials	Product/Model number
Countersunk washer	2	\$3.72	\$7.44	McMaster	92538A461
10 mm stainless steel ball	1	\$1.443	\$1.443	McMaster	1598K32
Extension spring	2	\$3.298	\$6.596	McMaster	9433K196
2.5x12mm dowel pin	4	\$0.2034	\$0.8136	McMaster	91585A293
3x20mm dowel pin	2	\$0.3512	\$0.7024	McMaster	91585A390
M3x0.5mm heat set insert	2	\$0.2876	\$0.5752	McMaster	97171A310
1/4"-80 fine-thread insert	2	\$9	\$18	McMaster	98625A950
1/4"-80 fine-thread thumb screw	2	\$8.92	\$17.84	McMaster	97424A560
Epoxy	1	\$24.91	\$24.91	McMaster	7467A21





Step 8) Insert 2x springs through holes and lock in place by inserting dowel pins through the springs loop ends

Step 9) Repeat step 8 on the opposite side, and make sure that the spring is properly attached on both sides




Step 12) Insert 2x screws to adjust platform to preferred tip and tilt

Step 11) Insert stainless steel ball between the countersunk washers


Ball-Screw Carriage for Reduced Backlash

Additional required components for ball-screw carriage


Component	Quantity (per motor)	Cost per unit	Total cost	Source of materials	Product/ Model number
NEMA 11 external ball screw linear stepper motor	1	\$106.49	\$106.49	StepperOnline	11E18S1004BA M5-150RS
Heat set inserts	6	\$0.44	\$2.64	McMaster	97163A149
6 mm M3 round head screws	2	\$0.06	\$0.12	McMaster	92095A179



Step 1) 3D print ball screw carriage




Step 2) Heat set insert the threaded stainless steel inserts




Step 3) Attach ball nut to ball 3D printed carriage


NB! When removing the ball nut from the ball screws, screw the ball nut onto a 6 mm OD rod to prevent balls from falling out




Step 4) Unscrew motor attachment plate, ball bearing attachment plate, and lead screw carriage



Step 5) Unscrew motor and remove the lead screw to release the motor attachment block



Step 6) Attach ball screw motor to the motor attachment block. For shorter linear actuators, the ball screw can be cut to the desired length using appropriate cutting tools.



Step 7) Screw the assembled ball nut and carriage onto the ball screw and reverse the steps in step 4 to assemble everything