





Notes:

- · All wires should be in the range of 12-26 AWG.
- · The ACR9000 requires a 5-24 VDC Enable input.
- · The Aries e-brake (BK) requires a 24 VDC supply.

RF-DFS Wiring Diagram