

H50.11:LD Status									
MOTOR STATUS									
0	Unit1	==	[WLFQD]SrcA OWAD08 LDTRY1~Motion command	[WLFQD]SrcB 00000	==	[WLFQD]SrcA OWAD88 ---	[WLFQD]SrcB 00000	MB040698	[MB040698] .../0015
								Axis No Command	
1	3/9	==	[WLFQD]SrcA OWAE08 ---	[WLFQD]SrcB 00000				MB040699	[MB040699] .../0016
								Axis No Command	
2	5/12	==	[WLFQD]SrcA OWAF08 SBTT~Motion command	[WLFQD]SrcB 00000				MB04069A	[MB04069A] .../0017
								Axis No Command	
3	7/15		MB040698	MB040699	MB04069A			MB04069D	
			Axis No Command	Axis No Command	Axis No Command			ALL Axis No Command	
Loader Transfer Vacuum Status									
4	11/18		MB041840	MB041841				MB041888	[MB041888] H50.41/1395
			Unit1 Vacuum 1 On (Sensor)	Unit1 Vacuum 2 On (Sensor)				Unit1 Sol 9 On (Sensor)	
5	14/22		MB041850	MB041851				MB041898	
			Unit1 Vacuum 1 Off (Sensor)	Unit1 Vacuum 2 Off (Sensor)				Unit1 Sol 9 Off (Sensor)	
Loader Table Blower Status									
6	17/29		MB041860	MB041861	MB041862	MB041863		MB04188C	
			Unit1 Blow 1 On (Sensor)	Unit1 Blow 2 On (Sensor)	Unit1 Blow 3 On (Sensor)	Unit1 Blow 4 On (Sensor)		Unit1 Sol 13 On (Sensor)	
7	20/31		MB041870	MB041871	MB041872	MB041873		MB04189C	
			Unit1 Blow 1 Off (Sensor)	Unit1 Blow 2 Off (Sensor)	Unit1 Blow 3 Off (Sensor)	Unit1 Blow 4 Off (Sensor)		Unit1 Sol 13 Off (Sensor)	
Loader TR Blower Status									
8	27/35		MB041864	MB041865				MB04188D	
			Unit1 Blow 5 On (Sensor)	Unit1 Blow 6 On (Sensor)				Unit1 Sol 14 On (Sensor)	
9	30/38		MB041874	MB041875				MB04189D	
			Unit1 Blow 5 Off (Sensor)	Unit1 Blow 6 Off (Sensor)				Unit1 Sol 14 Off (Sensor)	
Loader Align All Standby Pos									
10	33/41		MB041820	MB041821	MB041822	MB041823		MB040740	
			Unit1 Cylinder 1 Backward (Sensor)	Unit1 Cylinder 2 Backward (Sensor)	Unit1 Cylinder 3 Backward (Sensor)	Unit1 Cylinder 4 Backward (Sensor)		---	
Loader Align FWD Pos									
11	36/46		MB041800	MB041801	MB041802	MB041803		MB040742	
			Unit1 Cylinder 1 Forward (Sensor)	Unit1 Cylinder 2 Forward (Sensor)	Unit1 Cylinder 3 Forward (Sensor)	Unit1 Cylinder 4 Forward (Sensor)		---	
Loader Transfer All Standby Pos									
12	43/51		MB041100	MB041120	MB041140			MB040748	
			Axis11 Target Position Moving Command MB041101	Axis13 Target Position Moving Command	Axis15 Target Position Moving Command MB041142			---	
			Axis11 Target Position Moving Command		Axis15 Target Position Moving Command MB041143				
					Axis15 Target Position Moving Command				
Loader Transfer All Turn Possible Pos									
13	50/58		MB041101	MB041120				MB040749	
			Axis11 Target Position Moving Command	Axis13 Target Position Moving Command				---	
Loader Transfer All Carry In Pos									
14	53/61		MB041102	MB041122	MB041142			MB04074A	
			Axis11 Target Position Moving Command	Axis13 Target Position Moving Command	Axis15 Target Position Moving Command			---	

H50.41/1395

Loader Transfer All Carry Out Pos									
15	MB041103	MB041123	MB041143					MB04074C	
57/65	Axis11 Target Position Moving Com-	Axis13 Target Position Moving Com-	Axis15 Target Position Moving Com-					---	
Loader Transfer Vacuum Signal									
16	MB040888							MB040840	[MB040840]
61/69	---							Unit1 Vacuum 1 On (Sol)	.../0097w L10.51/0011iw L20.41/0001
								MB040841	[MB040841]
								Unit1 Vacuum 2 On (Sol)	.../0098w [MB040842]
								MB040842	.../0099w [MB040843]
								Unit1 Vacuum 3 On (Sol)	.../0100w [MB040844]
								MB040843	.../0101w [MB040845]
								Unit1 Vacuum 4 On (Sol)	.../0102w [MB040846]
								MB040844	.../0103w [MB040847]
								Unit1 Vacuum 5 On (Sol)	.../0104w [MB040888]
								MB040845	.../0069 [MB040850]
								Unit1 Vacuum 6 On (Sol)	.../0088w L10.51/0009i L20.41/0005
								MB040846	[MB040851]
								Unit1 Vacuum 7 On (Sol)	.../0089w [MB040852]
								MB040847	.../0090w [MB040853]
								Unit1 Vacuum 8 On (Sol)	.../0091w [MB040854]
								MB040888	.../0092w [MB040855]
								---	.../0093w [MB040856]
								MB040850	.../0094w [MB040857]
								Unit1 Vacuum 1 Off (Sol)	.../0095w H50.41/0720 L10.61/0156i
								MB040851	L10.61/0201i
								Unit1 Vacuum 2 Off (Sol)	H50.41/0731 L20.41/0009
								MB040852	H50.41/0742 L20.41/0017
								Unit1 Vacuum 3 Off (Sol)	H50.41/0753 L20.41/0025
								MB040853	H50.41/0764 L20.41/0033
								Unit1 Vacuum 4 Off (Sol)	H50.41/0775 L20.41/0041
								MB040854	H50.41/0786 L20.41/0049
								Unit1 Vacuum 5 Off (Sol)	H50.41/0797 L20.41/0057
								MB040855	H50.41/0896 L10.61/0158i
								Unit1 Vacuum 6 Off (Sol)	L10.51/0008iw L10.61/0199i
								MB040856	H50.41/0907 L20.41/0013
								Unit1 Vacuum 7 Off (Sol)	H50.41/0918 L20.41/0021
								MB040857	H50.41/0929 L20.41/0029
								Unit1 Vacuum 8 Off (Sol)	H50.41/0940 L20.41/0037
									H50.41/0951 L20.41/0045
									H50.41/0962 L20.41/0053
									H50.41/0973 L20.41/0061

17 79/87	MB040898						MB040850	[MB040850] .../0079w	H50.41/0896	L10.51/0008w
							Unit1 Vacuu m 1 Off (Sol)	L10.51/0009i L20.41/0005	L10.61/0158i	L10.61/0199i
							MB040851	[MB040851] .../0080w	H50.41/0907	L20.41/0013
							Unit1 Vacuu m 2 Off (Sol)	[MB040852] .../0081w	H50.41/0918	L20.41/0021
							MB040852	[MB040853] .../0082w	H50.41/0929	L20.41/0029
							Unit1 Vacuu m 3 Off (Sol)	[MB040854] .../0083w	H50.41/0940	L20.41/0037
							MB040853	[MB040855] .../0084w	H50.41/0951	L20.41/0045
							Unit1 Vacuu m 4 Off (Sol)	[MB040856] .../0085w	H50.41/0962	L20.41/0053
							MB040854	[MB040857] .../0086w	H50.41/0973	L20.41/0061
							Unit1 Vacuu m 5 Off (Sol)	[MB040898] .../0087		
							MB040855	[MB040840] .../0070w	H50.41/0720	L10.51/0006i
							Unit1 Vacuu m 6 Off (Sol)	L10.51/0011iw L20.41/0001	L10.61/0156i	L10.61/0201i
							MB040856	[MB040841] .../0071w	H50.41/0731	L20.41/0009
							Unit1 Vacuu m 7 Off (Sol)	[MB040842] .../0072w	H50.41/0742	L20.41/0017
							MB040857	[MB040843] .../0073w	H50.41/0753	L20.41/0025
							Unit1 Vacuu m 8 Off (Sol)	[MB040844] .../0074w	H50.41/0764	L20.41/0033
							MB040898	[MB040845] .../0075w	H50.41/0775	L20.41/0041
							Unit1 Vacuu m 1 On (Sol)	[MB040846] .../0076w	H50.41/0786	L20.41/0049
							MB040840	[MB040847] .../0077w	H50.41/0797	L20.41/0057
							Unit1 Vacuu m 2 On (Sol)			
							MB040841			
							Unit1 Vacuu m 3 On (Sol)			
							MB040842			
							Unit1 Vacuu m 4 On (Sol)			
							MB040843			
							Unit1 Vacuu m 5 On (Sol)			
							MB040844			
							Unit1 Vacuu m 6 On (Sol)			
							MB040845			
							Unit1 Vacuu m 7 On (Sol)			
							MB040846			
							Unit1 Vacuu m 8 On (Sol)			
							MB040847			
Loader Transfer Vacuum Break Signal										
18 97/109	MB04088D						MB040864	[MB040864] .../0114w	H50.41/1112	L20.41/0289
							Unit1 Blow 5 On (Sol)	[MB040865] .../0115w	H50.41/1122	L20.41/0297
							MB040865	[MB040874] .../0112w	H50.41/1272	L20.41/0293
							Unit1 Blow 6 On (Sol)	[MB040875] .../0113w	H50.41/1282	L20.41/0301
							MB040874	[MB04088D] .../0105		
							Unit1 Blow 5 Off (Sol)			
							MB040875			
							Unit1 Blow 6 Off (Sol)			
							MB04088D			

				H50.11 : Mode Status_Unit1 (SP)					P00003	

