

L80.25:Sol BTN Interlock_Unit5					
ManualEnable(PTP)					
Manual Interlock(PTP) (78,0)					
0	MB000081			MB884960	[MB884960] L20.55/0384
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,1)					
1	MB000081			MB884970	[MB884970] L20.55/0386
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,2)					
2	MB000081			MB884980	[MB884980] L20.55/0388
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,3)					
3	MB000081			MB884990	[MB884990] L20.55/0390
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,4)					
4	MB000081			MB885000	[MB885000] L20.55/0392
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,5)					
5	MB000081			MB885010	[MB885010] L20.55/0394
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,6)					
6	MB000081			MB885020	[MB885020] L20.55/0396
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,7)					
7	MB000081			MB885030	[MB885030] L20.55/0398
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,8)					
8	MB000081			MB885040	[MB885040] L20.55/0400
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,9)					
9	MB000081			MB885050	[MB885050] L20.55/0402
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,10)					
10	MB000081			MB885060	[MB885060] L20.55/0404
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,11)					
11	MB000081			MB885070	[MB885070] L20.55/0406
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,12)					
12	MB000081			MB885080	[MB885080] L20.55/0408
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,13)					
13	MB000081			MB885090	[MB885090] L20.55/0410
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,14)					
14	MB000081			MB885100	[MB885100] L20.55/0412
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,15)					
15	MB000081			MB885110	[MB885110] L20.55/0414
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,16)					
16	MB000081			MB885120	[MB885120] L20.55/0416
	Manual comm on IL(PTP)			---	
17	MB045741			MB885121	
	All Cutter X Wa it Position			---	
Manual Interlock(PTP) (78,17)					
18	MB000081			MB885130	[MB885130] L20.55/0418
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,18)					
19	MB000081			MB885140	[MB885140] L20.55/0420
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,19)					
20	MB000081			MB885150	[MB885150] L20.55/0422
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,20)					
21	MB000081			MB885160	[MB885160] L20.55/0424
	Manual comm on IL(PTP)			---	
Manual Interlock(PTP) (78,21)					
22	MB000081			MB885170	[MB885170] L20.55/0426

Manual Interlock(PTP) (78,22)					
23	MB000081				MB885180
46/46	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,23)					
24	MB000081				MB885190
48/48	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,24)					
25	MB000081				MB885200
50/50	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,25)					
26	MB000081				MB885210
52/52	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,26)					
27	MB000081				MB885220
54/54	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,27)					
28	MB000081				MB885230
56/56	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,28)					
29	MB000081				MB885240
58/58	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,29)					
30	MB000081				MB885250
60/60	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,30)					
31	MB000081				MB885260
62/62	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (78,31)					
32	MB000081				MB885270
64/64	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,0)					
33	MB000081				MB885280
66/66	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,1)					
34	MB000081				MB885290
68/68	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,2)					
35	MB000081				MB885300
70/70	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,3)					
36	MB000081				MB885310
72/72	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,4)					
37	MB000081				MB885320
74/74	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,5)					
38	MB000081				MB885330
76/76	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,6)					
39	MB000081				MB885340
78/78	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,7)					
40	MB000081				MB885350
80/80	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,8)					
41	MB000081				MB885360
82/82	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,9)					
42	MB000081				MB885370
84/84	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,10)					
43	MB000081				MB885380
86/86	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,11)					
44	MB000081				MB885390
88/88	Manual comm on IL(PTP)				---
Manual Interlock(PTP) (79,12)					
45	MB000081				MB885400
90/90	Manual comm on IL(PTP)				---

Manual Interlock(PTP) (79,13)						
46	MB000081					MB885410
92/92	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,14)						
47	MB000081					MB885420
93/94	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,15)						
48	MB000081					MB885430
95/95	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,16)						
49	MB000081					MB885440
96/96	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,17)						
50	MB000081					MB885450
100/100	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,18)						
51	MB000081					MB885460
102/102	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,19)						
52	MB000081					MB885470
104/104	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,20)						
53	MB000081					MB885480
105/105	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,21)						
54	MB000081					MB885490
108/108	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,22)						
55	MB000081					MB885500
110/110	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,23)						
56	MB000081					MB885510
112/112	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,24)						
57	MB000081					MB885520
114/114	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,25)						
58	MB000081					MB885530
116/116	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,26)						
59	MB000081					MB885540
118/118	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,27)						
60	MB000081					MB885550
120/120	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,28)						
61	MB000081					MB885560
122/122	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,29)						
62	MB000081					MB885570
124/124	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,30)						
63	MB000081					MB885580
126/126	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (79,31)						
64	MB000081					MB885590
128/128	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (80,0)						
65	MB000081					MB885600
130/130	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (80,1)						
66	MB000081					MB885610
132/132	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (80,2)						
67	MB000081					MB885620
134/134	Manual comm on IL(PTP)					---
Manual Interlock(PTP) (80,3)						
68	MB000081					MB885630
136/136	Manual comm on IL(PTP)					---

[MB885410]
L20.55/0474

[MB885420]
L20.55/0476

[MB885430]
L20.55/0478

[MB885440]
L20.55/0480

[MB885450]
L20.55/0482

[MB885460]
L20.55/0484

[MB885470]
L20.55/0486

[MB885480]
L20.55/0488

[MB885490]
L20.55/0490

[MB885500]
L20.55/0492

[MB885510]
L20.55/0494

[MB885520]
L20.55/0496

[MB885530]
L20.55/0498

[MB885540]
L20.55/0500

[MB885550]
L20.55/0502

[MB885560]
L20.55/0504

[MB885570]
L20.55/0506

[MB885580]
L20.55/0508

[MB885590]
L20.55/0510

[MB885600]
L20.55/0512

[MB885610]
L20.55/0514

[MB885620]
L20.55/0516

[MB885630]
L20.55/0518

Manual Interlock(PTP) (80,4)									
69	MB000081							MB885640	[MB885640] L20.55/0520
138/138	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,5)									
70	MB000081							MB885650	[MB885650] L20.55/0522
140/140	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,6)									
71	MB000081							MB885660	[MB885660] L20.55/0524
142/142	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,7)									
72	MB000081							MB885670	[MB885670] L20.55/0526
144/144	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,8)									
73	MB000081							MB885680	[MB885680] L20.55/0528
146/146	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,9)									
74	MB000081							MB885690	[MB885690] L20.55/0530
148/148	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,10)									
75	MB000081							MB885700	[MB885700] L20.55/0532
150/150	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,11)									
76	MB000081							MB885710	[MB885710] L20.55/0534
152/152	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,12)									
77	MB000081							MB885720	[MB885720] L20.55/0536
154/154	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,13)									
78	MB000081							MB885730	[MB885730] L20.55/0538
156/156	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,14)									
79	MB000081							MB885740	[MB885740] L20.55/0540
158/158	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,15)									
80	MB000081							MB885750	[MB885750] L20.55/0542
160/160	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,16)									
81	MB000081							MB885760	[MB885760] L20.55/0544
162/162	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,17)									
82	MB000081							MB885770	[MB885770] L20.55/0546
164/164	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,18)									
83	MB000081							MB885780	[MB885780] L20.55/0548
166/166	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,19)									
84	MB000081							MB885790	[MB885790] L20.55/0550
168/168	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,20)									
85	MB000081							MB885800	[MB885800] L20.55/0552
170/170	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,21)									
86	MB000081							MB885810	[MB885810] L20.55/0554
172/172	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,22)									
87	MB000081							MB885820	[MB885820] L20.55/0556
174/174	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,23)									
88	MB000081							MB885830	[MB885830] L20.55/0558
176/176	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,24)									
89	MB000081							MB885840	[MB885840] L20.55/0560
178/178	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,25)									
90	MB000081							MB885850	[MB885850] L20.55/0562
180/180	Manual comm on IL(PTP)							---	
Manual Interlock(PTP) (80,26)									
91	MB000081							MB885860	[MB885860] L20.55/0564
182/182	Manual comm on IL(PTP)							---	

		Manual Interlock(PTP) (80.27)							
92	184/184	MB000081						MB885870	[MB885870] L20.55/0566
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (80.28)							
93	186/186	MB000081						MB885880	[MB885880] L20.55/0568
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (80.29)							
94	188/188	MB000081						MB885890	[MB885890] L20.55/0570
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (80.30)							
95	190/190	MB000081						MB885900	[MB885900] L20.55/0572
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (80.31)							
96	192/192	MB000081						MB885910	[MB885910] L20.55/0574
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.0)							
97	194/194	MB000081						MB885920	[MB885920] L20.55/0576
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.1)							
98	196/196	MB000081						MB885930	[MB885930] L20.55/0578
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.2)							
99	198/198	MB000081						MB885940	[MB885940] L20.55/0580
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.3)							
100	200/200	MB000081						MB885950	[MB885950] L20.55/0582
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.4)							
101	202/202	MB000081						MB885960	[MB885960] L20.55/0584
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.5)							
102	204/204	MB000081						MB885970	[MB885970] L20.55/0586
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.6)							
103	206/206	MB000081						MB885980	[MB885980] L20.55/0588
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.7)							
104	208/208	MB000081						MB885990	[MB885990] L20.55/0590
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.8)							
105	210/210	MB000081						MB886000	[MB886000] L20.55/0592
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.9)							
106	212/212	MB000081						MB886010	[MB886010] L20.55/0594
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.10)							
107	214/214	MB000081						MB886020	[MB886020] L20.55/0596
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.11)							
108	216/216	MB000081						MB886030	[MB886030] L20.55/0598
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.12)							
109	218/218	MB000081						MB886040	[MB886040] L20.55/0600
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.13)							
110	220/220	MB000081						MB886050	[MB886050] L20.55/0602
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.14)							
111	222/222	MB000081						MB886060	[MB886060] L20.55/0604
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.15)							
112	224/224	MB000081						MB886070	[MB886070] L20.55/0606
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.16)							
113	226/226	MB000081						MB886080	[MB886080] L20.55/0608
		Manual comm on IL(PTP)						---	
		Manual Interlock(PTP) (81.17)							
114	228/228	MB000081						MB886090	[MB886090] L20.55/0610
		Manual comm on IL(PTP)						---	

