

TechMart Electronics — Comprehensive User Manual & Troubleshooting Reference

Official Corporate Policy & Reference Documentation | Doc ID: TM-UM-FULL-2026

1. SmartHub Pro LED Status Light Meanings

The multi-color front LED indicator conveys the operational status of your SmartHub Pro gateway.

LED Color & Pattern	System Status	Recommended Action
Solid Blue	Normal Operation	All systems connected and running smoothly.
Pulsing Amber	Setup / Pairing Mode	Open TechMart App to complete Wi-Fi setup.
Blinking Red (Fast)	Network Disconnected	Check router Wi-Fi signal or Ethernet connection.
Solid Red	Hardware Fault / Overheat	Power cycle device; allow 10 min to cool down.
Pulsing Purple	Firmware Updating (OTA)	Do NOT disconnect power during update.
Blinking White	Bluetooth Pairing Mode	Open TechMart App and tap 'Add New Device'.
Off (No Light)	Device Powered Off / No Power	Check power adapter connection and outlet.

2. Common Error Codes & Troubleshooting Steps

Error Code	Error Name & Cause	Resolution Steps
E-101	Authentication Failure Cause: Cloud account credentials mismatch.	Re-enter your TechMart account password in the mobile app Settings > Account.
E-204	Zigbee Signal Weak Cause: Sensor too far from SmartHub.	Move sensor within 10m of SmartHub or add a TechMart SmartPlug as a mesh repeater.
E-305	HDMI Handshake Error (VisionStream) Cause: HDCP version mismatch.	Verify TV HDMI port supports HDCP 2.2/2.3. Replace HDMI cable. Try a different port.
E-409	Bluetooth Audio Stutter (SoundWave) Cause: Bluetooth congestion or stale pairing.	Hold Bluetooth + Volume Down for 7 sec to clear paired list, then re-pair device.
E-512	SD Card Write Failure Cause: SD card full or corrupted.	Format SD card (FAT32, max 256GB) in Settings > Storage > Format Card.
E-615	Firmware Update Failed Cause: Interrupted OTA update.	Do not unplug during update. If stuck, hold reset button 15 sec to force re-download.

3. Factory Reset Procedures

If experiencing persistent operational anomalies, a factory reset returns the hardware to out-of-the-box defaults. All local settings, paired devices, and stored Wi-Fi credentials will be erased.

Device	Factory Reset Method	Duration & Notes
SmartHub Pro	Hold recessed RESET button (pin) for 15 seconds until LED flashes red 3 times.	~90 sec. All paired devices must be re-added in TechMart App.
SoundWave 500	Hold Volume Up + Power simultaneously for 10 seconds.	~30 sec. All Bluetooth pairings cleared. Wi-Fi config remains if assigned via app.

VisionStream 4K	Settings > System > Factory Reset in the on-screen menu.	~2 min. Google/Amazon account must be re-signed in after reset.
SmartSensor Trio	Hold tamper button on back for 5 seconds until LED flashes rapidly.	~10 sec. Re-add sensor to SmartHub Pro after reset.

4. Firmware Updates & App Requirements

All TechMart devices receive automatic Over-The-Air (OTA) firmware updates when connected to Wi-Fi. Updates are released on the second Tuesday of each month.

Device	Current Firmware Version	Minimum App Version	Auto-Update
SmartHub Pro	v4.7.2 (2026-07)	TechMart App v3.2+	Yes
SoundWave 500	v2.3.1 (2026-06)	TechMart App v3.0+	Yes
VisionStream 4K	v6.1.0 (2026-07)	Android 10+ / iOS 15+	Yes
SmartSensor Trio	v1.9.4 (2026-05)	TechMart App v2.8+	Yes (via SmartHub)
PowerPulse 65W	N/A (no firmware)	N/A	N/A

5. Technical Support Channels & Contact Info

Channel	Availability	Contact / Reference
Live Chat	Mon - Fri, 9 AM - 6 PM EST	techmart.com/support
Email Support	24/7 (response within 24h)	support@techmart.com
Phone Support	Mon - Fri, 9 AM - 6 PM EST	1-800-TECHMART
Community Forum	24/7	community.techmart.com
Warranty Claims	Mon - Fri, 9 AM - 5 PM EST	warranty@techmart.com