

- [4.1.17 mtu \(Interface view\)](#)
- [4.1.18 port description](#)
- [4.1.19 reset counters if-mib interface](#)
- [4.1.20 reset counters interface](#)
- [4.1.21 reset counters top interface](#)
- [4.1.22 restart \(interface view\)](#)
- [4.1.23 set flow-stat interval](#)
- [4.1.24 shutdown \(interface view\)](#)

4.1.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

4.1.2 collect counters top

Function

The **collect counters top** command sets the parameters for top N interface traffic statistics and enables the function to generate top N interface traffic statistics reports.

Format

collect counters top [*number*] **interface** { *interface-type* | **all** | **layer-2** | **layer-3** } [**sort-by** *statistics-type* | **interval** *interval-value*] *

Parameters

Parameter	Description	Value
<i>number</i>	Specifies the number of busiest interfaces for which traffic statistics reports are to be generated. For example, if the value is 10, a traffic statistics report about top 10 busiest interfaces is generated. If you do not specify this parameter, a traffic statistics report about top 20 busiest interfaces is generated.	The value is an integer ranging from 1 to 50000.

Parameter	Description	Value
interface { <i>interface-type</i> all layer-2 layer-3 }	Specifies the type of the interfaces for which a top N traffic statistics report is to be generated: • <i>interface-type</i>: indicates a specific type of interface. • all: indicates all interfaces. • layer-2: indicates Layer 2 interfaces. • layer-3: indicates Layer 3 interfaces.	The specified interfaces must be Ethernet physical interfaces or Eth-Trunk interfaces.
sort-by <i>statistics-type</i>	Specifies the statistics type by which ports are determined to be the busiest. If you do not specify sort-by statistics-type , statistics are sorted by the total number of bytes in descending order.	The value can be: • utilization: indicates to sort statistics by bandwidth utilization. • bytes: indicates to sort statistics by the total number of bytes. • packets: indicates to sort statistics by the total number of packets. • multicast: indicates to sort statistics by the total number of multicast packets. • broadcast: indicates to sort statistics by the total number of broadcast packets. • errors: indicates to sort statistics by the total number of error packets. • discards: indicates to sort statistics by the total number of dropped packets.
interval <i>interval-value</i>	Specifies the interval at which statistics are collected.	The value is an integer ranging from 1 to 999, in seconds. The default value is 30.

Views

All views

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The display command allows you to view statistics about the traffic sent and received by each interface on a device, but cannot sort these statistics by traffic volume in descending order. The **display counters top interface** command allows you to view top N interface traffic statistics reports, facilitating interface monitoring. Before you view a top N interface traffic statistics report, run the **collect counters top** command to generate your desired top N interface traffic statistics report. For example, configure the device to generate a top N statistics report about packets dropped on Layer 2 interfaces within 50s.

The top N interface traffic statistics function sorts statistics about inbound and outbound traffic processed by interfaces within a collection interval in descending order and generates a top N interface traffic statistics report. The device stops collecting interface traffic statistics after the collection interval ends. To generate another top N interface traffic statistics report, run the **collect counters top** command again.

Configuration Impact

- After the **collect counters top** command is run, the device collects interface traffic statistics and generates a top N interface traffic statistics report based on the set parameters.
- The **collect counters top** command configuration is not saved in the configuration file.

Follow-up Procedure

To view a top N interface traffic statistics report, run the **display counters top interface** command.

Precautions

- When the master switch in a stack containing multiple member switches is faulty, the top N interface traffic statistics function takes effect only on a master switch. If the master switch encounters a fault and switches to the backup state, run the **collect counters top** command on the new master switch again.
- The **collect counters top** command can be run multiple times in succession with different parameters specified. For example, you can configure a device to generate a top N statistics report about interface multicast packets when the device is still generating a top N statistics report about interface broadcast packets.
- The top N interface traffic statistics function allows a device to generate a maximum of five top N interface traffic statistics reports. If you want the device to generate new top N interface traffic statistics reports when five top N interface traffic statistics reports already exist, run the **reset counters top interface** command to clear existing ones.

Example

```
# Configure a device to generate a statistics report about top 10 Layer 2 interfaces  
in terms of the number of packets dropped within 40s.
```

<HUAWEI> collect counters top 10 interface layer-2 sort-by discards interval 40

Related Topics

[4.1.9 display counters top interface](#)

[4.1.21 reset counters top interface](#)

4.1.3 bandwidth (Interface view)

Function

The **bandwidth** command sets the interface bandwidth obtained by the NMS from the MIB.

The **undo bandwidth** command restores the default configuration.

By default, the interface bandwidth obtained by the NMS from the MIB depends on the interface type. For example, the bandwidth of a GE interface is 1000 Mbit/s.

NOTE

Only the S2750EI, S5720EI, S5720HI, S6720EI and S6720S-EI support this command.

Format

bandwidth *bandwidth*

undo bandwidth

Parameters

Parameter	Description	Value
<i>bandwidth</i>	Specifies the bandwidth of an interface.	The value is an integer ranging from 1 to 10000000, and the unit is Mbit/s.

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Tunnel interface view, Eth-Trunk interface view, VLANIF interface view, VE interface view, VE sub-interface view

Default Level

2: Configuration level

Usage Guidelines

Running the **bandwidth** command sets an interface bandwidth obtained by the NMS from the MIB and does not change an interface actual bandwidth. The NMS can check the interface bandwidth through the two objects **ifSpeed** and **ifHighSpeed** in IF-MIB.

- If the configured bandwidth is smaller than 4000 Mbit/s, **ifSpeed** and **ifHighSpeed** are respectively displayed as *bandwidth* x 1000 x 1000 and *bandwidth*.
- If the configured bandwidth is equal to or larger than 4000 Mbit/s, **ifSpeed** and **ifHighSpeed** are respectively displayed as 4294967295 (0xFFFFFFFF) and *bandwidth*.

Example

Set the bandwidth of GE0/0/1 to 100 Mbit/s.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet0/0/1
[HUAWEI-gigabitethernet0/0/1] bandwidth 100
```

4.1.4 description (interface view)

Function

The **description** command configures the description for an interface.

The **undo description** command restores the default description of an interface.

By default, the description of an interface is null.

Format

description *description*
undo description

Parameters

Parameter	Description	Value
<i>description</i>	Specifies the interface description.	The value is a string of 1 to 242 characters. The character string is case sensitive. It can contain blanks but cannot contain the question mark (?).

Views

Interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario