

- [8.2.31 mld static-group](#)
- [8.2.32 mld timer other-querier-present](#)
- [8.2.33 mld timer query](#)
- [8.2.34 mld ttl-check](#)
- [8.2.35 mld version](#)
- [8.2.36 require-router-alert \(MLD view\)](#)
- [8.2.37 reset mld control-message counters](#)
- [8.2.38 reset mld explicit-tracking](#)
- [8.2.39 reset mld group](#)
- [8.2.40 reset mld group ssm-mapping](#)
- [8.2.41 robust-count \(MLD view\)](#)
- [8.2.42 send-router-alert \(MLD view\)](#)
- [8.2.43 ssm-mapping \(MLD view\)](#)
- [8.2.44 timer other-querier-present \(MLD view\)](#)
- [8.2.45 timer query \(MLD view\)](#)
- [8.2.46 ttl-check \(MLD view\)](#)

8.2.1 MLD Configuration Commands

Product	Support
S1720	Not supported.
S2700	Not supported.
S5700	Supported by all models excluding the S5700S-LI, S5700LI, and S5710-X-LI.
S6720	Supported.

8.2.2 display default-parameter mld

Function

The **display default-parameter mld** command displays default MLD configurations.

Format

display default-parameter mld

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to check default MLD parameter settings even after MLD parameters are modified. This command helps you determine which MLD parameters have been modified.

Example

Display default MLD configurations.

```
<HUAWEI> display default-parameter mld
MLD View Default Configurations:
-----
Lastmember-queryinterval: 1 s
Lastmember-query time: 2 s
Max-response-time: 10 s
Require-router-alert: disabled
Robust-count: 2
Send-router-alert: enabled
Ssm-mapping: disabled
Timer query: 125 s

Interface View Default Configurations:
-----
Group-policy: disabled
Last listener query time: 2 s
Lastlistener-query-interval: 1 s
Max-response-time: 10 s
Other-querier-present-timer-expiry: off
Prompt-leave: disabled
Require-router-alert: disabled
Robust-count: 2
Send-router-alert: enabled
Ssm-mapping: disabled
Startup-query-timer-expiry: off
Static-group: disabled
Timer query: 125 s
Version: 2
```

Table 8-19 Description of the **display default-parameter mld** command output

Item	Description
MLD View Default Configurations	Default configurations in the MLD view.

Item	Description
Lastmember-queryinterval	Interval for sending Multicast Address Specific Query messages or Multicast Address and Source Specific Query messages. This parameter is configured using the lastlistener-queryinterval (MLD view) command in the MLD view or the mld lastlistener-queryinterval command in the interface view.
Lastmember-query time	Last listener query time, equaling Lastmember-query-interval x Robust-count.
Max-response-time	Maximum response time for MLD Query messages. This parameter is configured using the max-response-time (MLD view) command in the MLD view or the mld max-response-time command in the interface view.
Require-router-alert	Whether the switch checks the Router-Alert option in received MLD messages. This function is configured using the require-router-alert (MLD view) command in the MLD view or the mld require-router-alert command in the interface view.
Robust-count	Robustness variable of the MLD querier. This parameter is configured using the robust-count (MLD view) command in the MLD view or the mld robust-count command in the interface view.
Send-router-alert	Whether the MLD messages sent from the switch carry the Router-Alert option. This function is configured using the send-router-alert (MLD view) command in the MLD view or the mld send-router-alert command in the interface view.
Ssm-mapping	Status of the MLD SSM mapping function. The value can be: - enabled: This function is enabled. - disabled: This function is disabled. This function is configured using the mld ssm-mapping enable command in the interface view.
Timer query	Interval for sending MLD General Query messages. This parameter is configured using the timer query (MLD view) command in the MLD view or the mld timer query command in the interface view.

Item	Description
Interface View Default Configurations	Default configurations in the interface view.
Group-policy	Whether a multicast group policy is configured. - enabled: A multicast group policy is configured. - disabled: No multicast group policy is configured. A multicast group policy is configured using the mld group-policy command.
Last listener query time	Last listener query time, equaling Lastlistener-query-interval x Robust-count.
Lastlistener-query-interval	Interval for sending Multicast Address Specific Query messages or Multicast Address and Source Specific Query messages.
Other-querier-present-timer-expiry	Status of the other querier present timer. - off: The interface considers itself a querier and no other queriers exist. - on: The interface no longer considers itself a querier and another querier exists.
Prompt-leave	Whether the fast leave function is configured. This function is configured using the mld prompt-leave command.
Startup-query-timer-expiry	Status of the query timer on the interface that functions as the querier. - off: The interface has sent Query messages. - on: The interface has not finished sending Query messages.
Static-group	Whether static multicast groups are configured. - enabled: Static multicast groups are configured. - disabled: No static multicast groups are configured. A static multicast group is configured on an interface using the mld static-group command.
Version	MLD version number. MLD has two versions: MLDv1 and MLDv2. This parameter is configured using the mld version command.