

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, MultiGE interface view, port group view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

When multiple user networks connect to the interfaces of the same PE, the PE interface needs to distinguish STP packets from different user networks. In this case, you need to configure the STP packets sent from each CE interface to contain the specified VLAN ID. In addition, the STP packets sent to the CE interface must also contain the specified VLAN ID.

On the CE interface, run the **stp bpdu vlan** *vlan-id* command to configure the STP packets sent to the PE to contain the specified VLAN ID. On the PE interface connected to the CE, run the **l2protocol-tunnel vlan** command to enable the STP packets with the specified VLAN ID to traverse the ISP network.

Before running the **stp bpdu vlan** command on a CE interface, ensure that the CE interface has been added to the specified VLAN.

The **stp bpdu vlan** command is usually configured on the network interface of the CE.

Example

Configure the STP packets sent from GE0/0/1 to contain VLAN ID 100.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type trunk
[HUAWEI-GigabitEthernet0/0/1] port trunk allow-pass vlan 100
[HUAWEI-GigabitEthernet0/0/1] stp bpdu vlan 100
```

Related Topics

[5.17.15 l2protocol-tunnel vlan](#)

5.17.19 stp snooping enable

Function

The **stp snooping enable** command enables STP snooping.

The **undo stp snooping enable** command disables STP snooping.

By default, STP snooping is disabled on interfaces.

Format

stp snooping enable

undo stp snooping enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After you run the [l2protocol-tunnel](#) command to enable transparent transmission of Layer 2 protocol packets on untagged interfaces or the [l2protocol-tunnel vlan](#) command to enable transparent transmission of Layer 2 protocol packets on tagged interfaces, the untagged or tagged interfaces directly forward Layer 2 protocol packets sent from user networks over the ISP network but not send them to the CPU for processing. When a device enabled with Layer 2 protocol transparent transmission receives TC packets, the device clears the MAC entries and ARP entries and updates the forwarding table after the **stp snooping enable** command is executed.

Example

Enable STP snooping.

```
<HUAWEI> system-view  
[HUAWEI] stp snooping enable
```

Related Topics

[5.17.11 l2protocol-tunnel](#)

[5.17.15 l2protocol-tunnel vlan](#)

6 IP Service Commands

About This Chapter

- 6.1 IPv4 Configuration Commands
- 6.2 ARP Configuration Commands
- 6.3 DHCP Configuration Commands
- 6.4 DHCP Policy VLAN Configuration Commands
- 6.5 DNS Configuration Commands
- 6.6 mDNS Gateway Configuration Commands
- 6.7 mDNS Relay Configuration Commands
- 6.8 UDP Helper Configuration Commands
- 6.9 IP Performance Optimization Configuration Commands
- 6.10 Basic IPv6 Configuration Commands
- 6.11 DHCPv6 Configuration Commands
- 6.12 IPv6 DNS Configuration Commands
- 6.13 IPv6 over IPv4 Tunnel Configuration Commands
- 6.14 IPv4 over IPv6 Tunnel Configuration Commands

6.1 IPv4 Configuration Commands

- 6.1.1 Command Support
- 6.1.2 ip address
- 6.1.3 ip address unnumbered
- 6.1.4 display ip interface
- 6.1.5 display interface