

1.9663 esi dynamic

Function

The **esi dynamic** command binds a dynamic ESI instance to an interface.

The **undo esi dynamic** command unbinds a dynamic ESI instance from an interface.

By default, a dynamic ESI instance is not bound to an interface.

Format

esi dynamic *esi-name*

undo esi dynamic *esi-name*

Parameters

Parameter	Description	Value
<i>esi-name</i>	Specifies the name of a dynamic ESI instance.	The value is a string of 1 to 31 case-sensitive characters starting with a letter, spaces not supported.

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Task Name and Operations

Task Name	Operations
bgp	write

Usage Guidelines

Usage Scenario

In scenarios where different CEs are dual-homed to PEs, if you want a remote PE to send unicast traffic to different CEs in different modes (load balancing and non-load balancing), you can set a redundancy mode per ESI instance. Before performing this configuration, you need to confirm the ESI generation mode on the access side. If an ESI on the access side is automatically generated, you need to run the **esi dynamic-name** command in the global EVPN configuration view to configure a dynamic ESI instance, and then run the **evpn redundancy-mode** command in the dynamic ESI instance view to set a redundancy mode. To allow the configured redundancy mode to take effect, run the **esi dynamic** command to bind the dynamic ESI instance to an Eth-Trunk interface on the access side.

Prerequisites

A dynamic ESI instance has been created using the **esi dynamic-name** command in the global EVPN configuration view.

Example

```
# Bind a dynamic ESI instance to an Eth-Trunk interface.
<HUAWEI> system-view
[~HUAWEI] evpn
```

```
[*HUAWEI-evpn] esi dynamic-name esi1
[*HUAWEI-evpn-esi-dynamic-esi1] evpn redundancy-mode all-active
[*HUAWEI-evpn-esi-dynamic-esi1] quit
[*HUAWEI-evpn] quit
[*HUAWEI] interface Eth-Trunk 10
[*HUAWEI-Eth-Trunk10] esi dynamic esi1
```

1.9664 esi dynamic-name

Function

The **esi dynamic-name** command configures a dynamic ESI instance with a specific name.

The **undo esi dynamic-name** command deletes a dynamic ESI instance.

By default, no dynamic ESI instance is created.

Format

esi dynamic-name *esi-name*

undo esi dynamic-name *esi-name*

Parameters

Parameter	Description	Value
<i>esi-name</i>	Specifies the name of a dynamic ESI instance.	The value is a string of 1 to 31 case-sensitive characters starting with a letter, spaces not supported.

Views

Global EVPN configuration view

Default Level

2: Configuration level

Task Name and Operations

Task Name	Operations
bgp	write

Usage Guidelines

Usage Scenario

In scenarios where different CEs are dual-homed to PEs, if you want a remote PE to send unicast traffic to different CEs in different modes (load balancing and non-load balancing), you can set a redundancy mode per ESI instance. Before performing this configuration, you need to confirm the ESI generation mode on the access side. If an ESI on the access side is dynamically generated, you need to run the **esi esi** command in the global EVPN configuration view to configure a dynamic ESI instance, and then run the **evpn redundancy-mode** command in the dynamic ESI instance view to set a redundancy mode.

Precautions

After a dynamic ESI instance is created, you need to run the **esi dynamic** command to bind the dynamic ESI instance to an Eth-Trunk interface on the access side.

Example

```
# Configure a dynamic ESI instance with a specific name.
<HUAWEI> system-view
[~HUAWEI] evpn
[*HUAWEI-evpn] esi dynamic-name esi1
```

1.9687 evpn redundancy-mode

Function

The **evpn redundancy-mode** command sets a redundancy mode for an ESI instance.

The **undo evpn redundancy-mode** command restores the default configuration.

By default, if the evpn redundancy-mode single-active command is run in the system view, the redundancy mode of an ESI instance is single-active; if the evpn redundancy-mode single-active command is not run, the redundancy mode of an ESI instance is all-active.

Format

evpn redundancy-mode { single-active | all-active }

undo evpn redundancy-mode { single-active | all-active }

Parameters

Parameter	Description	Value
single-active	Sets an ESI instance to be in single-active mode.	-
all-active	Sets an ESI instance to be in all-active mode.	-

Views

esi-dynamic view, esi-static view

Default Level

2: Configuration level

Task Name and Operations

Task Name	Operations
bgp	write

Usage Guidelines

Usage Scenario

In scenarios where different CEs are dual-homed to PEs, if you want a remote PE to send unicast traffic to different CEs in different modes (load balancing and non-load balancing), you can set a redundancy mode per ESI instance. Before performing this configuration, you need to confirm the ESI generation mode on the access side and then create a dynamic or static ESI instance based on the ESI generation mode. Each dynamic or static ESI instance corresponds to a unique ESI on the access side. Therefore, you can run the evpn redundancy-mode { single-active | all-active } command in a dynamic or static ESI instance to set a redundancy mode for the corresponding ESI.

Precautions

- After the evpn redundancy-mode single-active command is configured for an ESI, the ESI cannot be configured for a BD with UMR enabled.
- If an ESI has been configured for a BD with UMR enabled, the evpn redundancy-mode single-active command cannot be configured for the ESI.

- In a scenario where the PEs to which a CE is dual-homed continuously transmit EVPN VPLS service traffic, after an EVPN service sub-interface is deleted and then reconfigured, or the EVPN service is bound to or unbound from a service sub-interface, upstream traffic will experience millisecond-level loopback, and downstream traffic will experience millisecond-level packet duplication. If a loop detection protocol is running on a device connected to a PE, the device may incorrectly consider that a loop exists. It is recommended that you manually stop EVPN VPLS service traffic before changing the configuration.

Example

Set the redundancy mode of a static ESI instance to single-active.

```
<HUAWEI> system-view
[~HUAWEI] evpn
[*HUAWEI-evpn] esi 0011.1001.1001.1001.1002
[*HUAWEI-evpn-esi-0011.1001.1001.1001.1002] evpn redundancy-mode single-active
```

Set the redundancy mode of a dynamic ESI instance to all-active.

```
<HUAWEI> system-view
[~HUAWEI] evpn
[*HUAWEI-evpn] esi dynamic-name esi1
[*HUAWEI-evpn-esi-dynamic-esi1] evpn redundancy-mode all-active
```