

4.2.49 port media type

Function

The **port media type** command determines whether an interface configuration item belongs to the optical interface or electrical interface.

The **undo port media type** command restores the default settings.

Format

port media type { copper | fiber }

undo port media type { copper | fiber }

Parameters

Parameter	Description	Value
copper	Indicates that a configuration item belongs to the electrical interface.	-
fiber	Indicates that a configuration item belongs to the optical interface.	-

Views

GE interface view

Default Level

2: Configuration level

Usage Guidelines

This command only distinguishes optical interface configuration and electrical interface configuration, and is not configurable.

If you have specified the interface attributes (such as auto-negotiation, speed, and full-duplex mode) on a combo interface, the system automatically generates this command to determine whether an interface configuration item belongs to the optical interface or electrical interface. After this command is generated, the configuration for the other interface type (such as optical interface) will not be lost if the combo interface works as an electrical interface.

For example, after you run the [2.1.10 display this](#) command on a combo interface, the interface configuration is as follows:

```
#  
interface GigabitEthernet0/0/1
```

```
port media type copper
undo negotiation auto
speed 100
port media type fiber
undo negotiation auto
#
```

The command output shows that there are two configuration items **undo negotiation auto** and **speed 100** when the combo interface works as an electrical interface and one configuration item **undo negotiation auto** when the combo interface works as an optical interface.

Example

None

4.2.50 port protect-group

Function

The **port protect-group** command creates an interface protection group and enters the interface protection group view.

The **undo port protect-group** command deletes the created interface protection group.

By default, no interface protection group is created.

Format

port protect-group *protect-group-index*

undo port protect-group *protect-group-index*

Parameters

Parameter	Description	Value
<i>protect-group-index</i>	Specifies the ID of an interface protection group.	The value is an integer that ranges from 0 to 63.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Item	Description
alarm time	Date and time when alarms were generated.
Total: <i>m</i>	Total number of suppressed entries <i>m</i> .

13.6.18 display snmp-agent trap feature-name cfmgr all

Function

The **display snmp-agent trap feature-name cfmgr all** command displays the status of all traps for the cfmgr module.

Format

display snmp-agent trap feature-name cfmgr all

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After enabling the trap function for the cfmgr module, you can run the **display snmp-agent trap feature-name cfmgr all** command to check the status of all traps for the cfmgr module. To enable the trap function for the cfmgr module, run the **snmp-agent trap enable feature-name cfmgr** command.

Prerequisites

The SNMP function has been enabled on the device.

Example

Display the status of all traps for the cfmgr module.

```
<> display snmp-agent trap feature-name cfmgr all
```

```
-----  
Feature name: cfmgr  
Trap number : 1
```

```
-----  
Trap name           Default switch status  Current switch status
```

```
hwAuthenAssociateAccessLimitTrap
on on
```

Table 13-110 Description of the **display snmp-agent trap feature-name cfgmgr all** command output

Item	Description
Feature name	Name of a module to which a trap belongs
Trap number	Number of traps.
Trap name	Trap name. Traps of the cfgmgr module include: hwAuthenAssociateAccessLimitTrap: A Huawei proprietary trap is sent when the number of associated users on an interface exceeds the maximum value.

13.6.19 local-authorize

Function

The **local-authorize** command specifies the user authorization information to be delivered to a control device.

The **undo local-authorize** command restores the default user authorization information to be delivered to a control device.

By default, all user authorization information can be delivered to a control device.

Format

local-authorize { **none** | { **acl** | **car** | **priority** | **ucl-group** | **vlan** } * }

undo local-authorize

Parameters

Parameter	Description	Value
acl	Delivers ACL authorization information.	-
car	Delivers CAR authorization information.	-

13.6.21 snmp-agent trap enable feature-name cfgmgr

Function

The **snmp-agent trap enable feature-name cfgmgr** command enables the trap function for the cfgmgr module.

The **undo snmp-agent trap enable feature-name mid_aaa** command disables the trap function for the cfgmgr module.

By default, the trap function is enabled for the cfgmgr module.

Format

**snmp-agent trap enable feature-name cfgmgr [trap-name
hwaauthenassociateaccesslimittrap]**

**undo snmp-agent trap enable feature-name cfgmgr [trap-name
hwaauthenassociateaccesslimittrap]**

Parameters

Parameter	Description	Value
cfgmgr	Enables or disables the trap function for the specified event of the cfgmgr module.	-
hwaauthenassociateaccesslimittrap	Enables the device to send a Huawei proprietary trap when the number of associated users on an interface exceeds the maximum value.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** as required to enable the trap function for one or more events.

Example

Enable the hwauthenassociateaccesslimittrap trap function for the cfgmgr module.

```
<> system-view
[] snmp-agent trap enable feature-name cfgmgr trap-name hwauthenassociateaccesslimittrap
```

13.6.22 user-detect

Function

The **user-detect** command enables the online user detection function on an access device.

The **undo user-detect** command disables the online user detection function on an access device.

By default, the online user detection function is enabled on an access device, the detection interval is 15 seconds, and the number of packet retransmission attempts is 3.

Format

user-detect { **interval** *interval-value* | **retry** *retry-value* } *

undo user-detect

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the detection interval.	The value is an integer that ranges from 1 to 65535, in seconds. The default value is 15.
retry <i>retry-value</i>	Specifies the number of packet retransmission attempts.	The value is an integer that ranges from 1 to 255. The default value is 3.

Views

System view

Default Level

2: Configuration level