

Individual Settings for Rig Control in Minos v2

Model	HamLib Reference	Connect Note 5	Hex Note 6	Speed Note 7	Data bits	Stop bits	Parity	Handshake	Notes
Elecraft									
K3	229	RS232		38400	8	1	N	N	
Flex									
6x00									See Note 9
Icom									See Note 8
IC756 pro2	347		0x64	19200	8	1	N	N	
IC-910X	344		0x64	19200	8	1	N	N	
IC-7100	341	USB	0x88	19200	8	1	N	N	
IC-7100	341	CT17	0x88	19200	8	1	N	N	
IC-7300	373	USB	0x94	19200	8	1	N	N	
IC-7300	373	CT17	0x94	19200	8	1	N	N	
IC-9100	368	USB	0x7C	19200	8	1	N	CTS/RTS	Also works with "Handshake" = N
IC-9100	368	CT17	0x7C	19200	8	1	N	N	
IC-9700	344	USB	0x2A	19200	8	1	N	N	Using settings for IC-910
IC-9700	344	CT17	0x7C	9600	8	1	N	N	Using settings for IC-910
Kenwood									
TS-590S	231	USB		19200	8	1	N	CTS/RTS	Also works at 38400 Bd
TS-590SG	237	ZLP RS		19200	8	1	N	N	
TS-2000	214	ZLP RS		9600	8	1	N	N	Latest version may have a Comms problem
TS-2000X	214			38400	8	2	N	N	
TS-2000X	214			9600	8	1	N	CTS/RTS	
Yaesu									
FT-817	120			4800	8	2	N	N	
FT-847	101	RS232		9600	8	2	N	N	Prolific chipset
FT-857D	122	Note		38400	8	1	N	N	USB-62 from RT Systems
FT-950	128			9600	8	2	N	CTS/RTS	
FT-991	135	USB		38400	8	1	N	N	Possible Comms problem
FT-991A	135	USB		38400	8	1	N	N	Possible Comms problem
FT-1000MP	124			4800	8	2	N	N	
FT-dx-5000	132	ZLP RS		38400	8	2	N	N	

Notes:

- 1> These settings have been found to work for individual users - they are not necessarily optimum but make a good "starting point" for new installations. Some Rigs (as noted) appear to have a Comms problem in that they do not always accept commands from Minos correctly.
- 2> Based on experience with other programs, using direct USB connection is likely to be more reliable than using an RS232 connection. Also, using an un-powered USB2 Hub seems to offer an improvement in some cases.
- 3> If using a USB<->RS232 converter, ones using a genuine "Prolific" chipset seem to be more reliable than others.
- 4> If data for your Rig is not shown here, then it is worth starting with default parameters given either in the Handbook or used in other programs.
- 5> CT17 = Icom CT-17 (CI-V); RS232 = USB to RS232 converter or direct RS232; USB = direct link via USB port; ZLP RS = USB to RS232 serial CAT Interface by G4ZLP.
- 6> The "Hex" value is normally only required for Icom Rigs and its value depends on the internal Rig setting. Can be left blank if the default setting is used in the Rig.
- 7> Ensure your Rig is set to the same Data Speed (Baud Rate) as the program! On some Rigs, you need to switch off the power and back on for the change to take effect. Most Rigs will work over a wide range of Baud Rates.
- 8> Most Icom Rigs need these "Set mode settings" - CI-V baud rate = 19200, CI-V Transceive = OFF. BUT "CI-V Transceive = ON" also works on some Rigs, but "OFF" seems to be more reliable.
- 9> The "HamLib" library that MINOS uses does not currently support Flex radios directly. A work-around is to setup the Flex to use "CAT over IP" or via "Serial Port". For IP use 127.0.0.1 and for serial use "Kenwood 2000" in MINOS.

Many thanks to ML&S for the use of some of their Rigs to enable us to complete part of the above data.

If/when you have a Rig working satisfactorily, would you please email me the details (see below) so I can add them to the list which I will then publish at intervals for all to use.

Email to MinosRigData@outlook.com

73, Peter G3ZPB. V3