

Individual Settings for Rotator Control in Minos v2

Model	Method Note 7	Speed	Data bits	Stop bits	Parity	Handshake Note 8	Notes
Idiom Press							
Rotor-EZ	RS232	4800	8	1	N	N	Prolific chipset.
Yaesu							
GS232B	RS232	9600	8	1	N	N	Prolific chipset. See Note 9
ERC							
ERC-M	RS232	9600	8	1	N	N	Older model - Set as "603, Yaesu, GS-232B"
ERC-M	RS232	9600	8	1	N	N	Newer model with SMD - Set as "601, Yaesu, GS-232A"
ERC-R							See Note 10
DF9GR	RS232	4800					
MDS/MFJ							
RC1							See Note 11

Notes:

- 1> These settings have been found to work for individual users - they are not necessarily optimum but make a good "starting point" for new installations.
- 2> Based on experience with other programs, using direct USB connection is likely to be more reliable than using an RS232 connection. Also, using an un-powered USB2 Hub seems to offer an improvement in some cases.
- 3> If using a USB<->RS232 converter, ones using a genuine "Prolific" chipset seem to be more reliable than others.
- 4> If data for your Controller is not shown here, then it is worth starting with default parameters given either in the Handbook or used in other programs.
- 5> Ensure your rotator is set to the same Data Speed (Baud Rate) as the program !
- 6> Setting the "Poll Time" to 3 seconds can sometimes help a slow system to work.
- 6> USB indicates a direct link via USB port to the rig; RS232 indicates USB <->RS232 converter or direct RS232 connection.
- 7> Setting Handshake to "CTS/RTS" can help supply power to the Interface.
- 8> Requires V4.0 firmware to support CW and CCW commands.
- 9> There are some significant problems with interfacing to ERC-R units and the User is advised to contact the suppliers to arrange an upgrade to an ERC-M unit.
- 10> Configure as an ERC DF9GR.

If/when you have a rotator working satisfactorily, would you please email me the details (see below) so I can add them to the list which I will then publish at intervals for all to use.

Email to MinosRigData@outlook.com

73, Peter G3ZPB. V5