

Contoso Field Handbook

Sample knowledge document for the kb-prompt-agent. Replace it with your own PDF.

1. Arriving on site

Check in with the site contact before touching any equipment. Confirm the work order number, the maintenance window and the isolation points. Photograph the equipment label before you start.

2. Replacing a pump seal

Isolate the pump and lock out the supply. Drain the casing into the approved container. Remove the coupling guard, then the old seal. Fit the new seal dry, never oil the faces. Torque the gland nuts in a cross pattern to 25 Nm. Restore power only after a second engineer signs the permit.

3. Escalation

If a fault is not cleared within two hours, escalate to the regional duty engineer. Record the fault code, the steps already tried and the readings you took. Safety incidents are escalated immediately, regardless of the time.

4. Returning spares

Return unused spares within five working days. Scan the part barcode, pick the return reason and attach the packing slip. Damaged parts go in the red crate with a fault note.