TimberNest

Crafted wood. Comfortable homes.

Frequently Asked Questions

Answers to commonly asked questions about TimberNest furniture products, delivery, assembly, care, warranty, and support.

Products and Materials

Q1. What types of furniture do you sell?

Beds, sofas, dining sets, wardrobes, study tables, bookshelves, TV units, and storage furniture.

Q2. Which woods do you use?

Solid sheesham, teak, and mango wood, plus engineered wood (MDF and plywood) for budget lines. The wood type is listed on each product page.

Q3. What sizes are available?

Small, medium, and large, suitable for rooms between 100 and 250 square feet. Exact dimensions are on every product page.

Q4. What weight can the furniture hold?

Beds up to 300 kg, sofas up to 250 kg, and dining chairs up to 120 kg per seat. Check each product page for exact limits.

Ordering, Delivery, and Assembly

Q5. How long does delivery take?

Ready-stock items arrive in 5 to 10 business days. Made-to-order and custom items take 3 to 6 weeks.

Q6. How can I track my order?

Share your order ID with Shree, our support assistant, or open My Orders on the website.

Q7. Can I assemble the furniture myself?

Professional assembly is strongly recommended. Self-assembly of items that include a free assembly service voids the warranty.

Q8. What should I check on delivery?

Inspect packaging for dents or missing parts, take photos or a video while unboxing, and report any issue within 48 hours.

Care and Maintenance

Q9. How should I clean wooden furniture?

Wipe with a soft, dry or slightly damp cloth, then dry immediately. Avoid harsh chemicals and polish with a wood-safe product every 3 months.

Q10. How often should I maintain my furniture?

Check screws, joints, and fittings every 3 months, and tighten them if needed for optimal performance.

Q11. How do I protect it from moisture and sunlight?

Keep it away from direct sunlight, heaters, and damp walls. Leave at least 2 inches of gap from the wall for air circulation.

Q12. How do I remove stains or water rings?

Blot spills immediately, do not rub. Use coasters under hot or wet items, and clean surfaces every 2 weeks.

Warranty, Returns, and Support

Q13. What warranty do I get?

1 year comprehensive warranty on all products and a 5 year warranty on the structural frame.

Q14. What is the return window?

Refund requests within 30 days of delivery; damaged or defective products are considered for up to 90 days.

Q15. How do I raise a refund or warranty request?

Contact support with your order ID and a description of the issue, with photos if possible, or chat with Shree on our website.

Q16. What if Shree cannot resolve my issue?

Shree escalates the case to a human manager, who reviews refunds and special requests and gets back to you.

© TimberNest. All rights reserved. This document is provided for informational purposes and represents a fictional company FAQ document.