

R-Control IP4 – MQTT Interface (Home Assistant / Generic)

What is this?

Over MQTT the device integrates into a home automation system — above all **Home Assistant**. The device reports its state to an MQTT broker and accepts switching commands from there.

The big advantage over every other interface: Home Assistant **creates the entities itself**. You do not have to configure anything by hand — after switching on, four switches, a temperature sensor and the buttons as automation triggers simply appear.

You need an MQTT broker on your network (e.g. the Mosquitto add-on in Home Assistant).

Getting there in 5 minutes

Step 1: Enter the broker details

Web interface → **Settings** → **Interfaces** → **Home Assistant MQTT**

Field	Example
Enable Home Assistant MQTT	tick
MQTT broker URI	mqtt://192.168.0.50:1883
MQTT username	homeassistant
MQTT password	your broker password
Base topic	r-control-ip4 (default)
Discovery prefix	homeassistant (default)

Step 2: Check the connection

Press **Test connection**. The status line tells you right away whether address and credentials are correct — before you even save.

Step 3: Save

After saving, the device connects. Under **Overview** → **Device status** → **Details**, the *Home Assistant MQTT* row shows whether the connection is up.

Step 4: Look in Home Assistant

Settings → **Devices & Services** → **MQTT** → the device appears automatically with all entities. Done.

Connection not working? The test states the cause in plain text, e.g. "Username or password incorrect" or "Broker unavailable". You can still save the settings — the device connects on its own as

soon as the broker becomes reachable.

What appears in Home Assistant

Entity	What you can do
4 × switch	turn outputs on and off
1 × temperature sensor	current temperature (if an NTC is connected)
4 × device trigger	react to button presses (click, double click, long press)

The easiest way to build an automation reacting to a double click on input 1 is graphically in Home Assistant:

Automation → **Trigger** → **Device** → **R - Control IP 4** → **Input 1 double clicked**.

From here on follows the **complete reference part** with all details.

What is this?

Over MQTT the device integrates into a home automation system — above all **Home Assistant**. The device reports its state to an MQTT broker and accepts switching commands from there.

The big advantage over every other interface: Home Assistant **creates the entities itself**. You do not have to configure anything by hand — after switching on, four switches, a temperature sensor and the buttons as automation triggers simply appear.

You need an MQTT broker on your network (e.g. the Mosquitto add-on in Home Assistant).

Getting there in 5 minutes

Step 1: Enter the broker details

Web interface → **Settings** → **Interfaces** → **Home Assistant MQTT**

Field	Example
Enable Home Assistant MQTT	tick
MQTT broker URI	mqtt://192.168.0.50:1883
MQTT username	homeassistant
MQTT password	your broker password
Base topic	r-control-ip4 (default)
Discovery prefix	homeassistant (default)

Step 2: Check the connection

Press **Test connection**. The status line tells you right away whether address and credentials are correct — before you even save.

Step 3: Save

After saving, the device connects. Under **Overview** → **Device status** → **Details**, the *Home Assistant MQTT* row shows whether the connection is up.

Step 4: Look in Home Assistant

Settings → **Devices & Services** → **MQTT** → the device appears automatically with all entities. Done.

Connection not working? The test states the cause in plain text, e.g. "Username or password incorrect" or "Broker unavailable". You can still save the settings — the device connects on its own as soon as the broker becomes reachable.

What appears in Home Assistant

Entity	What you can do
4 × switch	turn outputs on and off
1 × temperature sensor	current temperature (if an NTC is connected)
4 × device trigger	react to button presses (click, double click, long press)

The easiest way to build an automation reacting to a double click on input 1 is graphically in Home Assistant: **Automation** → **Trigger** → **Device** → **R - Control IP 4** → **Input 1 double clicked**.

From here on follows the **complete reference part** with all details.

This document describes the **MQTT interface** of the R-Control IP4 from an integration perspective. It targets customers/partners who want to connect the device via an MQTT broker (especially **Home Assistant MQTT Discovery**).

Status: Implementation in [components/ha_mqtt](#) (firmware repo). The interface is broker-based and publish/subscribe oriented.

1. Overview

Purpose

- Publish relay states and switch relays via command topics.
- Optional: publish temperature value (NTC).
- Optional: publish button/input events as Home Assistant "Device Automation Triggers".
- Home Assistant auto-discovery via MQTT (discovery prefix configurable).

Characteristics

- Transport: MQTT over TCP (URI-based, e.g. [mqtt://<broker>:1883](#))

- Authentication: broker login optional (`username/password`)
- QoS: 0..2 (configurable)
- Retain: configurable for state topics
- Availability / LWT: set (online/offline)

2. Activation & Configuration

The MQTT feature is enabled via the device configuration.

2.1 Configuration Path

All MQTT settings are located under:

- `config.interfaces.ha_mqtt.*`

2.2 Configuration Keys

Required/default:

- `config.interfaces.ha_mqtt.enabled` (bool)
 - `true` = MQTT client is started
 - `false` = MQTT client is stopped
- `config.interfaces.ha_mqtt.uri` (string)
 - broker URI, e.g. `mqtt://192.168.0.2:1883`
- `config.interfaces.ha_mqtt.username` (string, optional)
- `config.interfaces.ha_mqtt.password` (string, optional)
- `config.interfaces.ha_mqtt.base_topic` (string)
 - default: `r-control-ip4`
- `config.interfaces.ha_mqtt.discovery_prefix` (string)
 - default: `homeassistant`
- `config.interfaces.ha_mqtt.qos` (int 0..2)
 - default: `1`
- `config.interfaces.ha_mqtt.retain` (bool)
 - default: `true`
- `config.interfaces.ha_mqtt.keepalive` (int, seconds)
 - range: `15..3600`
 - default: `60`

Optional temperature publishing:

- `config.interfaces.ha_mqtt.temperature.enabled` (bool)
 - default (firmware): `true`
- `config.interfaces.ha_mqtt.temperature.min_interval_ms` (int)
 - default (firmware): `10000`
 - `0` = no throttling

Note: The example `spiffs/config.json` typically contains only the base fields. The `temperature.*` values are optional and use firmware defaults if not present.

3. Device Identity (`device_id`)

The MQTT topics include a `device_id`, which is generated automatically by the firmware:

- Base is `config.network.lan.eth0.hostname`.
- The hostname is normalized to an MQTT/HA compatible ID format (lowercase, special characters → `_`).
- Additionally (if available) the last 3 bytes of the MAC address are appended.

Example (schematic):

- Hostname: `R-Control-IP4`
- `device_id`: `r_control_ip4_a1b2c3`

4. Topic Structure

4.1 Base Topics

With `base_topic=<BT>` and `device_id=<ID>`:

- Device availability (global):
 - `<BT>/<ID>/status`
 - payload: `online` / `offline` (retained)
- Relays (1..4):
 - State: `<BT>/<ID>/relay/<n>/state`
 - payload: `ON` / `OFF` (retained depending on `retain`)
 - Command: `<BT>/<ID>/relay/<n>/set`
 - payload: `ON` / `OFF` / `TOGGLE`
- Button events (1..4):
 - `<BT>/<ID>/button/<n>/event`
 - payloads: `pressed`, `released`, `click`, `double_click`, `long_press`, `long_press_release`
 - retain: `false`
- Temperature (optional):
 - State: `<BT>/<ID>/temperature/state`
 - payload: float as string with 2 decimals (e.g. `22.50`)
 - Availability (sensor-specific): `<BT>/<ID>/temperature/status`
 - payload: `online` (only when sensor status OK) / `offline`

4.2 Home Assistant Discovery Topics

With `discovery_prefix=<DP>`:

- Relays as HA switch entities:
 - `<DP>/switch/<ID>/relay_<n>/config`
- Temperature as HA sensor entity (if enabled):
 - `<DP>/sensor/<ID>/temperature/config`

- Buttons as HA device automation triggers:
 - `<DP>/device_automation/<ID>/button_<n>_<event>/config`

Discovery payloads are JSON (unformatted), retained (`true`).

5. Payloads & Semantics

5.1 Relay Command Payload

Accepted payloads on `<BT>/<ID>/relay/<n>/set`:

- `ON` → turn relay on
- `OFF` → turn relay off
- `TOGGLE` → toggle relay

The firmware accepts commands case-insensitively (internally normalized to uppercase).

5.2 Relay State Payload

On `<BT>/<ID>/relay/<n>/state` the firmware publishes:

- `ON` or `OFF`

Publishing occurs:

- initially on MQTT connect (snapshot)
- on relay events (state changed / impulse done / blink tick)

5.3 Availability (LWT)

- On connect the device publishes `online` to `<BT>/<ID>/status`.
- A last will is configured to publish `offline` if the connection drops unexpectedly.
- LWT is retained.

5.4 Temperature Publishing (Optional)

- Only if `config.interfaces.ha_mqtt.temperature.enabled=true`.
- Sensor availability is tracked separately:
 - `online` only for `NTC_SENSOR_STATUS_OK`
 - otherwise `offline`
- Temperature values are throttled:
 - minimum interval `temperature.min_interval_ms`
 - additionally, publishing is allowed despite throttling if the value changes by at least `0.2°C`.

6. Integration Notes (Best Practices)

6.1 Topic Design

- For custom integrations it is recommended to use only the state/command topics.
- For Home Assistant, MQTT discovery (discovery prefix) is the preferred approach.

6.2 Idempotency

- Idempotent: **ON**, **OFF**
- Not idempotent: **TOGGLE** (retries may cause unexpected state changes)

Recommendation: In robust systems, avoid **TOGGLE** and send deterministic **ON/OFF**.

6.3 QoS/Retain

- QoS **1** is a good default for LAN integrations.
- Retain **true** for relay state is useful so new subscribers immediately receive the last known state.
- Button events are intentionally not retained.

7. Security Notes

Security largely depends on the MQTT broker.

Recommendations:

- Enable broker authentication (user/pass) and restrict permissions per client (ACLs).
- Operate the broker only in a trusted network or use TLS/**mqtt**s:// (depending on broker/setup).
- Design topics / configure ACLs so that only authorized systems are allowed to publish to **.../relay/<n>/set**.

8. Examples

8.1 Example (mosquitto_sub)

```
# Watch all device topics
mosquitto_sub -h 192.168.0.2 -t 'r-control-ip4/#' -v

# Watch discovery
mosquitto_sub -h 192.168.0.2 -t 'homeassistant/#' -v
```

8.2 Example (mosquitto_pub)

```
# Turn relay 1 on
mosquitto_pub -h 192.168.0.2 -t 'r-control-ip4/<device_id>/relay/1/set' -m 'ON'

# Turn relay 1 off
mosquitto_pub -h 192.168.0.2 -t 'r-control-ip4/<device_id>/relay/1/set' -m 'OFF'
```

Tip: You can easily find **<device_id>** in the broker by first running **mosquitto_sub -t 'r-control-ip4/+status' -v**.

9. Compatibility & Changes

The MQTT integration is Home Assistant compatible (discovery) and may be extended in future firmware versions.

For integrations with very specific requirements (e.g. complex state models), the JSON REST API or the WebSocket gateway can be used alternatively (see [docs/API.md](#)).