

MACHINE MAINTENANCE SOP

1. Purpose

This SOP explains the basic maintenance procedure for manufacturing machines.

2. Safety Precautions

- Switch off the machine before maintenance.
- Disconnect the power supply.
- Wear required safety equipment.
- Do not touch moving parts during maintenance.

3. Daily Inspection

- Check machine power connection.
- Check abnormal noise or vibration.
- Check oil and lubrication levels.
- Check machine temperature.
- Clean the machine working area.

4. Maintenance Procedure

Step 1: Stop the machine.

Step 2: Disconnect the power supply.

Step 3: Inspect machine components.

Step 4: Check lubrication.

Step 5: Check belts and connections.

Step 6: Clean the machine.

Step 7: Restart and test the machine.

5. Maintenance Frequency

Daily: Visual inspection and cleaning.

Weekly: Lubrication and component inspection.

Monthly: Detailed maintenance and calibration check.

6. Emergency Condition

If abnormal noise, excessive vibration, overheating or sudden machine failure is observed, stop the machine immediately and inform the maintenance supervisor.

7. Responsible Person

Maintenance Technician and Production Supervisor are responsible for maintenance activities.