User's Manual

2 L

Image may vary

English

Product Introduction

Pet fountain

Components:

Before getting started, ensure the package contains the following

1* water fountain storage tank



1* water tray + 1* filter tray + 3* filters + 1* buoy + 1* faucet

1* water pump

1* power adapter

1* user manual

Use Case

- This product is intended to be used as a water source for pets. This product is suitable for indoor use only.
- This product is intended to be used in dry **areas** only
- No liability will be accepted for damage(s) resulting from improper use or non-compliance with these instructions.

English

Before Use

- Carefully remove all packaging materials and retain for future use.
- Check for transport damages.
- Clean the water fountain by drinkable water. Rinse the filters 3-5 minutes thoroughly with drinable water before use(to remove the carbon powder that may maintain on the surface).
- Check the power supply, the voltage and the current rating corresonds before power on. They must match with the rating label on the adapter.

PRODUCT PARAMETERS

Product Name:Pet water dispenser

Product Model: **WF 150**

Product material: **304 stainless steel**

Voltage/current: 5V/100MA

Filter material: sponge + resin + activated carbon

Dimensions (L * W * H) : 185*185*130 mm

Color: **Silver**

Capacity: 2 L

Weight: **0.75** KG

PRODUCT INTRODUCTION



English

INSTALLATION AND SET UP

Make sure rinse the filters 3-5 minutes thoroughly with drinkable water every time before use.

Step1: Install the water pump on the base of the filter Press untill pump won't fall

Step2: Inset the buoy to the filter tray firstly and make the buoy sit on the red widget that stick on the filter tray

Step3: put 3 filters sequentially in the filter tank

Step4: add water into the water tank do not add too full

Step5: install the filter tray to the water tank, clear up the pump cord make sure it won't go to the bottom

Step6: Put the stainless steel water tray on the filter tray

Step7: install the faucet and press untill it fit snugly

Step8: Check the power supply than power on the water fountain

DEEP CLEAN INSTRUCTION

1.including parts 2.uninstall the outer cap 3.uninstall the inner motor cap 4.take out the rotor and clean all the parts

English

Operation

Turning the product on/off

WARNING **Risk of electric shock!** Always unplug the product when not in use.

CAUTION **Risk of damage!** Do not turn on the product when the water storage tank is empty.

- Place the product on a stable, flat, water-resistant ground.
- To turn on the product, plug the power adapter into an appropriate mains socket.
- To turn off, unplug the power adapter from the mains socket.

Cleaning and Maintenance

WARNING **Risk of electric shock!** Do not wash the power adapter by water or any other liquids. Always keep the power adapter dry.

WARNING **Risk of electric shock!** Always unplug the product when not in use. Do not plug in the power when installation and clean.

CAUTION **Risk of electric shock!** Do not use corrosive detergent and metal sharpe brush to wash and clean the product.

CAUTION **Must Clean Periodically!** Please clean it by hand under running water every time when changing the filters and do not use corrossive detergent for the health of your pets.

English

Cleaning Instruction

- Clean the water container and accessories before first use.
- Cleaning the pump is essential to the durability. Please clean the pump at least every 2 weeks.
- Clean the water container every two weeks,increasing the cleaning times according to pets drinking habits and the quality of the water.
- Clean every new (first use)filter under running water and rinse it for 3-5 minutes
- Change the filter set once 1-2 weeks

Cleaning Tips

- Rinse all parts,except the power adapter.
- Dry the product after cleaning.

Storage

- Store in a cool and dry place away from children and pets
- Avoid any sway and impact force.

FAQs

Q:What if the product does not work and there is no water come out?
A:Please check if the water in the water container reaches the minimum water level.

Q:The water tank is full of water,plug is in,but no water pumped out?
A:Please check if the adapter plug is damaged.If you still can't resolve the problem by replacing the adapter,please contact customer service.

Q:Why is the pump noisy after using for some times?
A:The pump make noise when the water level goes down to its top.Please add water to cover the pump and see.If does not help ask for customer service.

English

IMPORTANT SAFEGUARDS

Please read these instructions carefully and retain them for future use.

To avoid the risk of fire, electric shock and/or injuries users should always comply with the basic safety guides shown below when using electric appliance:

- Keep the operating water fountain away from children.
  Only use the original package accessories and the purchase the repalacement from the official store
- Do not use outdoors. For indoor use only.
- Do not drag the power cord to unplg. Pull out the adapter to unplug.
- Stop using when any damages been found on the power cord or the adapter. If the damages been found during the working please shut down the electricty of the house than unplug or call for professional help.
- Do not use the product near a bath tub or a sink to avoid the adapter or the cord getting wet.
- Be cautious about the biting behavior of the pets.

We offer a one-year warranty on our water fountain.
For the health of your beloved pets, please ensure you purchase replacement filter from our brand's official store.

English

Made In China