

STEP 1 — USB 연결 (WSL 터미널)

```
sudo modprobe gs_usb
```

```
sudo modprobe vhci-hcd
```

STEP 2 — USB 연결 (PowerShell 관리자)

```
usbipd bind --busid 1-2
```

```
usbipd attach --wsl --busid 1-2
```

STEP 3 — CAN 활성화 (WSL 터미널)

```
cd ~/piper_ws
```

```
bash can_activate.sh can0 1000000
```

STEP 4 — ROS2 노드 실행 (터미널 1)

```
cd ~/piper_ws
```

```
source install/setup.bash
```

```
ros2 launch piper start_single_piper.launch.py
```

(터미널 1은 계속 켜놔야 함)

STEP 5 — Piper Moveit 실행 (터미널 2, 새 터미널)

```
cd ~/piper_ws
```

```
source install/setup.bash
```

```
ros2 launch piper_moveit demo.launch.py
```

STEP 6 — (터미널 3, 새 터미널)

```
cd ~/piper_ws && source install/setup.bash
```

```
cd /mnt/c/Users/Ryuminseo/source/repos/DLIP/Final/Main
```

```
python3 Final_Robot.py
```