

Mimaki UJF-6042 MkII e

A2 UV-LED flatbed · direct-to-object (up to 153mm thick) · CMYK+W+Lc/Lm+Clear · Kebab rotary

ADPOST GROUP
SHOP-FLOOR CARD

GOLDEN RULE

Shake every **WHITE** ink bottle (~20 gentle tilts) before each shift and run daily white maintenance. White circulates only in the sub-tank, NOT through the head, so it settles fast. Never leave the machine idle longer than 1-2 weeks. Put it on a UPS / line conditioner.

DAILY — tick each shift

- ☐ Shake the white ink bottle(s) before the shift.
- ☐ Nozzle check before the first job; clean Head 4 (white) if it's dropping.
- ☐ Wipe the clear/primer head face with approved flushing fluid (F-200 / FL-007).
- ☐ Clean wiper, caps + flushing box; check the ionizer needle is clean.
- ☐ IPA-wipe slick parts (glass/acrylic); ionizer fan on in dry weather.
- ☐ Set head height to the part's true HIGH point + use the correct jig/spacer.

WEEKLY / MONTHLY PM

- Clean the X-axis encoder strip + homing sensor (prevents Error 533).
- Inspect dampers / filters / tubing; replace on schedule.
- Re-torque the table-base screws + re-check the table is level.
- Check ink expiry on delivery (firmware locks out expired ink); rotate FIFO.

TOP PROBLEMS » QUICK FIX

White drops out mid-job (Head 4) » shake bottle, white maintenance, syringe-flush/replace white solenoid (M015864), confirm Head 4 at temp.

Error 533 (X homing fail) » CLEAN the encoder strip + sensor FIRST — not the electronics.

White “blowout” / mist on art » ionizer + 35-65% RH, lower head gap (~1.5mm), IPA-wipe parts.

Ink scratches off glass/metal » PR-200 primer + IPA degrease; scratch-test new substrates.

Clear/primer head dead » cycle ink + clean daily; budget periodic head replacement.

KEEP ON THE SPARES SHELF

- White solenoid valve (M015864) — forum-sourced part, confirm against your unit.
- Wipers, caps, dampers, filters.
- Flushing fluid (F-200 / FL-007); spare X-axis encoder strip.

SOFTWARE

- **RasterLink7**: RIP + jig (object alignment) + variable-data / numbering.
- **Mimaki Clear Control (MCC)**: gloss / matte / 2.5D textured clear.
- **Kebab MkII control**: enter diameter for 360° cylindrical printing.

CALL THE TECH IF 1. auto-maintenance freezes >1h (temp sensor / valves / o-rings) 2. white won't recover after solenoid flush + cleaning 3. encoder strip is scratched (needs replacement)

Full brief: [Docs/printers/printer-onboarding-brief.md](#) | Official manuals + videos: [Docs/printers/official-resources.md](#) | Some figures are platform/sibling-sourced — verify on your unit. v1 · 2026-06-19