

ATA-42 rev a & Up-Grade Wiring

PAX Case Cir. Connector Amphe-Lite AL06F21-41P

TEC Power 2 pins

p TEC Power + **red**
q TEC Power - **black** (blue)

TEC Control 6 pins

a Heat Sink Temp **white** Z (twisted pairs)
G Heat Sink Temp **white** Z
b Pax Temp **blue** Y
H Pax Temp **blue** Y
c Airstream Temp **green** X
J Airstream Temp **green** X

Cryo Power 4 pins

d Cryo Power + **white**
K Cryo Power + **white**
e Cryo Power - **black**
M Cryo Power - **black**
Shield grnd **gray**

Cryo Temp 2 pins

D Cryo Temp 1 **white**
E Cryo Temp 2 **black**
Shield grnd **gray**

Dewar Temp 2 pins

U Dewar Temp 1 **white**
T Dewar Temp 2 **black**
Shield grnd **gray**

PAX Control 12 pins

Z Grnd OTXTEC **black** Z
Y +5V OTXTEC **red** Z
B Grnd OTX laser / PAM **black** Y
C +6V OTX laser / PAM **green** (gray) Y
k Gnd Sense **black**
s +6 Sense **green** (blue)(gray)
X +5 Sense **red**
m -6 Sense **blue** (black)
i Grnd OTXTEC **black** X
j +5V OTXTEC **red** X
V Grnd OTX / PAM **black** W
W -6V OTX / PAM **blue** W

Ion Pump Control 6 pins (11")

f Current monitor **blue**
g External reset **white**
h Power +12 VDC **red**
r Power com **black**
P Fault high voltage **brown**
R Fault blown fuse **gray**

Pax Case/ Rim Box Ground 1 pin (3-1/2")

L Grounded to case **green**

Connector Positions Not Used

A
N
n
S
t



Back View (inside Pax Case)

"A" position is at 12:00 / L position is at 6:00



2010 ID letters move around