Figure 6 Linetypes A Linetype Manager Linetype filters Load... Delete Show all used linetypes Current Hide details Current Linetype: ByLayer Linetype Description Appearance SFO-GAS -G -- G -- G -- G ---- G.AB -- G.AB -- G.AB -- HWR -- HWR -- HWR -- HWR -- HWR -- HWR -- HWS -- HWS -- HWS -- HWS -- HTWR -- HTWR -- HTWR -- HTWS SFO-HEATGWATR-RTRN(HVAC) SFO-HEATGWATR-SUPL(HVAC) SEO-HIGHTEMPWATR-RTRN(HVAC) SFO-HIGHTEMPWATR-SUPL(HVAC) -- HW --- HW ----- IW --- IW --- IW --- IW ----- IW-AB --- IW-AB --- IW-AB ----- IW-AB-SF --- IW-AB-SF ---SFO-HOTWATER(HVAC) SFO-INDWAST SFO-INDWASTA SFO-INDWASTA SLURRYFILLED SFO-INDWASTFM SFO-MAKEUPWATR(HVAC) - IW-FM --- IW-FM --- IW-FM ---- MW --- MW --- MW --- MW --- MW ---SFO-OHELEC SEO-OHTELE -OT -- OT -- OT --SFO-POWR SFO-POWR12KV SFO-POWR12KVA SFO-POWRDB SFO-PRECONDAIR-RTRN(HVAC) - P-DB --- P-DB --- P-DB --- P-- PCAR --- PCAR --- PCAR --- PCAR --- PC SFO-PRECONDAIR-SUPL(HVAC) SFO-PRIMCHILWATR-RTRN(HVAC) - PCAS --- PCAS --- PCAS --- PC - PCHR --- PCHR --- PCHR --- PCHR --- PC SFO-PRIMCHILWATR-SUPL(HVAC) PCHS --- PCHS --- PCHS --- PC SFO-SEWER SFO-SEWERA -- S --- S --- S --- S --- S -----S-AB---S-AB---S-AB---S-AB---SFO-SEWERFM SFO-SEWERGW SFO-SEWERLAT --- LAT --- LAT --- LAT ---SFO-SL - SL --- SL --- SL --- SL --- SL ---- SL-AB --- SL-AB --- SL-AB ----- SL-AB --- SL-AB --- SL-AB ----- T --- T --- T --- T ----- T-AB --- T-AB--- T-AB--- T-AB SFO-SLA SFO-TELE SFO-TELEA SFO-TELECOND(FAA) SFO-TVCOND --- T (FAA) --- T (FAA) --- T (FAA) ------ TV --- TV ---SFO-VENT(HVAC) SFO-VENTA(HVAC) SFO-WATRA SFO-WATRA SLURRYFILLED SFO-FIREALRM --- FA --- FA --- FA --- FA --- FA ------ Hidden (.5x) \_\_\_\_\_ HIDDEN2 SFO-TOFA-II ----- TOFA-II --- -------SFO-TOFA-III SEO-ROFA-L - ROFA-I --- --SFO-ROFA-II SFO-ROFA-III - ROFA-III -- --SFO-ROFA-IV -- ROFA-IV --- ---SFO-ROFA-VI ROFA-V ------- ROFA-VI ---— — OH — OH — OH — — # — AFFF — AFFF — AFFF — AF SFO-OHPOWR SFO-AUXFFF