L1-M3 · L1-M4

# E-stop and unexpected behaviour

What to do when something is not right

1. **E-stop works in every mode**
   In manual and autonomous mode alike, it takes immediate priority and halts all operation, whatever state MoRo is in.

2. **Manual override does not disable safety**
   It is for repositioning during setup, clearing a blocked path, or post-maintenance testing.

3. **Something unexpected?**
   MoRo moves somewhere new, or stops for no clear reason.

4. **Any immediate concern: use E-stop**
   Then report it. Diagnosing is not the operator's job at this level. Report early, even if it turns out minor.

**When in doubt, stop it and report it.**