

Connecting and Testing

1. Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.

- Plug the USB webcam into a USB port.
- Wait for Windows to detect the device.
- Windows usually installs the required driver automatically.

Step 2: Verify Driver Installation

1. Press Win + X → Device Manager
2. Expand Cameras or Imaging Devices
3. Your webcam should appear without any yellow warning icon.

Example:

Cameras

Logitech HD Webcam C270

Step 3: Open Camera App

1. Press Windows
2. Search Camera
3. Open the Camera app.
4. Allow camera permissions if prompted.

If the live video appears, the webcam is working.

Step 4: Capture a Photo

Click the Camera button.

The image is saved in:

Pictures

Camera Roll

Screenshot to Include

- Camera app showing live video.
- Captured photo.

Task 2. Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.

Step 1: Connect Printer

For USB Printer:

- Connect USB cable.
- Turn on printer.

For Network Printer:

- Connect printer to same Wi-Fi network.

Step 2: Install Driver

Go to

Settings

→ Bluetooth & Devices

→ Printers & Scanners

→ Add Device

Windows should detect the printer.

If not:

- Download the latest driver from the printer manufacturer's website.
- Install it.

Step 3: Print Test Page

1. Open

Settings

→ Printers & Scanners

2. Select your printer.

3. Click

Manage

4. Click

Print a Test Page

The printer should print a Windows test page.

Screenshot

Take a screenshot of:

- Installed printer
- Test page printed

**3. Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem.

Hint: Check for error icons and use the 'Scan for hardware changes' option after reconnecting.**

Step 1

Disconnect the USB cable.

Windows may display:

Printer Offline

or

Printer Not Connected

Step 2

Open

Device Manager

You may notice:

- Printer disappears

OR

- Yellow warning icon

Step 3

Reconnect USB cable.

Step 4

In Device Manager click

Action

→ Scan for hardware changes

Windows detects the printer again.

Step 5

Verify

Go back to

Printers & Scanners

Printer should return to

Ready

Troubleshooting Notes

Problem:

Printer not detected after unplugging USB.

Cause:

USB connection interrupted.

Resolution:

- Reconnect USB cable.
- Use Scan for hardware changes.
- Reinstall/update the printer driver if needed.
- Restart the Print Spooler service if necessary.

Task 4. A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications.<b

Step 1: Connect the Webcam

This usually means the webcam hardware is fine and the issue is with Zoom settings or permissions.

Step 1: Close Other Apps

Ensure no other app (Camera, Teams, Skype, etc.) is using the webcam.

Step 2: Check Camera Permissions

Go to:

Settings

→ Privacy & Security

→ Camera

Verify:

- Camera access = On
- Let apps access your camera = On
- Zoom is allowed to use the camera.

Step 3: Select the Correct Camera in Zoom

1. Open Zoom.
2. Click the Settings (gear) icon.
3. Select Video.
4. Choose the correct webcam from the Camera drop-down list.
5. Verify that the video preview appears.

Step 4: Restart Zoom

Close Zoom completely (including from the system tray) and reopen it.

Step 5: Update the Webcam Driver

1. Open Device Manager.

2. Expand Cameras.
3. Right-click the webcam → Update driver.
4. Choose Search automatically for drivers.

Step 6: Check Zoom for Updates

In Zoom:

- Click your profile picture.
- Select Check for Updates.
- Install any available updates.

Final Verification

- Open the Camera app and confirm the webcam works.
- Open Zoom and verify the live video appears in the Video settings or when joining a meeting.

Troubleshooting Summary

Issue	Cause	Solution
Webcam works in Camera but not Zoom	Incorrect camera selected	Choose the correct camera in Zoom
Black screen in Zoom	Camera in use by another app	Close other applications using the webcam

Issue	Cause	Solution
Zoom cannot access camera	Windows permissions disabled	Enable camera permissions for Zoom
Webcam not detected in Zoom	Driver or Zoom issue	Update the webcam driver and Zoom, then restart