

## **Machine - Switches**

### **1. Master Switch – Control All**

- Control Master relay and section relays.

### **2. Master Switch – Master Relay only**

- Control Master relay

### **3. Master Switch – Master Override**

- Master Switch is always on.

### **4. Work Switch**

- Use a switch connected to the implement to control On/Off.

### **5. Auto Switch – Rate**

- Auto rate control.

### **6. Auto Switch – Sections**

- Auto section control.

### **7. On-Screen Switches – Enabled**

- Show on-screen switches.

### **8. On-Screen Switches – Dual Auto**

- Show auto rate button and auto section button.