Machine – Primed Start

Menu: Machine > Primed Start

Applies product while the machine is stopped: to fill the lines, the meter or the sprayer booms, or to cover a corner that was missed. Once that is done, normal rate control can carry on as you drive away. The machine must be stopped (below 0.1 km/h) for Primed Start to begin.

Setting	Description	Default
Simulated Speed	The ground speed the rate is worked out from while priming. This is the same setting as the simulated speed used by Machine > Calibrate, by the Simulated speed source in File > Options and by the phone page, so changing it here changes it there too.	8 km/h (5 mph)
Application Rate	The rate while priming and stopped, as a % of the rate at the Simulated Speed. 100 % gives the full target rate; a lower % gives a slower flow. 0 % gives no flow.	100 %
Prime Duration	How long priming runs (seconds). With **When moving at** selected, this is the longest priming can run while stopped.	20 s
Hold Master to start Prime	How long to hold a momentary master switch on to start priming (3 to 8 seconds). Shorter holds would start priming by accident.	3 s
Prime ends	When priming ends: **When Prime Duration ends**, or **When moving at** a set speed. See How Priming Ends below.	When Prime Duration ends
When moving at	The speed that ends priming, when that option is selected (0.3 to 5 km/h, 0.2 to 3 mph). Priming ends after about 1 second at or above this speed.	0.8 km/h (0.5 mph)
Keep Master on when Prime Duration ends	When Prime Duration runs out, leave master on so normal rate control carries on. Unticked, master turns off.	Off

The note under the settings says what will flow: that a product's Min UPM still applies, that Prime Duration limits priming while stopped (with **When moving at** selected), or that nothing will flow when the Simulated Speed or Application Rate is 0.

How Priming Ends

When Prime Duration ends

Priming runs for the Prime Duration, then ends. If **Keep Master on** is ticked, master stays on and normal rate control carries on. If not, master turns off. If you drive away before it ends, the rate follows your real speed and area counts, but priming still runs until the time is up.

When moving at

Priming runs while you are stopped and ends about 1 second after you reach the set speed. Master always stays on, so normal rate control (or AgOpenGPS section control) carries on with no presses. Short speed spikes while

parked, such as GPS jitter, don't end it. If you don't move, Prime Duration still ends it, and **Keep Master on** decides whether master stays on.

Once priming ends, normal control decides. With AgOpenGPS auto sections on, AgOpenGPS turns the sections off on a headland or over covered ground, as it normally would.

Working with AgOpenGPS or AgOpenWeb

For no gap when you pull away into the field, set the slow speed cutoff in AgOpenGPS (Config > Tool) or in AgOpenWeb (Tool, *Slow speed cutoff*) at or below the **When moving at** speed. Then AgOpenGPS is ready to turn its sections on when priming hands over.

While priming, the sections follow the switchbox or on-screen section switches, not AgOpenGPS.

Rate While Priming

- **Application Rate:** while stopped, the flow is the % set here of the flow at the Simulated Speed, for the sections that are on.
- **Min UPM:** a product's Min UPM (Products > Settings) still applies. If it is above the priming flow, the Min UPM flows instead. For a fixed low flow while stopped, use a low % with the product's Min UPM.
- **Current Rate:** while priming and stopped, Current Rate shows the target rate at any %. A lower % shows as a slower flow and quantity, not a lower rate.
- **Area:** no area is counted while stopped. Quantity and hours still count. Once you move, area counts at your real speed.
- **Moving:** once the machine is moving, the rate follows the real speed, at the full target rate.

Activating Primed Start

On-Screen Switch Panel or Phone

Press the **PRM** button. Primed start activates immediately — no hold required. The PRM button turns green while priming is active, and is dimmed while the machine is moving. This is the quickest way to start priming.

Before pressing PRM, turn on the section switches you want to prime. Only sections that are currently switched on will run during priming.

Physical Switchbox — Momentary Switch

Hold the master switch in the **On** position for the **Hold Master to start Prime** time. Primed start activates once the time is up. Holding master while moving doesn't start priming.

Cancelling

Press the master switch Off, or press the on-screen **MST** button while master is on. Primed start stops immediately.

> **Note:** Primed Start is not available when **Maintained** switch type is selected in Machine > Switches.

Controls

Control	Action
Cancel	Discard changes
Save	Save settings