Machine – Switches

Menu: Machine > Switches

Configures how the master switch, auto switches, and on-screen virtual switches behave.

Master Switch Mode

Select one option. Controls what the master switch turns on and off.

Option	Description
Standard	Master switch controls the master relay and all section relays. When master turns off, all section relays turn off. When master turns back on, section relays resume their switch positions.
Master Override	Forces the module to treat master as always on, regardless of switch state. Useful for motor control when the master switch should not interrupt the motor PID loop.

Switch Type

Select one option. Describes the physical type of master switch connected.

Option	Description
Momentary	Standard push-to-make switch. Each press toggles master on or off. Holding the switch in the on position while stopped activates Primed Start after the **Hold Master to start Prime** time set in Machine > Primed Start.
Maintained	Toggle or latching switch. Master follows the switch position directly — on when switch is on, off when switch is off. Primed Start is not available in this mode.

Auto Switch

Setting	Description
Rate	Enables automatic rate control via the switchbox Auto Rate switch
Sections	Enables automatic section control via the switchbox Auto Section switch

Other Settings

Setting	Description
Work Switch	Uses a switch connected to the implement to gate master on/off. Master will only activate when the work switch is on. The switch's pin, momentary behavior and NO/NC invert are set per module under Modules > Pins.
On-Screen Switches – Enabled	Shows the virtual on-screen switch panel. See On-Screen Switches below.
On-Screen Switches – Rate Only	Shrinks the on-screen panel to just the rate up/down buttons. Master, PRM, the section switches and Auto Rate/Section are hidden, and the switch count is not used.
On-Screen Switches – 4 / 8 / 12 / 16	Number of section switches shown on the on-screen switch panel. Not available when Rate Only is selected.

On-Screen Switches

When enabled, a floating switch panel appears on screen. Its buttons always show the switch states in use. With no physical switchbox connected, the panel is the switchbox. With a switchbox connected the panel still works — see With a Switchbox Connected below.

Button	Function
MST	Toggles master on/off. Green = master on, unlit = master off.
PRM	Activates Primed Start immediately. Green while priming is active. Dimmed when Maintained switch type is selected or when the vehicle is moving. Before pressing Prime, turn on the section buttons you want to prime — only sections that are switched on will run. How priming ends is set in Machine > Primed Start.
▲ / ▼	Rate adjustment. Hold to increase or decrease rate or PWM.
1 – 16	Section switches (4, 8, 12, or 16 buttons, as configured). Green = section on, unlit = section off.
Auto Rate	Toggles automatic rate control. Green = auto rate on.
Auto Section	Toggles automatic section control. Green = auto section on.

The panel has no title bar and uses the display colours set under Options. To reposition it, drag the panel background (the gaps between the buttons) with either mouse button, or **right-click and drag** on a button. A left click on a button always presses it. Where it is dropped decides what it follows. Dropped overlapping the main screen it follows the main screen. Dropped overlapping another floating window — a product popup display or the pressure display — it follows that window instead, so a group of windows can be moved together. If it overlaps both, the main screen wins. Drop it clear of everything to unlatch it.

With **Rate Only** checked, the panel shrinks to a small window holding just the ▲ / ▼ buttons.

With a Switchbox Connected

- **Taking control:** the first on-screen press takes control from the switchbox. It starts from the current switch positions, so only the button pressed changes.

- **The switchbox always wins:** moving any switch on the switchbox (master, sections, rate or auto) hands control back straight away and the switchbox positions apply again. The work switch doesn't count.
- **No timeout:** the screen keeps control until a switchbox switch is moved. Unlike the phone, there is no 120 second timeout.
- **▲ / ▼:** change the rate while held and stop when released.
- **Main screen MST and Auto:** work the same way. With no switchbox, MST on from the main screen also turns all enabled sections on. With a switchbox connected it only turns master on — the sections stay as they are.

Plugging In or Unplugging the Switchbox

Neither changes any switch positions. About 3 seconds after the switchbox stops communicating, the on-screen panel carries on from the positions in use, including a maintained master that is on. When the switchbox is plugged back in, those positions are held until a switch on the switchbox is moved, and then the switchbox takes over. The exception is the first switchbox after the app starts: its switch positions apply straight away.

Phone Switches

The **Switches** page on the phone is a copy of the on-screen switch panel: MST, PRM, ▲, ▼, the section switches, Auto Rate and Auto Section, in the tablet's display colours. It shows the full panel even when the tablet uses Rate Only. Like the on-screen panel, it works with a physical switchbox connected. To connect a phone, see File > Options > Phone.

- **Taking control:** the first press on the phone takes control from the cab. It starts from the current switch positions, so nothing changes until a button is pressed. The status line shows *Remote in control* and the seconds left.
- **The cab always wins:** moving any switch on the switchbox (master, sections, rate or auto) hands control back straight away and the switch positions apply again. The work switch doesn't count. With no switchbox connected, a press on the on-screen panel does the same. The phone shows *Cab switchbox took control*.
- **Sharing with the on-screen panel:** with a switchbox connected, on-screen presses don't end the phone's control — the phone and the screen share it until a switchbox switch is moved. While only the screen has control, the phone shows *Cab in control*.
- **Timeout:** after 120 seconds with no press on the phone or the on-screen panel, control goes back to the cab and **master turns off** (*Timed out, master off*). A maintained master switch stays off until it is switched off and on again.
- **Auto Section:** can be turned off from the phone, for when auto was left on in the cab. While it is on and AgOpenGPS is connected, AgOpenGPS controls the sections and the page shows a warning.
- **▲ / ▼:** change the rate while held. If the phone loses its connection while a button is held, the change stops within about a second.
- **PRM:** works as on the tablet: master on and prime, only with a momentary master switch and the machine stopped. When Prime Duration ends without **Keep Master on** ticked, master turns off and the sections stay as set on the phone.

Controls

Control	Action
Cancel	Discard changes
Save	Save settings