

Rate Map

Menu: File > Rate Map

The Rate Map enables variable rate application by defining geographic zones with different target rates. It integrates with AgOpenGPS for GPS-referenced mapping.

Zones Tab

Create zones by clicking the  button, then clicking at least **3 points** on the map to define the boundary.

- With **overlapping zones**, the **last zone added** takes priority.
- When variable rate is enabled but **no zone exists**, the **base rate** is used.

Button	Action
 New	Create a new rate zone
 Edit	Edit rate zone properties (name, rate per product, color)
 Delete	Delete corner (while creating) or delete zone (while editing)
 Cancel	Cancel edits
 Save	Save edits

Data Tab

Button	Action
Record count	Number of data points recorded
A / B / C / D / E	Select which product's applied rate to display on the map
 Record	Start/stop recording applied rates
 Delete	Delete all recorded applied rate data

Files Tab

Button	Action
 Import Zones	Import rate zones from a shapefile
 Export	Export the current rate zones to a shapefile (.shp)
 Import KML	Import a KML overlay file
 Delete KML	Delete a KML file associated with the current job
 Import Yield Data	Import yield data into the current job folder

VR Tab — Variable Rate Look-Ahead

Configures how far ahead of a zone boundary the application rate begins adjusting, so the rate matches the new zone's target as soon as the machine enters it. This compensates for the lag in the applicator system responding to a setpoint change.

Setting	Description
Look-Ahead Time (per product)	Seconds before entering a zone boundary that the rate adjustment begins. One value per product (up to 5).
Auto Tune	When checked, RC monitors look-ahead performance and automatically adjusts the look-ahead time to improve zone entry accuracy.

Set look-ahead time manually by entering a value for each product and pressing  OK. Enable **Auto Tune** to let RC refine the value automatically based on observed transition performance.

Display Toggle Buttons (right panel)

These buttons highlight green when active. Click to toggle on or off.

Button	Action
Sat. View	Toggle satellite background image
Target Zones	Toggle rate zone boundaries display
Applied Rates	Toggle applied rate colour overlay
Yield Data	Toggle yield data overlay
Elev.	Toggle elevation data overlay
KML Files	Toggle KML file overlay

Bottom Controls

Button	Action
 Minimize	Shrink the map to a small window. Drag it by its title bar to reposition.
 Centre	Centre the map on the current GPS position
 Help	Open this help page
 OK	Close the Rate Map