

Modules – Network

Menu: Modules > Network

Connects the application to a rate control module over Ethernet/UDP.

Connection Procedure

1. **(B) Refresh** the IP list to discover modules on the network.
2. **(A) Select** the module's IP address from the list.
3. **(C) Send** the subnet to the module.
 - The **Mod** indicator on the main screen should turn **green**.
 - The module must be connected before sending any other settings.
4. **(E) Select** a board type that matches your module hardware — this populates the **Defaults**.
5. Save changes with **(G)** or cancel with **(F)**.
6. Make any necessary changes on the remaining module pages (Config, Pins, Relay Pins, Valves), saving with **(G)** on each.
7. When all edits are complete, press **(D) Send** to transmit all settings to the module.
8. **(D)** can also be used after single-page edits.

Controls

Control	Action
 (C) Send	Send the subnet to the module
 (E) Select board type / Defaults	Select board type and populate default settings
 (F) Cancel	Discard changes
 (G) Save	Save settings

Board Types

Board	Controller
Nano (RC12-3)	Arduino Nano
Teensy (RC11-2)	Teensy 4.1
ESP32 (RC15)	ESP32

Note: After updating module firmware, resend the subnet (step 3) and resend the module config settings (steps 6–7).