

# Machine – Switches

---

## Menu: Machine > Switches

Configures how the master switch and auto switches behave.

| Setting                              | Description                                                 |
|--------------------------------------|-------------------------------------------------------------|
| 1. Master Switch – Control All       | Controls both the Master relay and all section relays       |
| 2. Master Switch – Master Relay Only | Controls only the Master relay                              |
| 3. Master Switch – Master Override   | Master switch is always on (ignores physical switch state)  |
| 4. Work Switch                       | Uses a switch connected to the implement to control On/Off  |
| 5. Auto Switch – Rate                | Enables automatic rate control                              |
| 6. Auto Switch – Sections            | Enables automatic section control                           |
| 7. On-Screen Switches – Enabled      | Shows on-screen section switches                            |
| 8. On-Screen Switches – Dual Auto    | Shows separate auto rate and auto section buttons on screen |

## Controls

| Control                                                                                    | Action          |
|--------------------------------------------------------------------------------------------|-----------------|
|  Cancel | Discard changes |
|  Save   | Save settings   |