

Modules – Config

Menu: Modules > Config

Configures the hardware settings of the connected module.

1. Relay Type

Value	Description
0	No relays
1	GPIOs — use micro-controller pins directly
2	PCA9555 — 8-relay module
3	PCA9555 — 16-relay module
4	MCP23017
5	PCA9685
6	PCF8574

2. Pin Assignments by Board

Parameter	RC5 (Nano)	RC8 (Nano)	RC11 (Teensy)	RC11-2 (Teensy)	RC12 (Nano)	RC12-3 (Nano)	RC15 (ESP32)
Sensor Count	2	2	2	2	1	2	2
Relay Control	4	4	1	1	2	4	5
Flow 1	2	2	28	28	D3	3	17
Flow 2	3	3	29	29	—	2	16
PWM 1	5	5	36	36	D9	5	33
PWM 2	9	9	15	15	—	9	26

3. Nano Pin Reference

Pin Name	Number
D0–D13	0–13
A0–A7	14–21

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings

Modules – Pins

Menu: Modules > Pins

Manually assigns the GPIO pins used for sensors and motor/valve control on the module. Pin values range from 0–50. A value of 255 (displayed as "–") means the pin is not assigned.

Setting	Description
Flow Sensor 1 Pin	Input pin for the first flow sensor
Flow Sensor 2 Pin	Input pin for the second flow sensor
Motor Direction 1 Pin	Output pin for motor direction channel 1
Motor Direction 2 Pin	Output pin for motor direction channel 2
PWM 1 Pin	PWM output pin for product 1 motor/valve
PWM 2 Pin	PWM output pin for product 2 motor/valve
Work Pin	Input pin for the work/implement switch
Pressure Pin	Analog input pin for the pressure sensor
Momentary	Enables momentary switch behavior on the work pin

Press **Rescan** to reset all pins to their board-specific defaults (as defined in Config).

Tip: When a board type is selected in Modules > Config, pressing **Defaults** populates these pin values automatically. Only change them if your hardware differs from the standard layout.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings

Modules – Relay Pins

Menu: Modules > Relay Pins

Assigns the physical GPIO pins to each of the 16 relay outputs on the module. Pin values range from 0–50. A value of 255 (displayed as "–") means the relay pin is not assigned.

- **Low Relays (1–8):** Labeled "Onboard Relays" or "Remote Relays" depending on module config.
- **High Relays (9–16):** Labeled "Onboard Relays" or "Remote Relays" depending on module config.

Press **Rescan** to clear all relay pin assignments.

Tip: When a board type is selected and **Defaults** is pressed in Modules > Config, relay pins are populated automatically for the chosen hardware.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings

Modules – Valves

Menu: Modules > Valves

Selects the wiring mode for the valve or motor driver.

Option	Description
2-Wire	Simple on/off control — one wire for power, one for ground 
3-Wire	For valves with separate open and close windings — one wire applies power to open, one applies power to close, and the third is a shared ground 

Select the mode that matches how your valve or motor driver is wired to the module.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings