

Options

Menu: File > Options

Speed Source & Display

Selects the source of ground speed used for rate calculations and configures display units.

Speed Source

Option	Description
GPS	Use speed from AgOpenGPS
Simulated Speed	Simulate a constant speed (useful for testing)
Wheel Sensor	Use a speed sensor connected to a module GPIO pin

Wheel Sensor Setup

1. Enter the **Module ID** and **GPIO pin** used for speed sensing.
2. Enter the calibration number in **pulses per mile** or **pulses per kilometer**.
3. Press the **up arrow** to send configuration to the module (also sent on Save).
4. Use the **Calibration screen** to calculate the calibration number if unknown.

Display Options

Option	Description
Metric	Toggle between metric (km, ha, L) and imperial (mi, ac, gal) units
Rate Display	Show or hide an additional rate display window with a larger font

Buttons

Button	Action
 up arrow	Send wheel sensor configuration to the module
Calibration screen	Open the speed calibration screen
 Save	Save settings
 Cancel	Discard changes

CAN

Configures communication with rate control modules via CAN bus. This is an alternative to direct Ethernet/UDP communication.

Enable CAN

Check the **CAN Enable** checkbox to activate CAN communication.

CAN Driver Selection

Driver	Description
SLCAN	Serial port-based CAN adapter. Requires COM port selection.
InnoMaker USB2CAN	Native USB CAN adapter (InnoMaker hardware)
PCAN	Native USB CAN adapter (Peak PCAN hardware)

COM Port (SLCAN only)

1. Use the dropdown to select the COM port the adapter is connected to.
2. Press **Refresh** to rescan available COM ports.

Diagnostics

Option	Description
Enable Diagnostics	Enables CAN traffic debug logging

Status Indicators

Indicator	Meaning
 Connected	Green — module data received within the last 2 seconds
 Driver Found	Green — CAN adapter is open and receiving frames

Buttons

Button	Action
 Refresh	Rescan available COM ports
 Save	Save settings
 Cancel	Discard changes