

Machine – Pressure

Menu: Machine > Pressure

Calibrates a pressure sensor using two known reference points.

Calibration Procedure

- 1. Set the system to a **known low pressure**.
- 2. Enter the sensor **reading** and the actual **pressure** value.
- 3. Set the system to a **known high pressure**.
- 4. Enter the sensor **reading** and the actual **pressure** value.
- 5. Enter the **minimum sensor reading** that corresponds to 0 pressure.
- 6. Press **Show** to display the live pressure screen.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings