

Machine – Primed Start

Menu: Machine > Primed Start

Allows boom priming or a simulated product application while the tractor is stopped. Activate by holding the switchbox momentary master switch in the **On** position for the configured delay time.

Setting	Description
1. On Time	How long the application runs (seconds)
2. Speed	Simulated ground speed during priming
3. Master Switch Delay	How long to hold the master switch On to trigger primed start (seconds)
4. Resume	After On Time expires, if the tractor is moving, continue with normal operation

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings