

Machine – Relays

Menu: Machine > Relays

Assigns relay functions to each relay output on the module. There are **16 relays per module** and up to **8 modules**.

Control	Action
 Reset (circle)	Reset all relays to default
 Renummer (+)	Renummer sections sequentially
Relay Number	The relay output number
Relay Type	The behavior of the relay (see below)
Number	For Switch type: switch number. For Section/Invert_Section type: section number.
 Cancel	Discard changes
 Save	Save settings

Relay Types

Type	Description
Section	Controlled by section switch (AOG, switchbox, or on-screen). Master and Auto switches also apply.
Slave	On when any section relay is on; off when all section relays are off
Master	On when any section relay is on; turns off before section relays turn off
Power	Always on
Invert_Section	On when its assigned section is off
Hyd Up	Hydraulic raise
Hyd Down	Hydraulic lower
Tram Right	Tram marker right
Tram Left	Tram marker left
Geo Stop	Geofence stop output
Switch	Controlled directly by a switch. Not affected by Master or Auto switches.
Invert_Master	On when master is off or all sections are off