

Modules – Boards

Menu: Modules > Boards

Loads default pin assignments and module settings for a known board type. Use this as a starting point when setting up a new module — select the board closest to your hardware, save, then adjust individual settings on the Config, Pins, Relay Pins, and Valves pages as needed.

Board Types

Board	Microcontroller
Nano (RC12-3)	Arduino Nano
Teensy (RC11-2)	Teensy 4.1
ESP32 (RC15)	ESP32

Usage

1. Select the board type that most closely matches your module hardware.
2. Press **Save** to apply the default settings. The Save button highlights when a change is pending.
3. Review and adjust settings on the Config, Pins, Relay Pins, and Valves pages.

Resetting to Defaults

Press the **Reset** button to reload the default pin and relay settings for the currently selected board type without switching to a different board. This is useful if settings have been changed and you want to start over from the defaults.

Note: Saving a board type or pressing Reset overwrites the current module pin and relay settings with defaults. Only do this during initial setup or when switching hardware.