

Profiles

Menu: File > Profiles

A profile stores all machine configuration settings. Multiple profiles can be maintained for different implements.

Button	Action
 1. New	Create a new profile
 2. Load	Load the selected profile
 3. Delete	Delete the selected profile. Default, and the last remaining editable profile, can not be deleted
 4. Copy	Copy the selected profile to a new name. The copy is always editable, even when copied from Default
5. File name	Enter name for New or Copy
6. Files	List of available profiles to select
  7. Page Up/Down	Scroll through the profile list

The Default Profile

Default is a read only reference profile. It holds a known good starting configuration and is never changed by the program, so it is always available to start over from. It can not be deleted.

Because it is read only, settings changed while Default is loaded are **not saved**. To warn you of this, the profile name at the top left of the menu is shown on a **red background** whenever a read only profile is loaded.

To start a new setup from the reference configuration, select **Default**, type a name, and press **Copy**. The copy is a normal editable profile and is loaded automatically.

Because Default can not be saved to, the program always keeps one editable profile. On first run it makes one from Default and names it **Example**. Example is an ordinary profile — edit it, copy it, or delete it once you have a profile of your own. It is only rebuilt if no editable profile is left.