

Machine – Pressure

Menu: Machine > Pressure

Calibrates a pressure sensor using two known reference points, and sets a maximum pressure limit per module.

Calibration Procedure

1. Select the **Module** the pressure sensor is connected to.
2. Set the system to a **known low pressure**.
3. Enter the sensor **reading** and the actual **pressure** value.
4. Set the system to a **known high pressure**.
5. Enter the sensor **reading** and the actual **pressure** value.
6. Enter the **minimum sensor reading** that corresponds to 0 pressure.
7. Press **Show** to display the live pressure screen.

Pressure Display Window

Show opens a floating window with the live pressure for the current product's module. It has no title bar and uses the display colours set under Options.

Click and drag the window (either mouse button) to reposition it. Where it is dropped decides what it follows. Dropped overlapping the main screen it follows the main screen. Dropped overlapping another floating window — a product popup display or the on-screen switch panel — it follows that window instead, so a group of windows can be moved together. If it overlaps both, the main screen wins. Dropped clear of everything it follows nothing until it is dropped onto something again.

The window detaches while the main screen is minimized and re-attaches when the main screen is restored. If the window it was following is closed, it stays where it is and simply stops following. Its position is remembered between sessions.

Max Pressure

Sets the maximum allowed pressure for the selected module. When the measured pressure exceeds this value:

- The application shows a **High Pressure** alarm.
- The module also enforces the limit on its own, reducing flow to bring the pressure back below the limit — this protects the system even if communication with the PC is lost. Requires up-to-date module firmware.

If the pressure limit trips repeatedly in a short time, the module treats it as a fault and keeps reducing flow until the **master switch is turned off**, which resets the protection.

Set Max Pressure to **0** to disable the limit.

Sending to the Module

While the Pressure page is open, a **Send** button appears in the menu below Calibrate. Pressing it sends the saved Max Pressure limit of every connected module to that module. Nothing else is sent and the modules do not restart. The calibration points are used by the application only and are never sent.

Save stores the settings in the profile — it does not send anything. When a saved Max Pressure value differs from what was entered before, the Send button is highlighted green as a reminder to send it.

Send also works without editing anything. Use it to push the stored limit to a module that was not connected when the profile was opened — for example after switching to a different implement whose module has not received this profile's Max Pressure yet.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings to the profile (nothing is sent to the module)
Send	Send the saved Max Pressure limit to all connected modules