

Machine – Switches

Menu: Machine > Switches

Configures how the master switch, auto switches, and on-screen virtual switches behave.

Master Switch Mode

Select one option. Controls what the master switch turns on and off.

Option	Description
Standard	Master switch controls the master relay and all section relays. When master turns off, all section relays turn off. When master turns back on, section relays resume their switch positions.
Master Override	Forces the module to treat master as always on, regardless of switch state. Useful for motor control when the master switch should not interrupt the motor PID loop.

Switch Type

Select one option. Describes the physical type of master switch connected.

Option	Description
Momentary	Standard push-to-make switch. Each press toggles master on or off. Holding the switch in the on position activates Primed Start after the configured delay.
Maintained	Toggle or latching switch. Master follows the switch position directly — on when switch is on, off when switch is off. Primed Start is not available in this mode.

Auto Switch

Setting	Description
Rate	Enables automatic rate control via the switchbox Auto Rate switch
Sections	Enables automatic section control via the switchbox Auto Section switch

Other Settings

Setting	Description
Work Switch	Uses a switch connected to the implement to gate master on/off. Master will only activate when the work switch is on. The switch's pin, momentary behavior and NO/NC invert are set per module under Modules > Pins.
On-Screen Switches – Enabled	Shows the virtual on-screen switch panel. See On-Screen Switches below.
On-Screen Switches – Rate Only	Shrinks the on-screen panel to just the rate up/down buttons. Master, PRM, the section switches and Auto Rate/Section are hidden, and the switch count is not used.
On-Screen Switches – 4 / 8 / 12 / 16	Number of section switches shown on the on-screen switch panel. Not available when Rate Only is selected.

On-Screen Switches

When enabled, a floating switch panel appears on screen. It stays visible and its buttons track the connected switchbox's live state, but every on-screen button (Master, sections, Auto Rate/Section, Rate Up/Down) becomes unresponsive while a physical switchbox is actively connected — the panel is only functional when no physical switchbox is present. **PRM** is the exception: it always activates Primed Start immediately, even while a physical switchbox is connected.

Button	Function
MST	Toggles master on/off. Green = master on, unlit = master off.
PRM	Activates Primed Start immediately. Green while priming is active. Dimmed when Maintained switch type is selected or when the vehicle is moving. Before pressing Prime, turn on the section buttons you want to prime — only sections that are switched on will run.
▲ / ▼	Rate adjustment. Hold to increase or decrease rate or PWM.
1 – 16	Section switches (4, 8, 12, or 16 buttons, as configured). Green = section on, unlit = section off.
Auto Rate	Toggles automatic rate control. Green = auto rate on.
Auto Section	Toggles automatic section control. Green = auto section on.

The panel has no title bar and uses the display colours set under Options. **Right-click and drag** anywhere on the panel — including on the buttons — to reposition it. Where it is dropped decides what it follows. Dropped overlapping the main screen it follows the main screen. Dropped overlapping another floating window — a product popup display or the pressure display — it follows that window instead, so a group of windows can be moved together. If it overlaps both, the main screen wins. Drop it clear of everything to unlatch it.

With **Rate Only** checked, the panel shrinks to a small window holding just the **▲ / ▼** buttons. The same restriction applies to them as to the rest of the panel: they only operate when no physical switchbox is connected. With a switchbox attached they still track its rate up/down state, but pressing them does nothing.

Note: On-screen buttons other than PRM become unresponsive while a physical switchbox is connected and communicating — use the physical switchbox in that case. The panel remains visible and its buttons

continue to show the switchbox's state for reference.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings