

Rate Map

Menu: File > Rate Map

The Rate Map enables variable rate application by defining geographic zones with different target rates. It integrates with AgOpenGPS for GPS-referenced mapping.

Prescriptions Tab

Manages prescription shapefiles for the current field. The active prescription determines which zone rates are used during application.

Control	Action
Field	Shows the field name assigned to the current job
Prescription list	Lists all prescription files available for the current field. Select one to make it active. Zones.shp is the default and cannot be deleted.
New	Create a new empty prescription file with a given name
Copy	Copy the selected prescription to a new name. The copy becomes the active prescription.
Import	Import a prescription shapefile from another location
Export	Export the selected prescription shapefile to a chosen location
Delete	Delete the selected prescription file. Zones.shp cannot be deleted.

Note: Selecting a prescription from the list immediately makes it the active prescription for the current job. The map reloads to show the selected zones.

Zones Tab

Create and edit rate zones within the active prescription.

Create zones by clicking the  New button, then clicking at least **3 points** on the map to define the boundary.

- With **overlapping zones**, the **last zone added** takes priority.
- When variable rate is enabled but **no zone exists**, the **base rate** is used.

Button	Action
 New	Create a new rate zone
 Edit	Edit zone properties (name, rate per product, color)
 Delete	Delete corner point (while creating) or delete zone (while editing)
 Cancel	Cancel current edit
 Save	Save current edit

Data Tab

Control	Action
Record count	Number of applied rate data points recorded
A / B / C / D / E	Select which product's applied rate to display on the map
 Record	Start/stop recording applied rates
 Delete	Delete all recorded applied rate data

VR Tab — Variable Rate Look-Ahead

Configures how far ahead of a zone boundary the application rate begins adjusting, so the rate matches the target as soon as the machine enters the new zone. Compensates for applicator response lag.

Setting	Description
Look-Ahead Time (per product)	Seconds before entering a zone boundary that rate adjustment begins. One value per product (up to 5).
Auto Tune	RC monitors look-ahead performance and automatically adjusts the value to improve zone entry accuracy.

Files Tab

Import and manage supporting data files for the current field.

Control	Action
Import KML	Import a KML overlay file for the current field
Delete KML	Select and delete a KML file from the current field
Import Yield	Import a yield data CSV file. If the file contains elevation data, RC will offer to extract it to a separate elevation file.
Delete Yield	Remove the selected yield data file
Import Elevation	Import an elevation data CSV file (Lat, Lon, Elevation)
Restore Elevation	Restore the previous elevation file from the automatic backup
Delete Elevation	Remove the current elevation data file

Display Toggle Buttons (right panel)

These buttons highlight green when active. Click to toggle on or off.

Button	Action
Sat. View	Toggle satellite background image
Target Zones	Toggle rate zone boundaries display
Applied Rates	Toggle applied rate colour overlay
Yield Data	Toggle yield data overlay
Elev.	Toggle elevation data overlay
KML Files	Toggle KML file overlay

Bottom Controls

Button	Action
 Minimize	Shrink the map to a small window. Drag by title bar to reposition.
 Centre	Centre the map on the current GPS position
 Help	Open this help page
 OK	Close the Rate Map