

Machine – Switches

Menu: Machine > Switches

Configures how the master switch, auto switches, and on-screen virtual switches behave.

Master Switch Mode

Select one option. Controls what the master switch turns on and off.

Option	Description
Control All	Master switch controls the master relay and all section relays
Master Relay Only	Master switch controls only the master relay; sections are controlled independently
Master Override	Master is always on regardless of switch state

Switch Type

Select one option. Describes the physical type of master switch connected.

Option	Description
Momentary	Standard push-to-make switch. Each press toggles master on or off. Holding the switch in the on position activates Primed Start after the configured delay.
Maintained	Toggle or latching switch. Master follows the switch position directly — on when switch is on, off when switch is off. The on-screen master button has no effect when a physical switchbox is connected. Primed Start is not available in this mode.

Auto Switch

Setting	Description
Rate	Enables automatic rate control via the switchbox Auto Rate switch
Sections	Enables automatic section control via the switchbox Auto Section switch

Other Settings

Setting	Description
Work Switch	Uses a switch connected to the implement to gate master on/off. Master will only activate when the work switch is on.
On-Screen Switches – Enabled	Shows the virtual on-screen switch panel. See On-Screen Switches below.

On-Screen Switches

When enabled, a floating switch panel appears on screen. This panel is active only when no physical switchbox is connected.

Button	Function
MST	Toggles master on/off. Green = master on, red = master off.
PRM	Activates Primed Start immediately. Green while priming is active. Disabled when Maintained switch type is selected or when the vehicle is moving. Before pressing Prime, turn on the section buttons you want to prime — only sections that are switched on will run.
↑ / ↓	Rate adjustment. Hold to increase or decrease rate or PWM.
1 – 8	Section switches. Green = section on, grey = section off.
Auto Rate	Toggles automatic rate control. Green = auto rate on.
Auto Section	Toggles automatic section control. Green = auto section on.

Note: The on-screen switch panel is blocked when a physical switchbox is connected. Use the physical switchbox in that case.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings