# RateController User Manual

RateController (RC) is a Windows application for controlling the application rate of agricultural products (liquids, granules, seeds, ammonia) in conjunction with AgOpenGPS. It communicates with rate control modules via UDP/Ethernet to manage product application rates, boom sections, and tank quantities.

RC can also be used without AgOpenGPS. Automatic rate control based on ground speed will continue to work normally. Section control will be manual only.

---

## Table of Contents


1. Getting Started
2. Profiles
3. Jobs
4. Options – Speed Source, Display & Phone
5. Products – Rate
6. Products – Settings
7. Products – Mode
8. Products – Data Reset
9. Products – Monitoring
10. Products – Control (PID Tuning)
11. Machine – Calibrate
12. Machine – Sections
13. Machine – Relays
14. Machine – Switches
15. Machine – Pressure
16. Machine – Primed Start
17. Modules – Boards
18. Modules – Communication
19. Modules – Config
20. Modules – Pins
21. Modules – Relay Pins
22. Modules – Valves
23. Rate Map
24. Rate Graph
25. Scale / Tank Display
26. Language Selection
27. Color Customization
28. Help – Logs & Diagnostics
29. Tips & Tricks
30. Troubleshooting

↑ Contents

# 1. Getting Started

Before operating, complete these setup steps in order:

1. **Create or load a Profile** — a profile stores all machine settings (products, sections, relays, etc.)
2. **Connect the module** via Ethernet — go to **Modules > Communication**, set the subnet, and send it to the module
3. **Give the board its module** — go to **Modules > Boards**, select the **New** board, choose a module, Save, and accept the starting configuration for its type (see Setting Up a New Board)
4. **Configure the module** — go to **Modules > Config** to check the relay type and sensor count
5. **Configure pins** — go to **Modules > Pins** to verify or set sensor and PWM pin assignments
6. **Configure relay pins** — go to **Modules > Relay Pins** to assign physical pins to each relay
7. **Set valve mode** — go to **Modules > Valves** to select 2-wire or 3-wire valve control
8. **Define sections** — go to **Machine > Sections** and set section widths
9. **Configure relays** — go to **Machine > Relays** and assign relay types to sections
10. **Configure switches** — go to **Machine > Switches** to set master switch behavior
11. **Set up your product** — go to **Products > Rate** and enter product name, control type, units, and rates
12. **Assign the sensor** — go to **Products > Settings** to assign the module ID and sensor ID
13. **Calibrate** — go to **Machine > Calibrate** to determine the Cal Factor
14. **Create a Job** — go to **File > Jobs** to create a job for the field
15. **Connect AgOpenGPS** — the AOG status indicator should turn green

### Using Rate Control with AgOpenWeb

- Run RC and AgOpenWeb on the same PC, and close AgOpenGPS and AgIO.
- Open a field in AgOpenWeb. RC only gets speed and section states while a field is open.
- Section changes reach RC when you press Save in AgOpenWeb, or 10 seconds after your last edit.
- RC's switches control AgOpenWeb's sections, as they do with AgOpenGPS.

### Data Folder (File > Folders)

RC stores its data — profiles, jobs, fields, rate maps, and logs — in a data folder (Documents by default). Use **File > Folders** to move it, e.g. to a synced folder (OneDrive, Dropbox) or another drive.

| Control | Description |
|---|---|
| **Current location** | The data folder currently in use |
| **New location** | Press to browse for the new data folder; the chosen path can also be typed in the box |
| **Copy Data** | Copy the contents of the current data folder to the new location. Leave unchecked to simply switch to a folder that already contains RC data. |
| **Overwrite** | Allow copying into a folder that already contains files. Without this, Copy Data only copies into an empty folder. |

Press **OK** and confirm — RC changes the folder and restarts. The new location cannot be a sub-folder of the current data folder.

↑ Contents

## 2. Profiles

**Menu: File > Profiles**

A profile stores all machine configuration settings. Multiple profiles can be maintained for different implements.

| Button | Action |
|---|---|
| 1. New | Create a new profile |
| 2. Load | Load the selected profile |
| 3. Delete | Delete the selected profile. Default, and the last remaining editable profile, can not be deleted |
| 4. Copy | Copy the selected profile to a new name. The copy is always editable, even when copied from Default |
| 5. File name | Enter name for New or Copy |
| 6. Files | List of available profiles to select |
| 7. Page Up/Down | Scroll through the profile list |

### The Default Profile

Default is a read only reference profile. It holds a known good starting configuration and is never changed by the program, so it is always available to start over from. It can not be deleted.

Because it is read only, settings changed while Default is loaded are **not saved**. To warn you of this, the profile name at the top left of the menu is shown on a **red background** whenever a read only profile is loaded.

To start a new setup from the reference configuration, select **Default**, type a name, and press **Copy**. The copy is a normal editable profile and is loaded automatically.

> Because Default can not be saved to, the program always keeps one editable profile. On first run it makes one from Default and names it **Example**. Example is an ordinary profile — edit it, copy it, or delete it once you have a profile of your own. It is only rebuilt if no editable profile is left.

---

↑ Contents

## 3. Jobs

**Menu: File > Jobs**

Jobs track application activity per field. Each job stores application data, notes, and a rate map.

### Current Job

| Field | Description |
|---|---|
| Name | Job name |
| Date | Date/time of the job |
| Field | Select from list or type a new field name |
| Notes | Free-text notes for the job |

### Jobs List

The list shows each job's **Name**, **Date**, and **File**. Click a job to select it.

| Control | Action |
|---|---|
| Year | Year used by the filter |
| Field | Field used by the filter |
| Filter | When checked, only jobs matching the selected Year and Field are listed |
|  Field | Delete the selected field from the Fields list (not allowed while the field is in use) |
|  Load | Open the selected job |
|  New | Create a new job |
|  Copy | Copy selected job and its rate map to a new file |
|  Delete | Delete selected job |
| Show at Start-Up | Display the Jobs menu when the app launches |
|  Activity | Job report |
|  Import | Import jobs |
|  Export | Export all jobs to a chosen folder |

↑ Contents

# 4. Options – Speed Source, Display & Phone

**Menu: File > Options**

The page has two tabs. **Speed** selects the source of ground speed used for rate calculations and configures display units. **Phone** connects a phone to RateController's phone page (see Phone Tab below).

## Speed Source

| Option | Description |
|---|---|
| **GPS** | Use speed from AgOpenGPS |
| **Simulated Speed** | Simulate a constant speed (useful for testing) |
| **Wheel Sensor** | Use a speed sensor connected to a module GPIO pin |

## Wheel Sensor Setup

1. Enter the **Module ID** and **GPIO pin** used for speed sensing.
2. Enter the calibration number in **pulses per mile** or **pulses per kilometer**.
3. Press the **up arrow** to send configuration to the module (also sent on Save).
4. Use the **Calibration screen** to calculate the calibration number if unknown.

## Display Options

| Option | Description |
|---|---|
| **Metric** | Toggle between metric (km, ha, L) and imperial (mi, ac, gal) units |
| **Compact Display** | When on, the arrow on the main screen collapses it to just the rates instead of minimizing it to the small restore window. Tap the collapsed display to expand it again. |

The rate display window is no longer switched on here. Each product now has its own **Popup Display** button on Products > Settings, so a separate window can be shown for each product.

## Phone Tab

RateController has a built-in page for a phone's web browser, so the switches and calibration can be used away from the tablet: walking the boom to check nozzles, or standing at the meter with a catch bag. It is always available; there is nothing to install on the phone and nothing to switch on in RateController.

### Connecting a Phone

1. Put the phone and the tablet on the **same network**. Any of these works:
    - **The phone's hotspot**: connect the tablet to it.
    - **A WiFi router** (Starlink, a cellular router or any other): connect both to its main network.
    - **The tablet's own hotspot**: choose **Tablet Hotspot** on Modules > Communication > WiFi and press Save, then connect the phone using the network name and password shown on this tab.

2. **Phone hotspot or router only:** once the tablet is connected, tap **WiFi settings**, tap the network and set it to **Private**. Windows blocks the phone page on a Public network. Do this again for a new phone or after renaming the phone's hotspot, because Windows treats it as a new network.
3. Scan the code with the phone's camera to open the page. Adding it to the phone's home screen makes it quicker next time.

### Phone Tab Controls

| Control | Description |
|---|---|
| **QR code** | Opens the phone page when scanned. When the tablet is on more than one network, tap the code to show the next address. It updates by itself when a network is joined or left. |
| **Address** | The same address as text, for typing into the phone's browser. "(1 of 3, tap for next)" shows when there are several. |
| **Tablet Hotspot** | The hotspot's state: On, Off, Checking..., *On, firewall not allowed* or *Off, restarts failed*. The hotspot is switched on and off on Modules > Communication > WiFi; the **Comm → WiFi** link opens that page. |
| **Network / Password** | The tablet hotspot's network name and password, for joining it from the phone, or Windows' reason when the hotspot can't start. |
| **WiFi settings** | Opens the Windows WiFi page, for setting a network to Private. |

### Tablet Hotspot

Set on Modules > Communication > WiFi. The same hotspot carries both the phone and any ESP32 modules joined to it.

- The first time Tablet Hotspot is saved, Windows asks for **administrator permission** to let the phone page through the firewall. This is needed once per tablet. If it's declined, the phone can join the hotspot but the page won't open, and the status shows *On, firewall not allowed*. On a standard Windows account the prompt asks for an administrator's password.
- The tablet's hotspot address is always **192.168.137.1**, so a bookmark or home-screen link on the phone keeps working.
- If the hotspot turns off, RateController turns it back on within about 30 seconds, up to 3 times. After that the status shows *Off, restarts failed*. To try again, choose Current WiFi Network on Comm → WiFi and Save, then Tablet Hotspot and Save, or restart RateController.
- Windows' **Power saving** turns the hotspot off when no device has been connected for 5 minutes. If necessary, turn it off in Windows' **Hotspot settings** (linked from Comm → WiFi). RateController can't change this setting.
- Windows shares the tablet's internet connection through the hotspot. If the tablet connects to a router by WiFi as well, its WiFi adapter must be able to do both at once; not all adapters can.

### Router Tips

- Use the router's main network, not a guest network, and make sure **AP isolation / client isolation** is off. Either one stops the phone from reaching the tablet.
- A **DHCP reservation** for the tablet in the router keeps its address the same, so the phone's bookmark keeps working.
- The phone has to stay within the router's WiFi range at the boom.

### Phone Page

The phone opens a menu titled **RateController** with two buttons: **Switches**, a copy of the on-screen switch panel (see Phone Switches in §14), and **Calibration**, product calibration (see Calibrating from a Phone in §11). Each page has a **Menu** button at the bottom to go back. The page uses the tablet's display colours.

> **Note:** The phone page has no password. Anyone on the same network can open it, so use your own hotspot or network.

---

↑ Contents

# 5. Products – Rate

**Menu: Products > Rate**

Configures the fundamental properties of a product.

| Setting | Description |
|---|---|
| **1. Product Name** | Name of the product |
| **2. Control Type** | How the application rate is controlled (see below) |
| **3. Quantity Units** | Units used to measure the product (L, gal, kg, lbs, seeds, etc.) |
| **4. Coverage Units** | Acre, Hectare, Minute, or Hour |
| **5. Sensor Counts/Unit** | Number of sensor pulses per unit of product applied |
| **6. Density** | Product density (used for mass/volume conversion) |
| **7. Base Rate** | Target application rate |
| **8. Alt. Rate (%)** | Alternate rate as a percentage of the base rate |
| **9. Tank Size** | Total tank capacity |

## Control Types

Selects the actuator driving the product and how the PID loop positions it. This must match the physical valve/motor wiring on the module — an incorrect selection can leave the actuator open or unresponsive.

| Type | Description |
|---|---|
| **Standard Valve** | A proportional flow-control valve driven continuously by the PID loop — includes a motorized ball valve or a solenoid valve. PWM = 0 stops the valve motor and holds its last position (does not drive it closed) — use this for valves with no dedicated closed/shutoff position. |
| **Combo Close** | Same continuous PID control as Standard Valve — includes a motorized ball valve or a solenoid valve — but the valve is also driven fully closed whenever the product/section is off (rather than just holding position). Use for valves that must shut off flow, not just stop adjusting. |
| **Motor** | Drives a variable-speed motor that IS the metering device itself (e.g. a hydraulic or electric drive motor turning a metering roller/auger/pump) — not a motorized valve. PID output accumulates over time (integrating control) instead of positioning directly, so it needs different gain tuning than a valve. |
| **Combo Timed** | For close-only/on-off style valves that can't be positioned proportionally. Instead of continuous PWM, the valve is pulsed through alternating Adjust/Pause cycles (set on the Control page) to work the rate toward target, with a fast minimum-start ramp from zero. |

## Fans

The last two products in the list are fans, named Fan 1 and Fan 2. Selecting one replaces the product settings with the fan settings, because a fan is controlled to a speed rather than to an application rate.

| Setting | Description |
| --- | --- |
| **Sensor Counts / RPM** | Number of sensor pulses per revolution |
| **Target RPM** | The speed the fan is controlled to |
| **Current RPM** | Measured fan speed (read-only) |
| **Error %** | How far the measured speed sits from the target, as a percentage (read-only) |

To put a fan's speed in its own floating window, use **Popup Display** on Products > Settings (see Popup Display Window). The same button serves every product, so a fan window and a product rate window work the same way.

---

↑ Contents

# 6. Products – Settings

**Menu: Products > Settings**

Configures sensor assignment, alarm thresholds, and display preferences per product.

| Setting | Description |
|---|---|
| **1. Enable product** | Activate this product |
| **2. Rate Sensor Location** | Module ID (0–7) and Sensor ID (0–1) for the flow sensor |
| **3. Minimum UPM** | Minimum flow rate the controller will maintain. Enter either a fixed **UPM** value or a **By Speed** value (MPH/KPH) — the hint below the boxes shows the equivalent value the other way (e.g. the speed that corresponds to the entered UPM). |
| **4. Off-Rate Alarm** | % error in rate that triggers an alarm |
| **5. Default Product** | Product displayed at startup |
| **6. Scale Weight** | Show the scale weight screen |
| **7. Popup Display** | Open a floating window showing this product's rate — or this fan's speed (see below) |

### Popup Display Window

**Popup Display** opens a small floating window with the live value for that product: the applied rate, or the speed if the product is one of the two fans. Press Save to apply it. Every product has its own button and its own window, so several can be on screen at once; each window is labelled with the product it belongs to. The windows have no title bar and use the display colours set under Options.

**Click and drag** a window (either mouse button) to reposition it. Where it is dropped decides what it follows. Dropped overlapping the main screen it follows the main screen. Dropped overlapping another floating window — another popup display, the pressure display, or the on-screen switch panel — it follows that window instead, so a group of windows can be built up and moved together. If it overlaps both, the main screen wins. Dropped clear of everything it follows nothing until it is dropped onto something again.

A window detaches while the main screen is minimized and re-attaches when the main screen is restored. If the window it was following is closed, it stays where it is and simply stops following. Each window's position is remembered separately between sessions.

A product that is not enabled has no display window, whatever this button is set to, and enabling the product again brings its window back.

## Controls

| Control | Action |
| --- | --- |
| Navigate left | Previous product |
| Navigate right | Next product |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

# 7. Products – Mode

**Menu: Products > Mode**

Sets the operating mode for each product. Navigate between products with the left/right arrows.

| Mode | Description |
|---|---|
| **Controlled UPM** | PID feedback control — adjusts motor/valve to maintain the target rate as speed changes |
| **Constant UPM** | Maintains a fixed flow rate based on total machine width regardless of which sections are on. Used for sprayers where turned-off sections return flow to the tank (after the flow meter). RC corrects the measured flow by subtracting the estimated contribution of the off sections to give an accurate application rate per acre/hectare. |
| **Document Applied** | Tracks and records material that has already been applied — no active control |
| **Document Target** | Tracks and records the target rate for comparison — no active control |
| **Document Applied Manual Rate** | For implements with a fixed mechanical/manual metering that has no flow sensor or module at all (e.g. a fertilizer spreader gate set to a position). Enter the implement's flow output with all sections on, in units per minute, in the Manual Rate box; RC computes the displayed/logged application rate from that fixed value and ground speed, and scales the flow down when sections are switched off — no active control, no module. |

**Manual Rate** (enabled only when Document Applied Manual Rate is selected): enter the implement's measured output in units per minute, **not** per acre/hectare — typically found by running the implement at its set position and weighing or measuring output over a timed interval. Because the value is a constant flow, the displayed/logged rate per acre/hectare will rise and fall with ground speed even though the implement setting hasn't changed — this is expected for fixed-metering implements.

Enter the output of the **whole machine with every section running** — on an implement with more than one dispenser (two gates, two spinners, and so on) that is their combined output, not one dispenser's. When a section is switched off RC lowers the reported flow by that section's share of the implement width, so with two equal dispensers and one shut off the flow halves; the ground being covered halves at the same time, so the rate per acre/hectare correctly stays where it was.

This requires **one section per dispenser**, with each section's width set to the ground that dispenser actually covers. There is no flow sensor in this mode, so RC cannot detect real flow — it can only assume a section switched off stops that section's share of the material. Fewer sections than dispensers makes applied totals read high; more sections than dispensers makes them read low (and the machine genuinely over-applies, since the dispenser keeps running and simply overlaps). A reminder appears each time the Manual Rate value is entered. A single-dispenser machine needs nothing special.

## Controls

| Control | Action |
| --- | --- |
| Navigate left | Previous product |
| Navigate right | Next product |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

## 8. Products – Data Reset

**Menu: Products > Data**

Displays accumulated totals for the selected product and allows resetting individual counters. Navigate between products with the left/right arrows.

| Counter | Description |
|---|---|
| **Coverage Area 1** | Total area covered (primary counter) |
| **Coverage Area 2** | Total area covered (secondary counter) |
| **Quantity Applied 1** | Total product applied (primary counter) |
| **Quantity Applied 2** | Total product applied (secondary counter) |
| **Hours 1** | Operating hours (primary counter) |
| **Hours 2** | Operating hours (secondary counter) |

Press the reset button next to any counter to zero it. Both counters are independent, allowing a session total and a season total to be tracked simultaneously.

### Controls

| Control | Action |
|---|---|
| Navigate left | Previous product |
| Navigate right | Next product |
| Reset counter | Zero the selected counter |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

## 9. Products – Monitoring

**Menu: Products > Monitoring**

Displays real-time diagnostic data for the selected product. Navigate between products with the left/right arrows.

### Rate Information

| Display | Description |
|---|---|
| **Target UPM** | The current setpoint (desired flow rate) |
| **Applied UPM** | The measured actual flow rate |
| **Rate Error %** | Difference between target and actual, with sign |
| **PWM** | Current PWM output value (0–255) |
| **Frequency (Hz)** | Flow sensor pulse frequency |

### Speed & Coverage Information

| Display | Description |
|---|---|
| **Ground Speed** | Current speed in MPH or KPH |
| **Working Width** | Implement working width in feet or meters |
| **Work Rate** | Area covered per hour (ac/hr or ha/hr) |

### Section Status

Shows 16 section indicator boxes — green for On, red for Off.

### Module Communication

| Display | Description |
|---|---|
| **WiFi / Signal** | Module signal strength (RSSI) bar |
| **Counts per Revolution** | The number of pulses the sensor produces per revolution. Total pulses per minute are divided by this value to calculate RPM. For example, a value of 3 means every 3 pulses equals one revolution. |

### Controls

| Control | Action |
|---|---|
| Navigate left | Previous product |
| Navigate right | Next product |
| Cancel | Discard changes |
| Save | Save settings |

↑ Contents

# 10. Products – Control (PID Tuning)

**Menu: Products > Control**

Configures the PID controller that adjusts the motor or valve to maintain the target rate.

## Primary Settings

| Setting | Description |
|---|---|
| **1. Gain** | Rate adjustment factor — how strongly the controller responds to rate errors. The effect is linear: doubling Gain doubles the correction. Errors are measured as a percentage of the target rate, so the same Gain setting behaves consistently at low and high rates. |
| **2. Integral** | Trims residual error once the rate is close to target (inside the BrakePoint band — see below). Far from target, only Gain (proportional) drives the approach; Integral does not speed that up. Increase if the rate settles near, but not exactly on, target. Integral accumulates once per PID loop tick, so a shorter PID loop time (setting 4 below) also makes it trim faster in real time, independent of this setting. |
| **3. Max Power** | Maximum PWM power delivered to motor or valve |
| **4. Min Power** | Minimum PWM power delivered to motor or valve |

## Adjustment Process

1. **Initial Setup** — Set minimum power to the minimum needed to move the motor/valve. Set maximum power to 100. Set Integral to 0.
2. **Gain Adjustment** — Slowly increase gain until the system overshoots the target, then reduce slightly to stabilize.
3. **Integral** — If the rate approaches target but settles slightly off, increase Integral to close the remaining gap. It only acts once you're already close (see BrakePoint) — it will not speed up a slow ramp toward target.

## Optional / Advanced Settings

Settings 7–9 apply to the Combo Timed control type only; setting 5 applies to Motor only.

| Setting | Description |
|---|---|
| **1. Deadband** | Error % below which no adjustment is made. Also controls when accumulated Integral is reset — only once the error clearly crosses to the other side of target, not on small wobble near the setpoint. |
| **2. BrakePoint** | Error % (of peak target) defining the "near target" band. Outside this band, only fast proportional (Gain) control acts and Integral stays at zero. Inside it, proportional gain drops to the Slow Adjustment % and Integral begins accumulating. |
| **3. Slow Adjustment** | % of full proportional adjustment used once inside the BrakePoint band |
| **4. PID loop time** | How often (50–250 ms) the PID recalculates its output. A shorter time makes the valve/motor react sooner to a real rate change, and also speeds up Integral trimming in real time (see Integral, above) since it accumulates once per tick. Reducing this after Gain/Integral were tuned at a slower rate can introduce new oscillation — check for overshoot as with any Gain increase. |
| **5. Slew Rate** | Motor control type only — maximum total PWM change per PID loop. Has no effect on Standard/Combo Close valves, which are positioned fresh each loop rather than ramped. |
| **6. Max Integral change** | Maximum Integral PWM change per PID loop. The total accumulated Integral is separately capped to the Max Power − Min Power range, so it can reach full authority (e.g. to free a stuck valve) without jumping there in one loop. |
| **7. Min Start %** | Combo Timed control type only — % of target rate below which the adjust/pause cycle is skipped for a faster start from 0. |
| **8. Adjust time** | Combo Timed control type only — milliseconds the valve is actively adjusted during each cycle. |
| **9. Pause time** | Combo Timed control type only — milliseconds the valve pauses (holds) between adjustments. |
| **10. Min flow sensor Hz** | Pulse frequency below which the sensor is treated as stopped/no-flow |
| **11. Max flow sensor Hz** | Pulse frequency above which pulses are rejected as sensor noise/bounce |
| **12. Flow sample time (Smp Tm)** | Time window in milliseconds (50–1500) used to calculate the median flow reading. A longer window smooths the reading; a shorter window responds faster. Default 400 ms. |

## Controls

| Control | Action |
|---|---|
| Navigate left | Previous product |
| Navigate right | Next product |
| Load defaults | Restore default PID values |
| Open rate graph | Display the rate graph |
| Gain/Integral/Power + | Increase the selected value |
| Gain/Integral/Power - | Decrease the selected value |
| Show advanced settings | Expand the advanced/optional settings panel |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

# 11. Machine – Calibrate

**Menu: Machine > Calibrate**

Use this screen to determine the **Cal Factor** (pulses per unit) for a product. The goal is to achieve a consistent meter roller RPM or liquid flow rate matching typical field operation.

### Step-by-Step Calibration

#### ① Step 1 — Set Ground Speed

- Enter the ground speed you typically operate at.

#### ② Step 2 — Set Meter Roller RPM / Valve Position

- Switch the product **ON** using the power button.
- Enter an **Initial Base Rate** and an **Estimated Cal Factor**. The Base Rate becomes the product's working rate when Save is pressed.
- Press **Start** — RC adjusts flow to match the target rate.
- If successful, RPM is locked.
- The PWM value used is shown in the **PWM** box (for motor controllers). While locked and stopped it can be edited — accept the value RC found, or enter your own (0–255).
- RC stops automatically when the target rate is met.

*If RC fails to reach target RPM:*

- Press **Stop**.
- Check ground speed.
- Adjust the estimated Cal Factor, PWM min/max, or metering drive range.

#### ③ Step 3 — Set Actual Cal Factor

- Press **Start** to run the meter roller and collect a sample.
- Press **Stop**, then enter the measured amount collected.
- RC calculates and displays the new Cal Factor.
- Press **Save** to record it.

#### ④ Step 4 — Optional Adjustments

- To redo meter speed: press **Unlock**, then repeat Step 2.
- To reuse a previously saved setting: press **Lock**, then proceed to Step 3.
- To skip Step 2 entirely (motor controllers): press **Lock**, enter the desired **PWM** directly, then proceed to Step 3. Useful for iterating on the metering-unit opening at a fixed PWM — run, weigh, adjust the opening, repeat.
- The lock is saved with Save and remembered the next time the product is calibrated, so Step 3 can be repeated without redoing Step 2.

### Calibrating from a Phone

The **Calibration** page on the phone runs the same calibration as this screen, so Start, Stop and the measured amount can be entered standing at the meter or the catch container. To connect a phone, see Options – Phone Tab.

- The page has the product buttons 1–5 (lit when that product's power is on), **Power**, the lock (shown as **Meter set** / **Meter not set**), **Start** / **Stop**, the live Pulses and Hz, and the Speed, Base Rate, Meter Cal, Expected, Measured and PWM boxes, with **Save** / **Cancel**.
- Tap a box to enter a value. The old value is shown faded; tapping away without typing keeps it.
- The tablet and the phone show the same calibration, and either can start or stop it. The tablet screen follows a run started from the phone.
- **A run started from the phone stops by itself** if the phone loses its connection, or its screen is locked or switched to another app, for about 5 seconds. The page then shows *Last run stopped: phone connection lost*.
- **A run started on the tablet does not stop by itself.** Start from the phone if you will be away from the tablet. Stop works from either.
- Closing the tablet's Calibrate screen stops a run started on the tablet; a run started from the phone keeps going.

### Important Notes

- AgOpenGPS is **not** used during calibration.
- The Switchbox is **not** used during calibration.
- If a switchbox is present, ensure the **master switch is OFF** before calibrating.
- Calibration uses **Constant UPM, Mode 2**.
- All sections on the calibrating module are activated during calibration; modules that are not calibrating are unaffected.
- More than one product can be calibrated at the same time, on the same or different modules (requires up-to-date module firmware).
- After calibration, the original mode and section states are restored.
- If RateController closes during a calibration (power loss, a crash, or ended in Task Manager), the product's original settings and the speed source are restored at the next start, with the message *Product N restored after an interrupted calibration*. A calibration that wasn't saved has to be repeated.
- Start is refused if a locked motor product has PWM 0 — enter a PWM value first, or the motor would not turn.
- Watch the **Hz** display while running: aim for at least 10–12 Hz at working rate for a stable reading. Very high frequencies can exceed the sensor's switching limit — if Hz plateaus while speed rises, the sensor is at its ceiling.

## Controls

| Control | Action |
|---|---|
| Start | Start the meter roller / begin collecting a sample |
| Stop | Stop the meter roller |
| Lock/Unlock | Lock or unlock the current RPM setting. Shown on the phone as Meter set / Meter not set. Saved with Save |
| Power on/off | Switch the product on or off |
| Cancel | Discard changes |
| Save | Save the calculated Cal Factor |
| PWM | PWM used while locked (motor controllers only). Editable when locked and stopped; press Save to keep the value |
| Hz | Live sensor pulse frequency for the selected product (shown for all control types) |

---

↑ Contents

## 12. Machine – Sections

**Menu: Machine > Sections**

Defines the boom sections and their widths.

- There are **16 sections per module** and up to **8 modules**.
- Module 0 = sections 1–16
- Module 1 = sections 17–32, etc.
- Sections can be defined **individually** or grouped into **zones**.
- All sections in a zone share the same width.
- All sections in a zone are controlled by one switch.
- AgOpenGPS can still auto-control each section individually within a zone.
- When creating a new profile, sections must be defined.
- Sections are also automatically redefined when AgOpenGPS section count changes.

| Control | Action |
|---|---|
| Copy Button | Copies the width from Section 1 to all other sections |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

## 13. Machine – Relays

**Menu: Machine > Relays**

Assigns relay functions to each relay output on the module. There are **16 relays per module** and up to **8 modules**.

| Control | Action |
|---|---|
| **Reset (circle)** | Reset all relays to default |
| **Renumber (+)** | Renumber sections sequentially |
| **Relay Number** | The relay output number |
| **Relay Type** | The behavior of the relay (see below) |
| **Number** | For Switch type: switch number. For Section/Invert_Section type: section number. |
| Cancel | Discard changes |
| Save | Save settings |

### Application Control

Spraying occurs when:

- Master is ON
- A section is enabled
- In Auto, the guidance system allows application

## Relay Types

| Type | Description |
|---|---|
| **Section** | Controls an individual section.<br>In Manual, the switch turns the section on or off.<br>In Auto, the guidance system controls the section, but the switch can disable it. |
| **FlowMaster** | Controls overall product flow.<br>In Manual, it follows the Master switch.<br>In Auto, it is on only when the Master switch is on and the machine is moving.<br>Use this to control overall product flow through an upstream valve or common shutoff. |
| **Invert_FlowMaster** | Opposite of the FlowMaster output — on when the master switch is off or (in Auto) the machine is stopped. Intended for valve wiring that requires an inverted signal, not as a bypass for section activity. Use **Bypass** if you need a relay that responds to whether sections are actually on. |
| **Bypass** | On when all sections are off; off when any section is on. Use this for a return or bypass valve that diverts product when no boom sections are applying. |
| **Master** | Follows the Master switch.<br>Use this when a relay should follow the master logic itself rather than actual flow-enabled status. |
| **Invert_Master** | Opposite of the Master output (on when the Master output is off). |
| **Slave** | On when any section is on; off when all sections are off. |
| **Invert_Section** | Opposite of the Section output (on when the section is off). |
| **Power** | Always on. |
| **Switch** | Controlled directly by a switch (not affected by Master or Auto). |
| **Hyd Up** | Hydraulic raise. |
| **Hyd Down** | Hydraulic lower. |
| **Tram Right** | Tram marker right. |
| **Tram Left** | Tram marker left. |
| **Geo Stop** | Geofence stop output. |
| **None** | No function assigned to the relay. |


## FlowMaster Valve Options

These options apply only when exactly one **FlowMaster** relay is defined on the selected module.


| Option | Description |
|---|---|
| **2-wire valve (single relay powers open and close)** | One **FlowMaster** relay drives both open and close directions using the module's H-bridge output. Requires module support (e.g. RC15). |
| **2-wire valve (2 relays: FlowMaster powers open, Invert_FlowMaster powers close)** | Two relay outputs: the **FlowMaster** relay supplies power to open the valve; the **Invert_FlowMaster** relay supplies power to close it. Use this on modules without H-bridge support (e.g. RC11-2). |
| **3-wire valve (relay signal, valve self-powered)** | One **FlowMaster** relay provides a signal. The valve uses its own power supply to open or close based on that signal. |

## Valve Wiring Reference

The diagrams below show the wiring difference between 2-wire and 3-wire valves.




**2-wire valve**




**3-wire valve**

---

↑ Contents

## 14. Machine – Switches

**Menu: Machine > Switches**

Configures how the master switch, auto switches, and on-screen virtual switches behave.

### Master Switch Mode

Select one option. Controls what the master switch turns on and off.

| Option | Description |
|---|---|
| **Standard** | Master switch controls the master relay and all section relays. When master turns off, all section relays turn off. When master turns back on, section relays resume their switch positions. |
| **Master Override** | Forces the module to treat master as always on, regardless of switch state. Useful for motor control when the master switch should not interrupt the motor PID loop. |

### Switch Type

Select one option. Describes the physical type of master switch connected.

| Option | Description |
|---|---|
| **Momentary** | Standard push-to-make switch. Each press toggles master on or off. Holding in the On position activates Primed Start after the configured delay. |
| **Maintained** | Toggle or latching switch. Master follows the switch position directly — on when switch is on, off when switch is off. Primed Start is not available in this mode. |

### Other Settings

| Setting | Description |
|---|---|
| **Work Switch** | Uses a switch connected to the implement to gate master on/off. The switch's pin, momentary behavior and NO/NC invert are set per module under Modules > Pins. |
| **Auto Switch – Rate** | Enables automatic rate control via the switchbox Auto Rate switch |
| **Auto Switch – Sections** | Enables automatic section control via the switchbox Auto Section switch |
| **On-Screen Switches – Enabled** | Shows the virtual on-screen switch panel (see below) |
| **On-Screen Switches – Rate Only** | Shrinks the panel to just the rate up/down buttons. Master, PRM, the section switches and Auto Rate/Section are hidden, and the switch count is not used. |
| **On-Screen Switches – 4 / 8 / 12 / 16** | Number of section switches shown on the on-screen switch panel. Not available when Rate Only is selected. |

### On-Screen Switch Panel

When enabled, a floating switch panel appears on screen. Its buttons always show the switch states in use. With no physical switchbox connected, the panel is the switchbox. With a switchbox connected the panel still works — see With a Switchbox Connected below.

| Button | Function |
|---|---|
| **MST** | Toggles master on/off. Green = on, unlit = off. |
| **PRM** | Activates Primed Start immediately. Green while priming is active. Dimmed when Maintained switch type is selected or when the vehicle is moving. |
| **▲ / ▼** | Rate adjustment. Hold to increase or decrease rate or PWM. |
| **1 – 16** | Section switches (4, 8, 12, or 16 buttons, as configured). Green = on, unlit = off. |
| **Auto Rate** | Toggles automatic rate control. |
| **Auto Section** | Toggles automatic section control. |

The panel has no title bar and uses the display colours set under Options. To reposition it, drag the panel background (the gaps between the buttons) with either mouse button, or **right-click and drag** on a button. A left click on a button always presses it. Where it is dropped decides what it follows. Dropped overlapping the main screen it follows the main screen. Dropped overlapping another floating window — a product popup display or the pressure display — it follows that window instead, so a group of windows can be moved together. If it overlaps both, the main screen wins. Drop it clear of everything to unlatch it. With **Rate Only** checked the panel shrinks to a small window holding just the ▲ / ▼ buttons.

> **Note:** Before pressing PRM, turn on the section switches you want to prime. Only sections that are currently switched on will run during priming. Partial priming (some sections only) is valid.

#### With a Switchbox Connected

- **Taking control:** the first on-screen press takes control from the switchbox. It starts from the current switch positions, so only the button pressed changes.
- **The switchbox always wins:** moving any switch on the switchbox (master, sections, rate or auto) hands control back straight away and the switchbox positions apply again. The work switch doesn't count.
- **No timeout:** the screen keeps control until a switchbox switch is moved. Unlike the phone, there is no 120 second timeout.
- **▲ / ▼:** change the rate while held and stop when released.
- **Main screen MST and Auto:** work the same way. With no switchbox, MST on from the main screen also turns all enabled sections on. With a switchbox connected it only turns master on — the sections stay as they are.

#### Plugging In or Unplugging the Switchbox

Neither changes any switch positions. About 3 seconds after the switchbox stops communicating, the on-screen panel carries on from the positions in use, including a maintained master that is on. When the switchbox is plugged back in, those positions are held until a switch on the switchbox is moved, and then the switchbox takes over. The exception is the first switchbox after the app starts: its switch positions apply straight away.

### Phone Switches

The **Switches** page on the phone is a copy of the on-screen switch panel: MST, PRM, ▲, ▼, the section switches, Auto Rate and Auto Section, in the tablet's display colours. It shows the full panel even when the tablet uses Rate Only. Like the on-screen panel, it works with a physical switchbox connected. To connect a phone, see Options – Phone Tab.

- **Taking control:** the first press on the phone takes control from the cab. It starts from the current switch positions, so nothing changes until a button is pressed. The status line shows *Remote in control* and the seconds left.
- **The cab always wins:** moving any switch on the switchbox (master, sections, rate or auto) hands control back straight away and the switch positions apply again. The work switch doesn't count. With no switchbox connected, a press on the on-screen panel does the same. The phone shows *Cab switchbox took control*.
- **Sharing with the on-screen panel:** with a switchbox connected, on-screen presses don't end the phone's control — the phone and the screen share it until a switchbox switch is moved. While only the screen has control, the phone shows *Cab in control*.
- **Timeout:** after 120 seconds with no press on the phone or the on-screen panel, control goes back to the cab and **master turns off** (*Timed out, master off*). A maintained master switch stays off until it is switched off and on again.
- **Auto Section:** can be turned off from the phone, for when auto was left on in the cab. While it is on and AgOpenGPS is connected, AgOpenGPS controls the sections and the page shows a warning.
- **▲ / ▼:** change the rate while held. If the phone loses its connection while a button is held, the change stops within about a second.
- **PRM:** works as on the tablet: master on and prime, only with a momentary master switch and the machine stopped. When priming ends without Resume After Prime, master turns off and the sections stay as set on the phone.

### Controls

| Control | Action |
|---|---|
| ⊗ Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

# 15. Machine – Pressure

**Menu: Machine > Pressure**

Calibrates a pressure sensor using two known reference points, and sets a maximum pressure limit per module.

## Calibration Procedure

1. Select the **Module** the pressure sensor is connected to.
2. Set the system to a **known low pressure**.
3. Enter the sensor **reading** and the actual **pressure** value.
4. Set the system to a **known high pressure**.
5. Enter the sensor **reading** and the actual **pressure** value.
6. Enter the **minimum sensor reading** that corresponds to 0 pressure.
7. Press **Show** to display the live pressure screen.

## Pressure Display Window

**Show** opens a floating window with the live pressure for the current product's module. It has no title bar and uses the display colours set under Options.

**Click and drag** the window (either mouse button) to reposition it. Where it is dropped decides what it follows. Dropped overlapping the main screen it follows the main screen. Dropped overlapping another floating window — a product popup display or the on-screen switch panel — it follows that window instead, so a group of windows can be moved together. If it overlaps both, the main screen wins. Dropped clear of everything it follows nothing until it is dropped onto something again.

The window detaches while the main screen is minimized and re-attaches when the main screen is restored. If the window it was following is closed, it stays where it is and simply stops following. Its position is remembered between sessions.

## Max Pressure

Sets the maximum allowed pressure for the selected module. When the measured pressure exceeds this value:

- The application shows a **High Pressure** alarm.
- The limit is also sent to the module, which reduces flow on its own to bring the pressure back below the limit — this protects the system even if communication with the PC is lost. Requires up-to-date module firmware.

If the pressure limit trips repeatedly in a short time, the module treats it as a fault and keeps reducing flow until the **master switch is turned off**, which resets the protection.

Set Max Pressure to **0** to disable the limit.

## Controls

| Control | Action |
| --- | --- |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

# 16. Machine – Primed Start

**Menu: Machine > Primed Start**

Allows boom priming or a simulated product application while the tractor is stopped. The tractor must not be moving for primed start to activate.

| Setting | Description |
|---|---|
| **On Time** | How long the application runs (seconds) |
| **Speed** | Simulated ground speed used to calculate application rate during priming |
| **Master Switch Delay** | How long to hold the physical master switch in the On position to trigger primed start (seconds). Applies to momentary switchbox only. |
| **Resume** | After On Time expires, if the tractor is moving, continue with normal operation |

## Activating Primed Start

### Physical Switchbox — Momentary Switch

Hold the master switch in the **On** position for the duration of the **Master Switch Delay**. Primed start activates automatically once the delay expires.

### On-Screen Switch Panel

Press the **PRM** button. Primed start activates immediately — no hold required. The PRM button turns green while priming is active.

Before pressing PRM, turn on the section switches you want to prime. Only sections that are currently switched on will run during priming.

### Cancelling

Press the master switch Off, or press the on-screen **MST** button while master is on. Primed start stops immediately.

> **Note:** Primed Start is not available when **Maintained** switch type is selected in Machine > Switches.

## Controls

| Control | Action |
|---|---|
| ⊗ Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

# 17. Modules – Boards

**Menu: Modules > Boards**

Lists every board RateController can hear, and is where a board is given its module number and description. Each board is known by its built-in hardware (MAC) number, so boards are told apart even when they are the same type or share a module number. The list updates every second.

### Board List

| Column | Description |
|---|---|
| **Module** | The board's module number, 0–7, or **New** for a board that has no module yet. |
| **Board** | The board type, the last part of its MAC number, and its description, e.g. *ESP Rate ...0B:B0:12 Left Tank*. |
| **State** | **Connected** — the board is reporting.<br>**Duplicate** — two or more boards are on the same module. Each is listed on its own row. Move one of them to a free module.<br>**Update firmware** — a board on this module has firmware too old for this version of RateController. The module is not used until the firmware is updated.<br>**New** — a new or blank board waiting for a module. New boards are listed last.<br>**→ 3, not sent** or **Not sent** — a saved change that goes out with the next Send. |

### Settings

Select a board in the list to change it.

| Setting | Description |
|---|---|
| **Module** | The module the board serves. The list holds the board's own module and the free modules only: a module that already has a board, including one that needs a firmware update, is not offered. |
| **Description** | A name for the board, up to 16 characters, e.g. "Left Tank". It is stored on the board and kept through firmware updates. The box can't be used for a Nano (it stores no description), for a board on a duplicate module, or for a new board until a module is chosen. |
| **Web page link** | For an ESP32 on WiFi, the address of its web page. Click it to open the page. An ESP32 on Ethernet shows *Ethernet, no web page*. |

### Setting Up a New Board

New and blank boards start without a module (ID 25). While one is reporting, the **Boards** button on the menu has an orange border.

1. Connect the board to the same network as RateController. An ESP32 on WiFi is set up from Modules > Communication > WiFi instead, which gives it its module at the same time.
2. Open **Modules > Boards** and select the board marked **New**.
3. Choose a free **Module**, add a **Description** if you like, and press **Save**. The module pages switch to the chosen module.
4. RateController offers the starting configuration for the board's type (Nano, Teensy or ESP32). Press **OK** to load it, then check the Config, Pins, Relay Pins and Valves pages against your own board.

5. Press **Send** ⬆ . The board takes its module number and settings, restarts, and reconnects as that module.

### Moving a Board or Changing its Description

1. Select the board, choose the new **Module** and/or type a new **Description**, and press **Save**. The State column shows the change as *not sent*. A module change also moves the module pages to the new module, whose settings will be sent to the board.
2. Press **Send**. The board restarts on its new module with that module's settings.

- Only one module change can wait for Send at a time. Descriptions can be saved for any number of boards.
- To undo a saved module change, select the board's own module again and press Save. The module pages go back to the board's module.
- Another board can't be selected while the current one has unsaved edits. Press Save or Cancel first.

### When Send is Refused

Send does not go out, and a message says why, when:

- the board being moved has stopped reporting, or another board has appeared on its new module;
- the module being edited has no board connected, or its board needs a firmware update;
- a module page has unsaved changes after a module change ("*Save or cancel the pending changes first.*"). Save or cancel them and press Send again.

Except for the last case, saved module changes and descriptions are dropped when Send is refused, so they can't go out later by surprise. Save them again when the board is ready.

> **Note:** A Nano has no description. It is shown by its MAC number.

> **Note:** A board that is switched off isn't seen, so its module looks free. Make sure every board is powered before moving boards around.

---

↑ Contents

# 18. Modules – Communication

**Menu: Modules > Communication**

Configures how the application communicates with rate control modules. There are three tabs: **Ethernet**, **WiFi** and **CanBus**.

Modules talk to the application either over the network (Ethernet, or WiFi for ESP32 modules) or over CAN Bus. Tick **Enabled** on the Ethernet tab or on the CanBus tab and press Save; ticking one unticks the other. Ethernet is the default. With CAN Bus, Ethernet stays active for AgOpenGPS.

### Ethernet

Chooses the wired network adapter the modules are plugged into, and moves the modules to that adapter's subnet.

| Control | Description |
|---|---|
| **Enabled** | Use the network for module communication (unticks CAN Bus). Applied on Save. |
| **Adapter** | This PC's wired adapters that have an address, shown as name and subnet, e.g. *Ethernet 2 (192.168.1.x)*. WiFi and the tablet hotspot are not listed. If the saved subnet is on no adapter of this PC, such as after a new install or an adapter change, the page picks one by itself: the adapter modules are heard on, otherwise the first. |
| **Status line** | *Modules on this adapter: N*, *No modules heard on this adapter. Press Send to put them on it.*, or *No wired adapter on …* when the cable is unplugged. |
| **Refresh** | Reads the adapter list again, after plugging in a cable or an adapter. |
| **Send** | Tells the modules to move to the selected adapter's subnet. They restart and are counted on the status line once heard. After choosing a different adapter, Send stays greyed out until Save is pressed. |

The steps are shown on the page: select the adapter, Save, then Send.

> **Note:** An ESP32 connected over WiFi ignores Send, so a subnet meant for the cable doesn't take it off its WiFi network.

### WiFi

Sets up an ESP32 module to join a WiFi network from here, instead of from the module's own web page. Setup also gives the module its ID. The module can join either the tablet's own hotspot or the WiFi network this PC is connected to.

| Control | Description |
|---|---|
| **Tablet Hotspot** | The module joins this tablet's Windows Mobile Hotspot. RateController keeps the hotspot on while this is chosen. It is applied on Save, and the hotspot is started every time RateController starts. The hotspot is set to 2.4 GHz, because the module can't use 5 GHz. See Phone Tab for more on the tablet hotspot. |
| **Current WiFi Network** | The module joins the network this PC is connected to in Windows, such as a shop router or a phone hotspot. Connect the PC to it first. |
| **Network** | The network the module will join. For the hotspot: its name and state, which is On, Off, Checking..., *firewall not allowed*, *Off, restarts failed*, or Windows' reason when it can't start. For the PC's network: its name, or *Not connected*. |
| **Hint link** | For the hotspot: *If necessary, turn off Power saving in Hotspot settings*. Windows turns the hotspot off after 5 minutes with no device connected. For the PC's network: a link to **WiFi settings**. |
| **Band line** | The hotspot's band. It also warns when this PC's WiFi is on 5 GHz: the module needs the network's 2.4 GHz band. |
| **Discovered modules** | Module hotspots in range, with signal strength. A module's hotspot is named **RateModule*_ID_6 characters***, e.g. *RateModule_25_1A2B3C*; a new board shows ID 25. Select the module to set up. A lone module is selected by itself. Selecting a module that already has an ID picks that ID, and selecting a new board picks the lowest free ID. The refresh button scans again. |
| **Network password** | The password of the PC's network. It is remembered for that network. It isn't needed for the tablet hotspot, whose password the application knows. |
| **Module Password** | The module's own hotspot password. Leave it blank when the module hotspot is open (the default). It is remembered. |
| **Selected Module ID** | The ID the module gets, 0–7. Connected IDs are marked *(Connected)*. The default is the lowest free ID. Picking an ID selects that module's hotspot in the list, if it's there. |
| **Address link** | The web page address of the selected module, when it's a connected ESP32 on WiFi. Click it to open the page. Other boards show *No web page*, and an ESP32 on Ethernet shows *Ethernet, no web page*. |
| **Set Up** | Starts the setup (see below). |
| **Cancel** | Stops a setup. The PC is put back on its own network first. |
| **Log** | Each step of the setup is written in the box. The log button opens the whole log in a larger window. |

### Setting Up a Module

1. Choose **Tablet Hotspot** or **Current WiFi Network**, and press Save if it changed.
2. Power the module and wait for its hotspot to appear in the list. Select it.
3. Check the **Selected Module ID**, and type the network password if needed.
4. Press **Set Up**. The PC leaves its network for a moment, joins the module's hotspot and sends it the network name, password and ID. The module restarts and joins the network. The PC goes back to its network and waits up to a minute for data from the module, then asks the module what went wrong if nothing arrives. The log ends with *Done: module N is connected.* when it worked.

The page asks first if the chosen ID is already connected (only choose it when setting up that same module again), or if the PC's network password is blank (only for an open network). After a successful setup the list is scanned again, and the next free ID is chosen for the next module.

### Firewall

Windows Firewall can block module data on a phone hotspot or router network. On the first visit to this tab in a session, and after a setup where no data arrived, the page asks to allow it. Windows then asks for administrator permission. The tablet hotspot needs its own permission the first time it is saved. If that's declined, the Network line shows *firewall not allowed*.

> **Note:** The ESP32's radio is 2.4 GHz only. A network that is 5 GHz only can't be used. A dual-band router works when its 2.4 GHz band has the same name.

## Module WiFi (ESP32)

ESP32 modules run their own hotspot and settings page. The WiFi tab above does the usual setup for you. The page is for checking the module or changing it by hand. Connect a phone, tablet or laptop to the module's hotspot, named **RateModule_*ID*_** followed by six characters unique to that board. Then browse to **192.168.*(200 + module ID)*.1**: module 0 is at 192.168.200.1, module 1 at 192.168.201.1, and a new board (ID 25) at 192.168.225.1. Press **Network**. The hotspot is open unless a hotspot password has been set.

The Network page is where the module is pointed at your own WiFi network, so it can reach the application over an existing network instead of you connecting to the module directly.

| Control | Description |
|---|---|
| **Network** | Name of the WiFi network the module joins |
| **Password** | Password for that network |
| **Use this Network** | Ticked, the module joins the network above. Unticked, the module runs its hotspot only. |
| **Scan for Networks** | Lists the networks in range with signal strength, channel, and a padlock on encrypted ones. Tap a network to fill in its name. |
| **Retry Connection Now** | Forces an immediate connection attempt. Shown only when the module is set to join a network and is not connected. |
| **Hotspot Password** | 8 to 10 characters. Leave empty for an open hotspot. |
| **Save/Restart** | Saves the settings and restarts the module |

> **Note:** Tap a network in the scan results *before* typing the password. Tapping reloads the page, which clears anything already typed.

The status line below the settings reports what the module is doing:

| Status | Meaning |
|---|---|
| **Wifi Connected to *name* (address) on channel *n*** | Joined. The address shown is the module's address on your network. |
| **Wifi Not Connected — retrying in the background** | Set to join a network but not connected. The module keeps trying. |
| **Password refused by *name*** | The network rejected the password. Correct it and press Save/Restart. |
| **Hotspot only** | Use this Network is unticked. |

### Joining and Retrying

A module set to join a network keeps trying for as long as the setting is ticked. It does not switch itself back to hotspot-only, and it does not restart itself, so a network that goes down — the shed WiFi switched off, or the machine driving out of range — no longer interrupts work in progress. Earlier firmware gave up after several failures, turned **Use this Network** off and rebooted the module.

Attempts are deliberately spaced out. The module has a single radio shared between its hotspot and its connection to your network, so every attempt takes the hotspot briefly off the air. While a device is connected to the hotspot — a tablet running the application, for instance — attempts are about two minutes apart, or about five minutes if the module has never successfully joined that network. With nothing on the hotspot the module tries more often. Press **Retry Connection Now** rather than waiting.

Loading the module's settings pages pauses the retries for a minute after the last page, so the pages stay responsive while you are configuring. **Retry Connection Now** works regardless.

Scanning for networks takes the radio off the hotspot for a second or two, so a brief pause after pressing **Scan for Networks** is expected.

> **Note:** The hotspot uses the same channel as the network the module joins. Devices on the hotspot drop once the first time a module joins a network, and again if that network later changes channel — they reconnect on their own. From then on the module starts its hotspot on the remembered channel.

Some routers refuse a wrong password in a way the module cannot tell apart from a weak signal. When that happens the status stays on **Wifi Not Connected** instead of naming the password, so check the password whenever a module will not join a network you know is in range.

## CAN Adapter

| Driver | Description |
|---|---|
| **SLCAN** | Serial port-based CAN adapter. Requires COM port selection. |
| **InnoMaker USB2CAN** | Native USB CAN adapter (InnoMaker hardware). No COM port required. |
| **PCAN** | Native USB CAN adapter (Peak PCAN hardware). No COM port required. |

## COM Port (SLCAN only)

1. Use the dropdown to select the COM port the SLCAN adapter is connected to.
2. Press **Refresh** to rescan available COM ports.

## Diagnostics

| Option | Description |
|---|---|
| **Diagnostics** | Enables CAN traffic debug logging in the activity log |

### Status Indicators

| Indicator | Meaning |
|---|---|
| **Module** | Green — module data received within the last 2 seconds |
| **Driver** | Green — CAN adapter is open and receiving frames within the last 4 seconds |

> **Note:** Changing the CAN adapter type or COM port while CAN Bus is active will restart the CAN bridge with the new settings.

---

↑ Contents

# 19. Modules – Config

**Menu: Modules > Config**

Configures the hardware settings of the connected module.

## Module Identity

The underlined line at the top shows which module the module pages are editing — the module number, the board's description (or reported label), and its connection state. It updates live while the page is open. If it turns red with **"Two boards are answering as module N!"**, two powered boards share the same module ID — disconnect one and give it its own ID before continuing.

If the module's board needs a firmware update, the line turns red and reads **Module N (Firmware update required)**. The module is not used, and nothing is sent to it, until its firmware is updated.

Below it, while the module is connected, is the board type it reports, e.g. **Teensy Rate** or **ESP Rate**. Nothing is shown while it is not connected.

Boards are given their module number and description on the Modules > Boards page (§17), which also lists new boards.

| Setting | Description |
|---|---|
| **Module to edit** | The module to edit, listed as *N (Connected)*, *N (Not connected)* or *N (Update firmware)*. All module pages (Config, Communication, Pins, Relay Pins, Valves) and the Send button work on this module; other connected modules ignore the settings. A new choice takes effect straight away, without Save. It is refused while any module page has unsaved changes. |

### Load Preset

Loads a full starting configuration for a known board — the settings on this page, the sensor pins and the relay pins — and saves it. It uses the type of the board reporting on this module. When no board is reporting, it asks which type to load.

| Preset | Microcontroller |
|---|---|
| **Nano (RC12-3)** | Arduino Nano |
| **Teensy (RC11-2)** | Teensy 4.1 |
| **ESP32 (RC15)** | ESP32 |

After loading, check the Pins, Relay Pins and Valves pages against your own board, then press **Send**. Load preset is refused while any module page has unsaved changes. **Rescan** resets the settings on this page only, to be saved or cancelled like any change.

> **Note:** A preset replaces the module's pin and relay settings. Only use it during initial setup or when changing hardware. It does not change the module number.

**Sending to the Module**

Press **Send** to give the module its settings. Send is refused, with a message, when no board is connected on the module being edited, or when its board needs a firmware update. Saved but unsent changes on the Boards page are dropped when that happens; save them again when the board is ready.

## 1. Relay Type

| Value | Description |
|---|---|
| 0 | No relays |
| 1 | GPIOs — use micro-controller pins directly |
| 2 | PCA9555 — 8-relay module |
| 3 | PCA9555 — 16-relay module |
| 4 | MCP23017 |
| 5 | PCA9685 |
| 6 | PCF8574 |

## 2. Pin Assignments by Board

| Parameter | RC5 (Nano) | RC8 (Nano) | RC11 (Teensy) | RC11-2 (Teensy) | RC12 (Nano) | RC12-3 (Nano) | RC15 (ESP32) |
|---|---|---|---|---|---|---|---|
| Sensor Count | 2 | 2 | 2 | 2 | 1 | 2 | 2 |
| Relay Control | 4 | 4 | 1 | 1 | 2 | 4 | 5 |
| Flow 1 | 2 | 2 | 28 | 28 | D3 | 3 | 17 |
| Flow 2 | 3 | 3 | 29 | 29 | — | 2 | 16 |
| DIR 1 | 4 | 4 | 37 | 37 | D6 | 4 | 32 |
| DIR 2 | 6 | 6 | 14 | 14 | — | 6 | 25 |
| PWM 1 | 5 | 5 | 36 | 36 | D9 | 5 | 33 |
| PWM 2 | 9 | 9 | 15 | 15 | — | 9 | 26 |
| Work Pin | — | — | — | 30 | — | 15 | — |
| Pressure Pin | — | — | — | 40 | — | 14 | — |

## 3. Nano Pin Reference

| Pin Name | Number |
|---|---|
| D0–D13 | 0–13 |
| A0–A7 | 14–21 |

## Controls

| Control | Action |
| --- | --- |
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

## 20. Modules – Pins

**Menu: Modules > Pins**

Manually assigns the GPIO pins used for sensors and motor/valve control on the module. The grid shows one row per sensor (the sensor count is set in Modules > Config). Pin values range from 0–50. A blank value (displayed as "–") means the pin is not assigned.

| Grid Column | Description |
|---|---|
| **Sensor** | Sensor/product number (read-only) |
| **Flow** | Input pin for the flow sensor |
| **Dir** | Output pin for the motor/valve direction channel |
| **PWM** | PWM output pin for the motor/valve |
| **Bin** | Input pin for the bin-empty sensor. Leave unassigned ("–") if the product has no bin sensor — the bin alarm is off for that product. |
| **Invert** | Inverts the bin sensor reading. Unchecked: an open input reads *empty* (sensor closes to ground while material is present). Checked: a grounded input reads *empty*. |

| Setting | Description |
|---|---|
| **Work Pin** | Input pin for the work/implement switch |
| **Momentary** | Enables momentary switch behavior on the work pin |
| **Invert Work Switch** | Inverts the work switch reading to suit the sensor type. Unchecked: an open input reads as *working* (normally-closed sensor). Checked: a grounded input reads as *working* (normally-open sensor). In momentary mode the toggle occurs on the opposite edge. Older module firmware ignores this setting. |
| **Pressure Pin** | Analog input pin for the pressure sensor |

Press **Rescan** to clear all pin assignments. Duplicate pin numbers are rejected on Save.

> **Tip: Load preset** in Modules > Config fills in these pin values for a standard board. Only change them if your hardware differs from the standard layout.

### Bin-Empty Alarm

When a Bin pin is assigned, the module watches that input and reports the bin state to RateController. The bin sensor input uses an internal pull-up, so a simple switch or level sensor wired between the pin and ground is all that is required. The module filters the reading — the sensor must hold its state for about 2.5 seconds before the reported state changes, so brief flickers from material sloshing are ignored.

- The alarm is only raised **while the master switch is on** — an empty bin at start-up does not alarm until you begin applying.
- When it triggers, the alarm button shows **Bin Empty** with the product name, the product's tile turns red, and on the selected product the quantity caption changes to **Bin Empty** with the quantity value shown as a red 0.

- The displayed 0 is display-only — the recorded tank amount and quantity applied are not changed, and the real value returns as soon as the alarm clears.
- The alarm clears immediately when the bin refills or the master switch is turned off. Tap the alarm button to silence the buzzer.

> **Tip:** Use a plain digital pin for the bin sensor. Inputs with analog conditioning on the board (such as the pressure input) load the internal pull-up and may not read reliably as a digital input.

### Controls

| Control | Action |
|---|---|
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

## 21. Modules – Relay Pins

**Menu: Modules > Relay Pins**

Assigns the physical GPIO pins to each of the 16 relay outputs on the module. Pin values range from 0–50. A value of 255 (displayed as "–") means the relay pin is not assigned.

- **Low Relays (1–8):** Labeled "Onboard Relays" or "Remote Relays" depending on module config.
- **High Relays (9–16):** Labeled "Onboard Relays" or "Remote Relays" depending on module config.

Press **Rescan** to clear all relay pin assignments.

> **Tip: Load preset** in Modules > Config fills in the relay pins for a standard board.

### Controls

| Control | Action |
|---|---|
| Cancel | Discard changes |
| Save | Save settings |

---

↑ Contents

# 22. Modules – Valves

**Menu: Modules > Valves**

Selects the wiring mode for the valve or motor driver.

| Option | Description |
|---|---|
| **2-Wire** | Motorized or latching valve — the driver actively powers the valve in both directions to open and close it. |
| **3-Wire** | One switched signal wire, one power wire and one ground wire. Compatible with standard solenoid valves and motorized ball valves that manage open/close internally. Default for most installations. |

Select the mode that matches how your valve or motor driver is wired to the module.

## Controls

| Control | Action |
|---|---|
| Cancel | Discard changes |
| Save | Save settings |

↑ Contents

# 23. Rate Map

**Menu: File > Rate Map**

The Rate Map enables variable rate application by defining geographic zones with different target rates. It integrates with AgOpenGPS for GPS-referenced mapping.

## Prescriptions Tab

Manages prescription shapefiles for the current field. The active prescription determines which zone rates are used during application.

| Control | Action |
|---|---|
| **Field** | Shows the field name assigned to the current job |
| **Prescription list** | Lists all prescription files available for the current field. Select one to make it active. **Zones.shp** is the default and cannot be deleted. |
| **New** | Create a new empty prescription file with a given name |
| **Copy** | Copy the selected prescription to a new name. The copy becomes the active prescription. |
| **Import** | Open the prescription import dialog — imports a shapefile or an XML prescription. See Importing a Prescription below. |
| **Export** | Export the selected prescription shapefile to a chosen location |
| **Delete** | Delete the selected prescription file. Zones.shp cannot be deleted. |

> **Note:** Selecting a prescription from the list immediately makes it the active prescription for the current job. The map reloads to show the selected zones.

## Importing a Prescription

The Import button opens a two-step import dialog:

### Step 1 — Import Data

| Control | Description |
|---|---|
| **Shape file / XML** | Choose the source format: a prescription **shapefile** (.shp) or an **XML** prescription file |
| **Import** | Select the file and read it in |
| **Mapping grid** | For shapefiles, match each product (A–E) to the attribute column in the shapefile that holds its rate. For XML files, the layer names found in the file are shown. |
| **Default column** | Fallback rate per product (shapefile import only). Zones missing the mapped attribute receive this rate instead of 0. Tap the cell to enter a value; leave it at 0 for no fallback. |
| **Product** | The primary product (A–E) used when adjusting zones in Step 2. Selected automatically from the imported data; change it if needed. |
| **Name** | File name for the saved prescription |

**Step 2 — Adjust Zones (optional)**

Grid-style prescriptions can contain thousands of tiny zones. Adjust consolidates them into fewer, larger zones that are easier to work with and apply.

| Setting | Description |
|---|---|
| **Max Zones** | Maximum number of distinct rate zones to create |
| **Min zone size** | Zones smaller than this area (Ac/Ha) are merged into their neighbours |
| **Min zone step** | Minimum rate difference between zones — rates closer together than this are combined |
| **Adjust** | Run the consolidation and report how many zones were created |

Press **Save** to save the prescription for the current field. It becomes the active prescription. If the imported data has different product names, RC offers to update the job's product names to match.

## Zones Tab

Create and edit rate zones within the active prescription.

Create zones by clicking the **New** button, then clicking at least **3 points** on the map to define the boundary.

- With **overlapping zones**, the **last zone added** takes priority.
- When variable rate is enabled but **no zone exists**, the **base rate** is used.
- Switching to another tab ends an active **New**/**Edit** — unsaved zone changes are discarded.

| Button | Action |
|---|---|
| New | Create a new rate zone |
| Edit | Edit zone properties (name, rate per product, color) |
| Delete | Delete corner point (while creating) or delete zone (while editing) |
| Cancel | Cancel current edit |
| Save | Save current edit |
| Zone List | Open the Zone List — view all zones with their areas, product rates (A–E), and colors; tap a rate cell to change it; select/deselect zones; delete zones; print the list. To set one rate on many zones at once, check the wanted zones, choose the product (A–E), enter the rate and press **Apply** — then Save or Cancel as usual. |

## Data Tab

| Control | Action |
|---|---|
| Record count | Number of applied rate data points recorded |
| A / B / C / D / E | Select which product's applied rate to display on the map |
| Record | Start/stop recording applied rates |
| Delete | Delete all recorded applied rate data |

### VR Tab — Variable Rate Look-Ahead

Configures how far ahead of a zone boundary the application rate begins adjusting, so the rate matches the target as soon as the machine enters the new zone. Compensates for applicator response lag.

| Setting | Description |
|---|---|
| **Look-Ahead Time (per product)** | Seconds before entering a zone boundary that rate adjustment begins. One value per product (up to 5). |
| **Auto Tune** | RC monitors look-ahead performance and automatically adjusts the value to improve zone entry accuracy. |

### Files Tab

Import and manage supporting data files for the current field. Use the file selector dropdowns to choose which file is active for each overlay layer.

#### Field Boundary

The field boundary defines the operated area and is used to clip automatically generated productivity zones. Select the active boundary from the **KML** dropdown. Import a boundary using the **Import Boundary** button — three file types are accepted:

- **AOG Field.kml** — the field KML from the AgOpenGPS Fields folder; the boundary polygon is extracted automatically.
- **AOG Boundary.txt** — AgOpenGPS boundary file; easting/northing coordinates are converted to lat/lon using the field origin.
- **Any KML (*.kml)** — any KML file containing a polygon boundary.

> **Tip:** Field files are typically found in:
>
> - **AgOpenGPS:** Documents\AgOpenGPS\Fields\[Field Name]\ — contains `Field.kml` and `Boundary.txt`
> - **TWOL:** Documents\TWOL\Fields\[Field Name]\ — contains `Boundary.txt`

### Yield, EC, and Elevation Data

| Control | Action |
|---|---|
| **Yield dropdown** | Select the active yield data file for the overlay and zone creation |
| **Import Yield** | Import a yield data CSV file. If the file contains elevation data, RC will offer to extract it to a separate elevation file. |
| **Delete Yield** | Remove the selected yield data file |
| **EC dropdown** | Select the active EC (electrical conductivity) data file |
| **Import EC** | Import an EC data CSV file (Lat, Lon, EC) |
| **Delete EC** | Remove the selected EC data file |
| **Elevation dropdown** | Select the active elevation data file |
| **Import Elevation** | Import an elevation data CSV file (Lat, Lon, Elevation) |
| **Restore Elevation** | Restore the previous elevation file from the automatic backup |
| **Delete Elevation** | Remove the current elevation data file |

### Create Zones

The **Create Zones** button opens the productivity zone creation dialog. Zones are generated automatically from yield history, soil EC, elevation data, or any combination. Clear existing zones before generating if you want to replace them.

| Setting | Description |
|---|---|
| **Yield files (checklist)** | Check one or more yield data files to include. Multiple years are blended by their assigned weight. |
| **EC** | Include the active EC layer in zone generation |
| **Elevation** | Include the active elevation layer in zone generation |
| **Weights** | Percentage weight for each active layer. All weights must sum to 100 before Build is enabled. |
| **Productivity levels** | Number of productivity classes to create (e.g. 3 = Low / Med / High). Each class may produce more than one zone polygon if the field has non-contiguous areas of the same productivity level. |
| **Min zone size** | Minimum zone area in hectares (or acres). Zone polygons below this size are discarded. Increase to reduce the number of small fragments. |
| **Build** | Generate zones using the selected layers and settings. The field boundary (set in the KML dropdown) clips zones to the operated area. |

> **Tip:** Set the field boundary KML before generating zones. Without a boundary, zones are clipped to the bounding box of the data files, which may not match the actual field edge.

## Display Toggle Buttons (right panel)

These buttons highlight green when active. Click to toggle on or off.

| Button | Action |
|---|---|
| Sat. View | Toggle satellite background image |
| Target Zones | Toggle rate zone boundaries display |
| Applied Rates | Toggle applied rate colour overlay |
| KML Files | Toggle KML file overlay |
| Yield Data | Toggle yield data colour overlay |
| EC | Toggle soil EC colour overlay |
| Elev. | Toggle elevation colour overlay |

### Bottom Controls

| Button | Action |
|---|---|
| Minimize | Shrink the map to a small window. Drag it by its title bar to reposition. |
| Centre | Centre the map on the current GPS position |
| Help | Open the help page |
| OK | Close the Rate Map |

---

↑ Contents

## 24. Rate Graph

**Menu: Help > Rate Graph** (opens as a separate window)

Displays a real-time chart of the PID control loop for a product. Used for tuning Gain and Integral settings.

### Displayed Data

| Element | Description |
|---|---|
| **Target UPM line** | The desired flow rate setpoint |
| **Applied UPM line** | The measured actual flow rate |
| **Error %** | Current deviation from target |
| **PWM value** | Current PWM output (0–255) |
| **Frequency (Hz)** | Current flow sensor frequency |

### Chart Controls

| Control | Description |
|---|---|
| **Auto** | Auto-scale the Y-axis to fit the data |
| **Up** | Increase Y-axis range by 1.5× |
| **Down** | Decrease Y-axis range by 0.67× |

The chart maintains the last 30 data points. Click the graph to select which product to display.

---

↑ Contents

## 25. Scale / Tank Display

**Menu: Products > Settings > Scale Weight** (enable checkbox to show)

Displays a floating window showing tank/scale data for a product. Each product has its own scale display window.

### Display Modes

Left-click on the icon to cycle through four modes:

| Mode | Description |
|---|---|
| **Current Weight** | Net weight from the scale sensor (after tare) |
| **Applied Weight** | Difference between starting weight and current weight |
| **Area Covered** | Area worked since the last reset |
| **Application Rate** | Applied weight divided by area covered |

### Controls

| Action | Result |
|---|---|
| Left-click on icon | Cycles the display mode |
| Left-click on value | Resets the starting weight and acres reference point |
| Right-click on value | Resets the tare (zero calibration) |
| Drag the background (either mouse button), or right-click and drag the icon | Repositions the window. The value can't be used to drag, since clicking it resets. |

---

↑ Contents

## 26. Language Selection

**Menu: File > Language**

Changes the display language of the application.

### Supported Languages

- English
- Deutsch (German)
- Hungarian
- Nederlands (Dutch)
- Polish
- Russian
- French
- Lithuanian

> **Note:** A restart of the application is required for the language change to take effect.

---

↑ Contents

## 27. Color Customization

**Menu: File > Color**

Customizes the foreground and background colors of the application interface.

### Preset Color Schemes

Three built-in color presets are available. Select one to apply it immediately.

### Custom Color

Select **Custom Color** to open the color picker:

1. Click in the **color gradient panel** to select a hue and saturation.
2. The horizontal position controls **hue**.
3. The vertical position controls **brightness/saturation**.
4. Separate foreground and background colors can be selected.

Color preferences are saved and applied immediately across all screens.

---

↑ Contents

## 28. Help – Logs & Diagnostics

**Menu: Help** (main menu)

Provides access to application logs, module diagnostics, and system information.

### Log Files

| Log | Description |
|---|---|
| **Activity Log** | Records application events and UDP/CAN communication activity in real time |
| **Error Log** | Records application errors and exceptions |
| **Ethernet Log** | Records raw UDP packet traffic — useful for diagnosing communication issues |

Press **Start/Pause** to freeze or resume live log updates.

### Activity Log — Module Status Events

When a module connects or its status changes, RC logs the following to the Activity Log automatically:

| Log Entry | Description |
|---|---|
| Module X, Ethernet connected: True/False | Whether the module's Ethernet port is connected |
| Module X, Wifi Strength: 0–3 | ESP32 WiFi signal level — 0 = not connected, 1 = weak (RSSI < -80), 2 = moderate (RSSI < -70), 3 = good (RSSI < -65) |
| Module X, Valves are 2 Wire / 3 Wire | Valve wiring mode reported by the module |
| Module X, Pin Configuration correct / not correct | Whether the module's pin configuration is valid |

These entries are written once on first connect and again whenever the status changes.

### Controls

| Control | Action |
|---|---|
| Start/Pause log | Freeze or resume live log updates |
| Reset logs | Delete all log files after confirmation |
| **PID Logging** | Toggle PID diagnostic logging. While on (green), the module streams per-loop rate control data (target, applied rate, PWM, error) which is saved to a CSV file in the `PIDLogs` folder inside the data folder — useful for tuning and diagnosing rate control problems. The setting is remembered between sessions. |
| Open rate graph | Display the rate graph |
| Check for updates | Check for a newer version of the application |
| Open user manual | Open the user manual |
| Navigate modules left | View previous module diagnostics |
| Navigate modules right | View next module diagnostics |

### Module Diagnostics

| Display | Description |
|---|---|
| **Module ID** | ID of the module currently being viewed (use left/right arrows to switch) |
| **Firmware Version** | Firmware version running on the selected module |
| **Elapsed Time** | Seconds since last module data was received |

### System Information

| Display | Description |
|---|---|
| **IP / Subnet** | Current Ethernet subnet in use |
| **Application Version** | Installed RC software version and date |
| **Current File** | Name of the active profile file |
| **GPS Coordinates** | Live latitude and longitude from AgOpenGPS |

### External Links

Links to the project repositories are available from this screen:

- AOG RC GitHub repository
- PCB Setup GitHub
- Rate Control PCBs GitHub

---

↑ Contents

## 29. Tips & Tricks

### Main Screen Navigation

- **To reposition the main screen**, press and hold (or right-click) in the middle of the screen, then drag it to the desired location. The product and fan icons only drag with the right mouse button, since a left click on them selects the product.
- Use the **minimize button** on the main form to reduce the display to rate only. RC remembers this — if it was minimized when closed, it starts minimized next time.

### Clickable Display Elements

- **Click on target rate label** to switch between the target rate and the alternate rate (a percentage of the target). When variable rate is enabled, the label shows the VR target rate and is not clickable.
- **Click on quantity applied label** to switch between quantity applied and quantity remaining.
- **Click on area applied label** to switch between area applied and area remaining.
- **Click on area applied value** to reset the area counter.
- **Click on the tank bar graph** to reset the tank quantity.
- Click a **product icon** at the top of the screen to select which product's rates and totals are displayed. The rate graph will reflect the currently selected product.

---

↑ Contents

## 30. Troubleshooting

### No Relays Activating

1. Is the module Config set correctly for board type and relay type?
2. Has the subnet been set in the app and uploaded to the module?
3. Have section count and widths been set?
4. Is Auto mode on?
5. Is a section assigned to each relay?
6. Is a switch assigned to each section?
7. If Auto is on, have sensor counts/unit and base rate been set?
8. If Work Switch is enabled (Menu > Switches), the master will only activate when the work switch reads on — check the switch's wiring, pin assignment, and the **Invert Work Switch** setting (Modules > Pins) against whether the sensor is normally-open or normally-closed.

### No UPM (No Flow Reading)

1. Check ground speed.
2. Check working width.
3. Check sensor control settings.
4. Is AgOpenGPS connected?
5. Is the module connected?
6. Check sensor counts/unit.
7. Check base rate.
8. Have control values been sent to the module?
9. Check control type — is it a valve or motor?
10. Is the connector fully plugged in?
11. Is the module running the latest firmware?
12. Is Auto mode on?
13. If Work Switch is enabled, is it reading on? A wrong **Invert Work Switch** setting (Modules > Pins) will hold the master off with no flow, even though everything else is configured correctly.

### Document Applied Manual Rate (Mode 5)

1. Don't assign a real module to a product set to Mode 5 — the module's real sensor data will conflict with the manually entered value.
2. Enter the flow value in units per minute, not per acre/hectare; there is no rate alarm in this mode to catch a units mistake.
3. Applied rate will rise and fall with ground speed even though the flow input is constant — this is expected for a fixed-metering implement.
4. A ground speed source is still required — GPS (via AgOpenGPS), a wheel-speed sensor module, or a manually entered/simulated speed (Menu > Speed) all work; with no speed source active, quantity won't accrue even though the flow value is set.
5. Applied totals reading consistently high or low on a multi-dispenser machine usually means the section count doesn't match the number of dispensers. The entered value must be the whole machine's output

with all sections on, and there must be one section per dispenser with its width set to the ground that dispenser covers — RC scales the flow by section width and has no sensor to check it against.

### AOG Status Light Not Green

1. The AOG light reflects whether AgOpenGPS is sending GPS or AutoSteer position data over the network — RateController does not need to send anything for it to turn green.
2. AgOpenGPS only sends that data once it has an active position source: a real GPS fix, or its built-in GPS Simulator turned on. No fix and no simulator means the light stays red, even if RateController and AgOpenGPS are both running correctly.
3. If your AutoSteer hardware also supplies GPS (common on combined GPS/IMU/steer boards), unplugging it removes the position source too — the AOG light will drop even though AutoSteer itself isn't what RateController is waiting on.
4. To test the connection without field hardware, turn on AgOpenGPS's GPS Simulator — the light should turn green the same way it would with a real fix.

### No Rate Adjustment

1. In manual mode, the master switch must be on.
2. Is minimum PWM too low?

### Motor Won't Shut Off

1. Minimum PWM should be set to 0.
2. Is master override enabled?

### After Updating Module Firmware

1. Use the RateController version released with the firmware. An older RateController shows an updated board as not connected.
2. The board keeps its module number (0–7) but its settings go back to defaults. Resend them: Modules > Config, choose the module, then Send.
3. If the board doesn't connect, resend the subnet (Modules > Communication).
4. A module that shows **Firmware update required** (Config page) or **Update firmware** (Boards page) still has old firmware. Update it; RateController doesn't use that module until then.
5. A board that comes back as **New** on the Boards page is given its module there again (see Setting Up a New Board).

### Phone Page Won't Open

1. The phone and the tablet must be on the same network (File > Options > Phone).
2. Phone hotspot or router: the network must be set to **Private** on the tablet (Options > Phone > WiFi settings). Needed again for a new phone or a renamed hotspot.
3. Tablet hotspot: the status must show *On*. If it shows *On, firewall not allowed*, choose Current WiFi Network on Modules > Communication > WiFi and Save, then Tablet Hotspot and Save, and accept the Windows prompt.
4. If the address shown isn't on the phone's network, tap the QR code to show the next address.
5. Router: guest networks and AP / client isolation stop the phone from reaching the tablet.

6. *Not running, port 8080 may be in use*: another program on the tablet is using port 8080.

### Product Restored After an Interrupted Calibration

This message shows at start when RateController closed during a calibration (power loss, a crash, or ended in Task Manager). The product's original application mode, enabled state and off-rate alarm have been put back, and the speed source restored. Check them before continuing; a calibration that wasn't saved has to be repeated.

↑ Contents