

Modules – Boards

Menu: Modules > Boards

Loads a starting pin layout for a known board type and manages the description saved on the module.

Example Presets

These load a starting pin layout for a known board. After loading, edit the Pins, Relay Pins, and Valves pages to match your own board.

Preset	Microcontroller
Load Nano (RC12-3)	Arduino Nano
Load Teensy (RC11-2)	Teensy 4.1
Load ESP32 (RC15)	ESP32

Usage

1. Select the preset that most closely matches your module hardware.
2. Press **Save** to apply the default settings. The Save button highlights when a change is pending.
3. Review and adjust settings on the Config, Pins, Relay Pins, and Valves pages.

Note: Loading a preset overwrites the current module pin and relay settings with defaults. Only do this during initial setup or when switching hardware.

Current Board

Setting	Description
Description	A short description saved on the module itself to identify the board (e.g. "Left tank Teensy"). It is stored in the module's memory and kept through firmware updates.