

Modules – Comm

Menu: Modules > Comm

Configures how the application communicates with rate control modules. Select either **Ethernet** or **CAN Bus** as the communication type — the two are mutually exclusive. The settings for each are on the **Ethernet** and **CanBus** tabs.

Option	Description
Ethernet	Modules communicate via UDP over the local network. Default mode.
CAN Bus	Modules communicate via a CAN adapter connected to this PC. Ethernet remains active for AgOpenGPS.

Ethernet

Select the PC network interface used to communicate with modules.

Control	Description
IP Address dropdown	Lists active network interfaces on this PC. Select the one on the same subnet as the modules.
Module Subnet	Shows the current subnet the application is using to reach modules.

Buttons

Button	Action
Send Subnet	Sends the selected IP subnet to the module so it knows which address to respond to
Rescan	Refreshes the IP address list and module subnet display

CAN Bus Settings

These settings apply when **CAN Bus** is selected.

CAN Adapter

Driver	Description
SLCAN	Serial port-based CAN adapter. Requires COM port selection below.
InnoMaker USB2CAN	Native USB CAN adapter (InnoMaker hardware). No COM port required.
PCAN	Native USB CAN adapter (Peak PCAN hardware). No COM port required.

COM Port (SLCAN only)

1. Use the dropdown to select the COM port the SLCAN adapter is connected to.
2. Press **Refresh** to rescan available COM ports.

Diagnostics

Option	Description
Diagnostics	Enables CAN traffic debug logging in the activity log

Status Indicators

Indicator	Meaning
 Connected	Green — module data received within the last 2 seconds
 Driver Found	Green — CAN adapter is open and receiving frames within the last 4 seconds

Note: Changing the CAN adapter type or COM port while CAN Bus is active will restart the CAN bridge with the new settings.