

Machine – Pressure

Menu: Machine > Pressure

Calibrates a pressure sensor using two known reference points, and sets a maximum pressure limit per module.

Calibration Procedure

1. Select the **Module** the pressure sensor is connected to.
2. Set the system to a **known low pressure**.
3. Enter the sensor **reading** and the actual **pressure** value.
4. Set the system to a **known high pressure**.
5. Enter the sensor **reading** and the actual **pressure** value.
6. Enter the **minimum sensor reading** that corresponds to 0 pressure.
7. Press **Show** to display the live pressure screen.

Max Pressure

Sets the maximum allowed pressure for the selected module. When the measured pressure exceeds this value:

- The application shows a **High Pressure** alarm.
- The limit is also sent to the module, which reduces flow on its own to bring the pressure back below the limit — this protects the system even if communication with the PC is lost. Requires up-to-date module firmware.

If the pressure limit trips repeatedly in a short time, the module treats it as a fault and keeps reducing flow until the **master switch is turned off**, which resets the protection.

Set Max Pressure to **0** to disable the limit.

Controls

Control	Action
 Cancel	Discard changes
 Save	Save settings