

Machine – Sections

Menu: Machine > Sections

Defines the boom sections and their widths.

- There are **16 sections per module** and up to **8 modules**.
- Module 0 = sections 1–16
- Module 1 = sections 17–32, etc.
- Sections can be defined **individually** or grouped into **zones**.
- All sections in a zone share the same width.
- All sections in a zone are controlled by one switch.
- AgOpenGPS can still auto-control each section individually within a zone.
- When creating a new profile, sections must be defined.
- Sections are also automatically redefined when AgOpenGPS section count changes.

Control	Action
 Copy Button	Copies the width from Section 1 to all other sections
 Cancel	Discard changes
 Save	Save settings