

	AS15	AS15-2	AS15-3
Controller	Teensy 4.1	Teensy 4.1	Teensy 4.1
Receiver Port	8	8	8
IMU Port	5	5	3
RS232 In		3	4
RS232 Out		1	2
Power Relay	0		0
Steer Relay	7	7	1
Steer Switch	26	26	30
Work Switch	27	27	31
WAS			25
Current sensor			26
Motor Dir	23	23	23
Motor PWM	22	22	22
Use ADS1115	TRUE	TRUE	FALSE