How To Use — Model 1575NR

Model 1575NR gives you three settings with a single turn of the nozzle: fog, straight stream and off. Approximate reach is 60 feet.

1. **Open the valve wide**
   At a rack hose station, fully open the supply valve.

2. **Pull the hose off the rack**
   Pull the hose off the rack to release water and pull out the required length. Keep the hose free of kinks.



3. **Hold the nozzle firmly**
   Use both hands. A charged hose creates nozzle reaction, so brace yourself and keep the nozzle pointed in a safe direction.

4. **Turn to adjust the stream**
   Turn the nozzle to choose FOG (wide spray), STRAIGHT STREAM (longer reach) or OFF (shut-off).

5. **Direct at the base of the fire**
   Aim at the base of the flames and sweep side to side. Evacuate and call the fire department.

6. **Shut down**
   Turn the nozzle to OFF, then close the supply valve and drain the hose before re-racking.

IMPORTANT

- Do not direct water at energized electrical equipment.
- Never exceed 200 PSI. Flow is approx. 75 GPM @ 100 PSI — be ready for the reaction force.
- Always call the fire department. Do not fight a fire if it is spreading or your exit is at risk.

tesla fire systems inc.

Toronto — Head Office
1010 Bathurst St, Toronto, ON M5R 3G7
(416) 535-9693 | 1-866-471-2916
info@teslafiresystems.com

Vancouver (Office)
112-970 Burrard Street
Vancouver, BC V6Z 2R4
1-866-471-2916

Montreal (Office)
2001 Blvd Robert-Bourassa, 17th Floor
Montreal, QC H3A 2A6
1-866-471-2916